



USER GUIDE

Contents

1	3D Scanning at a Glance	3
1.1	Activate	3
1.2	Prepare	5
1.3	Scan	5
1.4	Turn and Scan (Optional)	6
1.5	Use Autopilot	6
1.6	Process Manually	8
1.6.1	Crop Surroundings	8
1.6.2	Align	9
1.6.3	Global Registration	9
1.6.4	Eliminate Noise	9
1.6.5	Fusion	10
1.6.6	Erase Flaws (Optional)	10
1.6.7	Simplify Mesh	10
1.6.8	Apply Texture	11
1.7	Measure, Export, Share	11
1.8	Tips and Tricks	12
2	Glossary	13
3	Using the Hardware	15
3.1	3D Scanners	15
3.2	Buttons and LED Indicators for Eva and Spider	16
3.2.1	LED Indicators	16
3.2.2	Hardware Buttons	17
3.3	Hardware Synchronization for Eva	17
3.4	Artec Turntable	17
3.4.1	Recovering Lost Tracking	18
3.5	3D Mouse	18
3.6	Artec Battery Pack	20
4	Installation	23
4.1	System Requirements	23

4.2	User Account	23
4.3	Scanner Activation	24
4.3.1	Running Artec Installation Center	24
4.3.1.1	Logging Out and Switching Accounts	25
4.3.2	3D Scanner Activation Using Artec Installation Center	25
4.4	Artec Studio Installation	26
4.5	Offline Activation	30
4.6	Deactivation	33
4.7	Managing Artec 3D Scanners and Products	33
5	Scanning	37
5.1	Scanner Buttons and Capture Modes	37
5.2	Selecting and Preparing Objects for Scanning	38
5.3	Technique	38
5.4	Scanning Procedure	40
5.5	Tracking Modes	41
5.5.1	Base Removal: Erasing a Supporting Surface	43
5.5.2	Resuming Scan After Lost Tracking	44
5.5.3	Auto-align new scans with those marked in Workspace	46
5.5.4	Scanning With Real-Time Fusion	46
5.5.5	Target-Assisted Scanning	47
5.5.5.1	Placing Targets	48
5.5.5.2	Using Artec Scanners Only	49
5.5.5.3	Using Photogrammetry Solution (Scan Reference)	49
5.6	Using Certain Scanner Types	50
5.6.1	Notes on Scanning With Spider	50
5.6.2	Notes on Scanning With Third-Party 3D Sensors	51
5.6.3	Notes on Scanning With MHT	52
5.7	Tweaking Scanning Options	52
5.7.1	Disabling Distance Color	52
5.7.2	Tuning Texture Brightness	54
5.7.2.1	Preventing Overexposure	54
5.7.3	Sensitivity	55
5.7.4	Frequency for Capturing Texture Frames	55
5.7.5	Deactivating Scanner Flash	55
5.7.6	Tuning Exposure Time	56
5.7.7	Disabling Texture Recording	56
5.7.8	Decreasing Scanning Speed	56
5.7.9	Supplementary Settings	56
5.8	Troubleshooting	57
6	First Steps	59
6.1	Getting Started With Artec Studio	59
6.1.1	Windows, Panels and Bars	59
6.1.2	Primary Settings	60
6.2	Object Types	61
6.3	Workspace Columns	61
6.3.1	Scan list	62

6.4	Workspace Toolbar Commands	62
6.5	Selecting Scans and Models	62
6.5.1	Selecting Frames	63
6.5.2	Selecting Models	64
6.5.3	Selecting Point-Cloud Scans	65
6.6	Memory Management and History	65
6.6.1	Selectively Loading Project Data	65
7	Viewing Scans and Models	67
7.1	3D Navigation	67
7.1.1	Moving, Rotating and Scaling	67
7.1.1.1	Moving	67
7.1.1.2	Rotating	67
7.1.1.3	Flipping	68
7.1.1.4	Scaling	68
7.1.2	Global Coordinate System and Rotation Center	69
7.2	Choosing Projections	70
7.3	Viewpoints	70
7.4	Displaying 3D Data	71
7.4.1	Rendering and Shading Modes	71
7.4.2	Lighting, Color and Texture	72
7.4.3	Back-Face Rendering	75
7.4.4	Representation of Normals and Boundaries	75
7.4.5	Rendering and Texturing Untextured Polygons	75
7.4.6	Displaying Boundaries of Texture Atlas	76
7.5	Saving Screenshots	77
8	Projects, Scans and Models	79
8.1	Creating a Project	79
8.2	Saving a Project	79
8.3	Opening Project and Scans	80
8.3.1	Opening a Project from Leo	80
8.3.1.1	Connecting to Leo	80
8.3.1.2	Using SD Card	81
8.4	Importing Models and Scans	81
8.5	Exporting Models, Scans and Point Clouds	82
8.5.1	Exporting Scans	83
8.5.2	Exporting Meshes (Models)	84
8.5.3	Exporting Point Clouds	85
8.5.3.1	Merging Sections	85
8.5.4	Understanding How Artec Studio Applies Transformations	85
8.5.4.1	Special Aspects of Scan Placement	85
8.5.5	Storing and Exporting Color Information	86
8.5.6	Exporting Target Coordinates	86
8.5.7	Exporting to Leios	87
8.5.8	Exporting to Geomagic Design X	87
8.5.9	Exporting to SolidWorks	89
8.6	History of Project Changes	89

8.7	Autosaving a Project	89
9	Data Processing	91
9.1	Maximum Error and Registration Quality	91
9.2	Revising Scans	92
9.2.1	Separating Scans	93
9.3	Alignment and Registration at a Glance	93
9.4	Editing Scans	94
9.4.1	Eliminating 3D-Noise (Outlier Removal)	94
9.4.2	Erasing Portions of Scans (Eraser)	95
9.4.2.1	Selection Types	96
9.4.2.2	More Actions With Selections	96
9.4.2.3	Erasing Supporting Surface	97
9.5	Fine Registration	99
9.6	Scan Alignment	99
9.6.1	Selecting Scans for Alignment	99
9.6.1.1	Changing Scan Status	100
9.6.2	Displaying Scans in 3D View	100
9.6.3	Summary of Alignment Modes	101
9.6.4	Drag Alignment	101
9.6.5	Auto-Alignment	103
9.6.5.1	Managing Groups and Scans	104
9.6.6	Manual Rigid Alignment Without Specifying Points	104
9.6.6.1	Texture Alignment	104
9.6.7	Specifying Points and Editing Their Positions	105
9.6.8	Manual Rigid Alignment Using Point Specification	105
9.6.9	Nonrigid Alignment	107
9.6.10	Complex Alignment	109
9.7	Global Registration	111
9.7.1	Global-Registration Parameters	112
9.7.2	Global Registration for Point-Cloud Scans	112
9.7.3	Possible Global-Registration Errors	113
9.8	Ray Scan Triangulation	113
9.9	Creating Models (Fusion)	115
9.9.1	Fusion-Algorithm Errors	118
9.10	Editing Models	118
9.10.1	Small-Object Filter	119
9.10.2	Defeature Brush (Editor)	119
9.10.2.1	Selection Types	121
9.10.3	Smoothing	121
9.10.3.1	Smoothing (Tools)	121
9.10.3.2	Smoothing Brush (Editor)	122
9.10.3.3	Smoothing Edges	123
9.10.4	Hole Filling	123
9.10.4.1	Bridges or Smart Hole Filling	125
9.10.4.2	Automatic Hole Filling	127
9.10.4.3	Fixing Holes	128
9.10.5	Mesh Simplification	128

9.10.5.1	Conventional Algorithm	130
9.10.5.2	Fast Mesh Simplification	131
9.11	Texturing	132
9.11.1	Preparing Model	132
9.11.2	Applying Texture (Procedure)	132
9.11.3	Modes	134
9.11.3.1	Texturing for Preview (Triangle Map)	134
9.11.3.2	Texturing for Export (Texture Atlas)	134
9.11.4	Supplementary Settings	134
9.11.4.1	Inpaint Missing Texture	134
9.11.4.2	Remove Targets	135
9.11.4.3	Enable Texture Normalization	135
9.11.4.4	Reduce Glare	135
9.11.5	Texture Adjustment	136
9.12	Texture-Healing Brush: Manual Inpainting	137
9.13	Preparing Models To Export	138
9.13.1	Moving, Rotating and Scaling (Transformation Tool)	138
9.13.1.1	Translate	138
9.13.1.2	Rotate	139
9.13.1.3	Scale	139
9.13.2	Placing Objects on Coordinate Plane (Positioning Tool)	140
9.14	Advanced Techniques	142
9.14.1	Automatic Processing	142
9.14.2	Mirroring	144
9.14.3	Isotropic Remesh	144
9.14.4	Normal Inversion	147
9.14.5	Correcting Triangulation Errors	148
10	Additional Modes	149
10.1	Publishing to the Web	149
10.1.1	Model Requirements	151
10.1.2	Fixing Issues	151
10.2	Multicapturing	152
10.2.1	Bundle Creation	153
10.2.2	Performing Multicapture	155
10.2.2.1	Tweaking Multicapture Options	157
10.3	Measurement Tools	158
10.3.1	Linear Distance	159
10.3.2	Geodesic Distance	160
10.3.3	Using Sections to Measure Area and Volume	161
10.3.3.1	Switching Selections	163
10.3.3.2	Comparing Values	163
10.3.3.3	Exporting Sections	165
10.3.3.4	Displaying Only Sections	165
10.3.4	Surface-Distance Maps	165
10.3.5	Annotations	167
11	Settings	171

11.1	General	171
11.1.1	Project-Storage Path	173
11.1.2	Temporary Folder	173
11.1.3	Autosave Options	173
11.1.4	Registering Artec Studio as Default Viewer	173
11.1.5	Opening Files	174
11.1.6	Surface-Consistency Detection During Import	174
11.1.7	Model Placement	174
11.1.8	Base Removal for Leo Scans	174
11.1.9	Point-Cloud Export	175
11.1.10	Units	175
11.1.11	View-Control Settings	175
11.2	Performance	176
11.2.1	Multithreading	176
11.2.2	Memory	177
11.2.3	Command History	177
11.2.4	Data-Compression Level	177
11.2.5	Texture-Recording Mode	178
11.2.6	Real-Time Fusion Settings	178
11.3	Scan	178
11.3.1	Algorithm Settings	179
11.3.2	Photogrammetry Settings	179
11.3.3	Capture	180
11.3.3.1	Scan Using Auto-Alignment	180
11.3.4	Misalignment Detection	181
11.3.4.1	Default Capture Settings	181
11.4	UI	182
11.4.1	Audio Notification	183
11.4.2	Workspace Colors	183
11.4.3	Warnings	183
11.4.3.1	Startup Checks	183
11.4.3.2	Warnings in Tools and Editor	183
11.4.4	Displaying in 3D View Window	184
11.4.4.1	Display	184
11.4.4.2	Colors	185
11.4.4.3	Screenshots	185
11.4.4.4	Playback	185
11.4.4.5	Background	185
11.4.4.6	Welcome Screen	187
11.4.4.7	Autopilot	187
11.5	Miscellaneous	187
11.5.1	Usage Information	187
11.5.2	Language	187
12	Scanner Calibration and Correction	189
12.1	Suggestions for Use	189
12.2	Launching Diagnostic Tool	190
12.3	Scanner Correction	191

12.3.1	Correcting Field of View for EVA, MHT, MH and L Scanners	191
12.3.2	Correcting Calibration Data for Spider	192
12.4	Spider Calibration	193
12.5	Notes Regarding Scanner-Calibration Files	197
12.6	Assembling the Scanner Stand	199
12.7	Assembling the Calibration Rig	202
13	Hot Keys	203
13.1	Scanning	203
13.2	Workspace	204
13.3	Save, Export and Import	204
13.4	Viewing 3D Content	205
13.4.1	Switching Viewpoint	205
13.5	Editor	206
13.5.1	Transformation Tool	206
13.6	Aligning Scans	207
13.7	Starting Tools, Modes and Dialogs	208
14	Conventions and Acronyms	209
	Index	209

Popular Topics

- *How to scan*
- *Autopilot*
- *Create model manually*
- *Align scans*
- *Apply texture*
- *Orient model*
- *Fusion and Real-time fusion*
- *Bridges or Smart Hole Filling*
- *Export model*
- *Measure model*
- *About your scanner*
- *Ask for help*

Artec Studio is an industry-acclaimed software package for advanced 3D scanning and data processing. It enables you to scan countless objects using *Artec scanners*.

This manual will show you how to use the application as well as your 3D scanner to quickly and easily create great-looking 3D models. Use the left panel to get an overview of the entire manual, or refer to the *Quick Start Guide*. To get the most out of the documentation, review the various *terms* we use throughout. Consult the genindex to find references for specific parameters that appear in processing algorithms. Also, take a look at the *Conventions and Acronyms* section for a key that describes how we highlight semantic elements.

The incomplete list of chapters below is intended to clarify the document structure.

- *3D Scanning at a Glance* (Quick Start Guide) is a brief overview of scanning and processing basics. It also covers *Autopilot* mode.
- *Using the Hardware* covers hardware-related matters: scanners, third-party 3D sensors and 3D mice
- *Scanning* explains the basic principles of object scanning and offers advice on how to conduct the scanning process to obtain the best results.
- *Viewing Scans and Models* describes ways in which to control an object's appearance in the *3D View* window and obtain the best view of the 3D model.
- *Projects, Scans and Models* contains information on data management, working with projects, exporting and importing data, undoing recent operations, and saving the history of project changes.
- *Data Processing* focuses on data-processing techniques: working with separate

scans, alignment, fusion, filters, defect-elimination methods and texturing.

- *Additional Modes* demonstrates how to publish models on the Web; how to use additional features, such as employing several scanners to capture an object; and how to use measuring tools.

In addition to this manual, you can find practical tips and other information at the [Support Center](#). If you encounter an issue when using our 3D scanners or applications, please [submit a request](#).

Documentation for earlier versions of the software is available [here](#).

CHAPTER 1

3D Scanning at a Glance


Before you start using the guide, we want to show you how easy 3D scanning can be. Although this well-structured manual covers all the matters related to Artec scanners and software, you may find it helpful to have an overview at your fingertips. This brief summary will assist you in getting started right away! But if you prefer to begin with comprehensive and detailed information, you can skip this chapter.

1.1 Activate

The scanner case includes everything you need to start 3D scanning, except a computer. At a minimum, your PC must run the 64-bit version of Microsoft Windows 7 or 8 (10 is also supported). The more powerful the PC, the better. The main memory (RAM) and graphics card are the most critical components (visit our [FAQ page](#) for more information).

Warning: Don't connect the scanner just yet! Continue reading for more information.
--

1. Register for an account at [my.artec3d](#)
 2. Sign in and download Artec Installation Center from the welcome page
 3. Install Artec Installation Center. When prompted, enter your email and password.
 4. Plug the scanner into a power outlet, then connect it to your PC using the USB cable
 5. Wait for Windows to detect the scanner. Click *Activate*.
 6. Click *Install* in the *Software* section to get Artec Studio running on your machine
- (For more details, see [User Account](#), [Scanner Activation](#) and [Offline Activation](#).)



1.2 Prepare

Most objects are easily scannable. Before scanning transparent, reflective or black objects, we suggest applying a powder coating or a special anti-glare spray.

To scan monochrome objects with simple geometric shapes, do the following:

- Add auxiliary objects (e.g., crumpled paper) to the scene
- Paint markers (e.g., “X” shapes) on the surrounding surfaces

Be sure to provide good ambient light. (For more info, see [Selecting and Preparing Objects for Scanning](#).)


1.3 Scan




1. Launch Artec Studio, then aim the scanner at the object.
2. Press ► on the scanner to start *Preview* mode. If your scanner lacks this button, first open the *Scan* panel.
 - *Geometry + Texture* is the default scanning mode and is suitable for most cases
 - For older PCs, *Geometry* mode is a good alternative
 - The *Real-time fusion* mode creates a model in real time, allowing you to skip postprocessing; click *Stop*, then select the *Real-time fusion* checkbox and click *Preview*.
3. Make sure the object is visible, then press ► once again to initiate recording. If possible, scan all sides of the object in one go, slowly moving the scanner around it as pictured below.

Note: While scanning, pay closer attention to the object on the screen than to the actual object.

4. If you hear an alert sound and the screen displays an error against a red background, smoothly aim the scanner at the area you just captured. Possible reasons for the “Tracking lost” error include the following:


1. You are scanning simple geometric shapes
2. The part of the object you are scanning is too small
3. Scanner movement is too fast
5. Press  to display the scan in the *Workspace* panel.



1.4 Turn and Scan (Optional)



Note: This part is optional.

Turn the object and capture any remaining unscanned regions (press ). Also, to facilitate alignment, record at least one previously scanned region.

(For more info, see [Buttons and LED Indicators for Eva and Spider](#), [Tweaking Scanning Options](#), [Scanning Procedure](#), [Tracking Modes](#), and [Scanning With Real-Time Fusion](#).)

1.5 Use Autopilot



For beginners, the easiest way to obtain a 3D model is by using [Autopilot](#). It's also a great time saver for advanced users. If you prefer performing all the steps manually, refer to the [Process Manually](#) section.


Autopilot is a special mode that helps users obtain a complete 3D model without learning all the ins and outs of postprocessing. It consists of two major parts: semiautomatic


(editing and alignment) and automatic¹.

Tweaking Autopilot Settings

- *Hole-filling method* (available options are *Don't fill*, *Watertight* and *By radius*) instructs the algorithm to fill or not fill holes in the model.
- *Model resolution*—the lower the resolution value, the sharper the shape and the more details you will see. If you're unsure, leave the value as Auto. Effectively, it's the same as *Creating Models (Fusion)* resolution. Note that the resolution should be no less than 0.5 for scans captured using EVA and no less than 0.1 for Spider.
- *Polygon count* determines how many polygons the resulting model will have. The greater the value, the better the quality and the larger the file size. If you're unsure, leave the value as Auto. For more information, consult the *Mesh Simplification* section.
- *Texture*—clear this checkbox if you don't want to apply texture to the model.
- *Texture resolution* takes specific values in the range of 512x512 to 8192x8192 or 16384x16384 pixels depending on the available GPU memory.




To produce a model,

1. Click *Autopilot* in the left panel or hit F9.
2. Become familiar with the steps that you will perform in this guided mode (listed in the welcome screen).
3. In the *Workspace* panel, use the  flag to mark all scans that you intend to use, then click *Next*.
4. Then specify the input parameters for the model-creation step and click *Next*. Primary settings may include the following:

Note: We suggest consulting the tool tips, which you can reveal by clicking the  button next to the option name.

¹ Automatic steps may include the following:

1. Fine registration
2. Global registration
3. Outlier removal
4. Fusion
5. Small-object filter
6. Mesh simplification
7. Texturing
8. Texture optimization (Texture inpainting)

- a. *Scan quality (geometry)*. Click  to determine whether your scan of the object has the correct geometry by examining the tool-tip images.
 - b. *Scan quality (texture)*. Click , look at the images and decide whether your scan has sufficient texture.
 - c. *Hard-to-scan surfaces*. Select the checkbox if your object has surfaces that are difficult to capture. Consult the image samples by clicking the  button.
 - d. Decide on the *Object size* by referring to the image samples.
 - e. Leave the default values for the remaining options in this window (sufficient for most cases). For advanced scenarios, you can tweak these settings (more details appear in the *sidebar*).
5. If necessary, erase any extraneous objects that can hinder postprocessing. Learn how to use Eraser by consulting the *Erasing Portions of Scans (Eraser)* section.
 6. Once you're done, click *Next*. If the object was captured over several scans, Autopilot will align them and show you the result. You can approve it or align the scans manually (consult *Manual Rigid Alignment Without Specifying Points*).
 7. Click *Next*.
 8. Autopilot will begin postprocessing¹. Once it's finished, a message will appear informing you that the model is ready. Click *OK*.


1.6 Process Manually

1.6.1 Crop Surroundings



Once you finish, click *File* and select *Save project*. Close the *Scan* panel. You can now crop the surroundings.

Purpose: To erase auxiliary surfaces (e.g., a table or floor).




Steps: Open *Editor* → *Eraser* → *Cutoff-plane selection*. Follow the instructions.

(For more info, see *Editing Scans*.)


1.6.2 Align



Purpose: To align several scans. Skip this step if only one scan is in the *Workspace* panel.



Steps:

1. Mark two or more scans using , click *Align* and select those scans in the *Rigid* tab while holding the `Ctrl` key.
2. Click *Auto-alignment*.
3. If alignment fails owing a lack of texture or lack of overlapping areas, manually match the features among the scans and click the *Align* button.

(For more info, see [Scan Alignment](#).)

1.6.3 Global Registration



Purpose: To simultaneously optimize the frame position across all scans, thus preparing them for further processing.

Steps: Mark scans using , then click *Tools* → *Global registration* → *Apply*.

(For more info, see [Global Registration](#).)


1.6.4 Eliminate Noise



Purpose: To erase large outliers and some noise.

Steps: Open *Tools* → *Outlier removal* → *Apply*.


(For more info, see [Editing Scans](#) and [Eliminating 3D-Noise \(Outlier Removal\)](#).)



1.6.5 Fusion



Purpose: To create a model (a single surface, as opposed to the multiple surfaces that constitute the source scan).



Steps: Select *Tools* → *Smooth fusion* → *Watertight* → *Apply*.


To obtain sharper surfaces, select *Sharp fusion*. In both cases, *resolution* can be adjusted: the smaller the value, the more precise the resulting surface.

(For more info, see [Creating Models \(Fusion\)](#).)

1.6.6 Erase Flaws (Optional)



Purpose: To erase any outliers and poorly scanned regions.



Steps: Click *Editor* → *Defeature brush*. Follow the instructions.

(For more info, see [Editing Scans](#).)

1.6.7 Simplify Mesh



Purpose: To reduce the file size by decreasing the number of polygons without significantly distorting the actual 3D geometry.



Steps: Click *Tools* → *Mesh simplification* → *Apply*.

(For more info, see [Mesh Simplification](#).)

1.6.8 Apply Texture



Purpose: To create a textured model.



Steps:

1. Click *Texture*.
2. Select fusion and its “parent” scan(s) in the corresponding fields.
3. Select texturing for *Export* → *Apply*.

(For more info, see [Texturing](#).)

1.7 Measure, Export, Share





- Export the model: open *File* → *Export mesh*. Select the required format, specify the folder and file name, then click *OK*.
- Measure the model: open *Measures*, then select one of the following:
 - *Linear* for distance calculation (points are connected by lines)
 - *Geodesic* for distance calculation (points are connected by curves that pass over the model surface)

- *Sections* for area and volume calculation
- Share the model on viewshape.com by opening the *Publish* toolbar

(For more info, see *Exporting Models, Scans and Point Clouds*, *Publishing to the Web* and *Measurement Tools*.)

1.8 Tips and Tricks

- You can reset all settings to their defaults using `F10` → *Scan* tab → *Reset to defaults*
- To return any altered parameters in the *Tools* panel to their default values, click the adjacent  button. The  button indicates a default value.
- Save screenshots by hitting `Ctrl+Shift+S`
- Apply annotations using *Measures* → *Annotations*, enter the tag label and type text, then click *Apply*.

CHAPTER 2

Glossary

The following terms related to Artec Studio and 3D scanning appear regularly in this manual.

accuracy – general term How closely a measurement matches the actual value of the quantity being measured.

Autopilot An advanced smart mode that guides the user through postprocessing in a few steps, automatically selecting the most effective settings and producing a 3D model.

bundle Capture of an object through simultaneous use of multiple scanners, whose numbers and relative positions are specified in the application.

CAD model Feature-based, editable solid model used in manufacturing. It can be created in a CAD system or reverse-engineering software package.

fine registration A thorough frame alignment using an algorithm for relative positioning of sequential frame pairs.

frames 3D surfaces captured during a scanning session. The maximum scanning rate is 15 frames per second (30 frames per second for Microsoft Kinect, PrimeSense Carmine and Asus Xtion sensors).

fusion Process that creates a polygonal 3D model. It effectively melts and solidifies the captured and processed frames or point-cloud surfaces. Fusion can be run as a separate *algorithm* or throughout the scanning (*Real-time fusion*).

global registration Algorithm that optimizes the relative positions of all frames using a single coordinate system.

key frames Frames used by the global registration algorithm. The algorithm selects them automatically to fully cover the surface of the captured object using as few as possible.

mesh The surface geometry of a 3D model; it comprises a series of linked polygons.

model The 3D object that results from the fusion operation (in Artec Studio) or another modeling process in a different software package.

near and far cutting planes Planes that limit the space in which the scanner is capturing 3D frames. The device will ignore everything that is closer than the near cutting plane or more distant than the far cutting plane.

project A method of managing the scanned material, processed data and user operation history, either in memory or on disk. Artec Studio project files use the *SPROJ* extension.

resolution; general term The ability of a scanning system to capture detail in an object.

rough registration Preliminary frame alignment performed during capture.

scan A sequence of frames captured in a single continuous movement of the scanner around an object or scene.

section; in a point-cloud scan Corresponds to the region selected in the Ray preview area. The application may save these sections in the export files differently (*Merging Sections*).

section; in measurements Short for cross-section. Section is the plane that splits model or scan into two parts (*Using Sections to Measure Area and Volume*).

supporting surface A surface on which the object is resting (e.g., a table or the floor).

targets Stickers placed on the object being scanned to ease identification of the various regions. There are two types of targets: non-coded and coded. Unless the type is explicitly specified, the target is considered non-coded. Typically, a non-coded target is a round sticker that has a black ring with a white circle in the center; a coded target has a unique code ring that photogrammetry software can automatically recognize.

tracking Calculation of the scanner's position in a coordinate system relative to the scene. You can also find these terms along with some algorithm parameters in *genindex*.

CHAPTER 3

Using the Hardware

3.1 3D Scanners

Artec Studio can work with one or more Artec 3D scanners. It offers tools to quickly create 3D models of physical objects. Besides managing the process of capturing objects, it lets you perform full data postprocessing, optimize mesh tessellations and apply other operations to obtain a quality 3D model. You can then send the complete model to a CNC machine or import it to another 3D-modeling application.



Figure 1: Features of Artec 3D scanners: Space Spider (left) and EVA (right).

Most Artec 3D scanners are specifically designed for handheld use, offering light weight and compact size. Being structured-light 3D scanners, they don't require you to place any special targets on the object you're capturing. Using them is easy—no special knowl-

edge or skills are necessary. To obtain a complete 3D model, simply scan the object from different angles and fuse the resulting scans into a single model using Artec Studio.

Depending on the size of the object you're scanning, use either Artec Ray, Leo and Eva, Spider or Micro. The primary difference between these models is the depth and field of view. They also differ in 3D resolution as well as point accuracy; consult the [Artec web site](#) and respective manuals for details.









Figure 2: Fields of view for Eva and Spider 3D scanners.

You can combine several different scanner types while capturing a scene. In some cases when capturing complex shapes, this capability increases the scanning rate and enables you to achieve your desired precision.

3.2 Buttons and LED Indicators for Eva and Spider

3.2.1 LED Indicators

Artec scanners include built-in multicolor indicators. By explaining the meaning of these indicators, the list below enables you to keep track of the scanning process:

-  **Steady blue**—scanner is booting up.
-  **Flashing green**—Artec Studio cannot detect a 3D scanner.
-  **Steady green**—scanner is connected to the application and ready to use.
-  **Flashing red**—scanner is in *Preview* mode, or tracking in *Recording* mode is lost.
-  **Steady red**—scanner is in *Recording* mode and object tracking is proceeding correctly.

3.2.2 Hardware Buttons

The Artec EVA and Artec Spider 3D scanners have three-position buttons on their bodies:




Figure 3: Scanner buttons: Artec Spider on the left and Artec EVA on the right.

- ▶ –press this button once to open the *Scan* panel and start *Preview* mode; press it once more to switch to *Recording* mode. Subsequently, pressing this button will switch between *Preview* and *Recording*.
- –press once during a scan to stop the scanning process; press twice to stop scanning and close the *Scan* panel.

3.3 Hardware Synchronization for Eva

Artec EVA is equipped with two jacks designed for 6P6C connectors (RJ12). By creating a bundle, you can link multiple Artec EVA scanners to each other. The master device is a leading scanner that sends signals to the next slave device. Each subsequent device is connected to the previous one sequentially as [Figure 4](#) shows. To connect the devices, you can use a standard phone cable (*RJ12 6P6C*) or any other cable that uses the conductor scheme shown in [Figure 4](#). Each scanner should also connect to the PC via USB.

Warning: Only Artec EVA scanners can connect to each other. Do not connect Artec EVA to a telephone wall port!

3.4 Artec Turntable

Artec Turntable is designed to ease scanning of small and midsize objects by eliminating the need to rotate them manually. Both the rotary plate and the mat that comes with the turntable feature a special pattern to ensure robust tracking with Artec scanners. The mat is made of silicone, which prevents objects from sliding off the rotary plate.

To scan using Turntable, follow the steps:

1. Ensure your computer has a Bluetooth adapter that supports the 4.0 standard.
2. Add a new Bluetooth device.




Figure 4: Synchronization scheme.

Jacks on the Artec EVA scanner shown at left and conductors in a 6P6C connector shown at right.

3. Open Artec Studio.
4. Access the *Scan* panel.
5. Select the *Use turntable* checkbox.
6. Place the object on the turntable.
7. Click *Preview*.
8. Click *Record* to start capturing. The turntable will start rotating.
9. Click *Pause* or *Stop*. The turntable will stop rotating.

3.4.1 Recovering Lost Tracking

If you experience a *tracking loss*, Artec Studio will pause the turntable. It also turns the rotary plate back by about 15 degrees. Once the application has recovered tracking, it resumes rotation.

3.5 3D Mouse

Artec Studio can work with 3Dconnexion manipulators.

Basic support includes navigation in *3D View* and the following commands:

- Home
- Fit to view
- Undo
- Redo

For 3D mouse to function, you need to install drivers from the manufacturer's [web site](#). Additionally, you can assign four currently supported commands to the mouse radial menu or at least two of them to the hardware buttons for Artec Studio.

To assign a command to the 3D mouse button, follow the steps:

1. Open Artec Studio
2. Then open *3Dconnexion Properties* utility from the Windows tray
3. Click *Buttons*
4. Click on the > arrow on the right side of either button field. A flyout window will open for that 3D mouse button.
5. Open the *Artec Studio* category
6. Select either of the currently supported command.




Figure 5: Assigning command to 3D mouse button.

If you want to assign several commands, create a new *Radial menu* (use the eponymous category in the flyout menu). For more information, consult the manual for your 3Dconnexion mouse.

To get used to navigating 3D content, use *3Dconnexion Trainer* or *3Dconnexion Demo* from the *3Dconnexion Home* application.

Note: In Artec Studio, you move the camera around the object rather than the object itself.

3.6 Artec Battery Pack

Available as an accessory, battery pack allows you to scan anywhere without the need to be near a power outlet. Battery from this pack supports Artec EVA, Artec Spider and Artec MHT scanners and lasts for up to 6 hours of scanning.



Figure 6: Battery pack with Eva.

Battery pack includes the following items:

- Battery
- Battery pouch

- Power adapter (110–230 V → 19 V)
1. Fully charge Artec battery using its *Input* socket.
 2. Plug the cable into the battery *Output* socket.
 3. Then connect the cable to your Artec scanner.



Figure 7: Battery ports from left to right: Input, Output.

Important: Never confuse battery ports when connecting scanner.

4.1 System Requirements

Your computer must meet [the system requirements](#) to use Artec 3D scanners.

In addition, take note of the following:

Real-time fusion mode (*Scanning With Real-Time Fusion*): ensure that your graphics card has at least 1 GB of memory or your Intel HD Graphics chipset is 4600 or higher (consult the [FAQ article](#) for more information).

Using Intel RealSense camera requires your computer to run Windows 8 (Windows 10 for SR300) and to feature at least 4th Generation Intel Core processor and USB3.0

Using Kinect v2 requires your computer to run Windows 8 and to feature 3.1 GHz (or faster) processor with physical dual-core (2 logical cores per physical) and USB3.0 based on Intel or Renesas chipset.

Using multiple scanners (*Multicapturing*) requires your workstation to integrate as many independent USB host controllers as connected scanning devices. Upgrading your hardware with PCI/PCI Express USB cards may provide the required number of hosts.

4.2 User Account

To install Artec Studio and keep it up to date, register for a free account at [my.artec3d](#). Registration is also required to activate an Artec 3D scanner. In addition, the site allows you to track all your Artec devices and products.

Your account at [my.artec3d](#) will be valid for all Artec sites and services (including [view-shape.com](#)).




Figure 8: *my.artec3d* welcome screen.

To register, follow these steps:

1. Go to *my.artec3d* and click *please sign up*
2. Fill in all the fields in the registration form (by clicking *Next*) and click *Create account*
3. Receive a registration email that contains a confirmation link.
4. Click the link or copy it to your browser to confirm your registration and go straight to your *my.artec3d* account.

4.3 Scanner Activation

Before using your new Artec 3D scanner, you must activate it and link it to an account at *my.artec3d*. You can do so with the help of Artec Installation Center—a standalone utility available for download from *my.artec3d*. If you're a new user and don't yet have Artec Installation Center, please read *Running Artec Installation Center* below. Otherwise, proceed to *3D Scanner Activation Using Artec Installation Center*.

Warning: Do not connect your scanner to the USB port before installing Artec Installation Center.

4.3.1 Running Artec Installation Center

To use Artec Installation Center, first ensure that your computer is connected to Internet. Any computer with USB2.0 or USB3.0 ports will work. If necessary, you will be able to install and activate Artec Studio on a separate computer later. Also make sure that you already have a *my.artec3d* account; if not, see *User Account*.

1. Log into your *my.artec3d* account and download Artec Installation Center. The link for the Artec Installation Center executable is available in the *My software* section.
2. After downloading, open the folder that contains the executable and run it. Follow the instructions on the installation screens. Once Artec Installation Center is installed, you will see a dialog requesting your email address and password. Use your *my.artec3d* account to log in as Figure 9 shows.




Figure 9: Authentication for Artec Installation Center

4.3.1.1 Logging Out and Switching Accounts

You may need to change *my.artec3d* account. Artec Installation Center displays the current user email in the top-right corner (Figure 26).

To log out of Artec Installation Center:

1. Click *Log out*.
2. Enter another user's email and password in the window that opens.
3. Click *Sign in*.

4.3.2 3D Scanner Activation Using Artec Installation Center

To activate a 3D scanner using Artec Installation Center, make sure your computer is connected to the Internet and that you have installed the application.

1. Run Artec Installation Center (go to the Start menu: click *Start* → *All Programs* → *Artec Group* → *Artec Installation Center*) to bring up the window shown in Figure 26.
2. Connect your new Artec 3D scanner to the computer and wait until Windows detects the device and installs the necessary drivers. You may see a notification similar to one shown in Figure 10.
3. Go to Artec Installation Center, click *Refresh* and wait for the new 3D scanner to appear in the hardware box. Click *Activate* (to the right of the serial number) to

enable your 3D scanner. The status of the device should change to *Activated*, as Figure 11 shows.




Figure 10: Windows notification indicating device installation.



Figure 11: 3D scanner activated

4.4 Artec Studio Installation

There are two ways to download and install Artec Studio:

- Through Artec Installation Center (either during the installation process or by clicking *Install* in the application, as Figure 12 shows)
- From my.artec3d.com—log into the site, go to the *My software* page and download the executable (see Figure 13)



Figure 12: Artec Installation Center is ready to install Artec Studio.


If you download the executable, run it to begin installation; otherwise, click *Install* in Artec Installation Center. To continue with the installation, click *Next* and proceed to the license agreement (see Figure 14). After reviewing the agreement, accept it by clicking *Yes*.

Specify the path to the installation folder (we recommend using the default location) as Figure 15 shows, then select the components you would like to install (see Figure 16):

Program-menu shortcuts create icon in the Start menu

Desktop shortcut create icon on the desktop

Start-menu shortcut add shortcuts to the Start menu and Quick Launch panel


John Smith Logout

[Scanners](#)
[My software](#)
[Support Center](#)

AIC

Product name	Available version	Download links
Artec Installation Center	1.5.16.4	64-bit

Applications

Product name	Installations	Available Version	Download Links
Artec 3D Scanning SDK		2.0.0.56	64-bit
Artec Studio 14 Professional (1 year subscription)	0 of 1	14.1.2.39	64-bit

Figure 13: Portion of *My software* page at *my.artec3d*.

Figure 14: License agreement




Figure 15: Installation location




Figure 16: Select components to install




Figure 17: Click *Install* to begin the installation




Figure 18: Artec Installation Center showing Artec Studio activation window




Figure 19: Finish installation

English manual install user manual in English

Artec scanner drivers install drivers for Artec 3D scanners

Artec Ray drivers install drivers for Artec Ray 3D scanner

Artec Micro drivers install drivers for Artec Micro 3D scanner

PrimeSense Carmine / Asus Xtion drivers install drivers for PrimeSense/Asus 3D sensors

Intel RealSense Runtime install drivers for Intel RealSense cameras

By default, the application will create all of the above icons and install the user manual and Artec 3D-scanner drivers. To continue with the installation, click *Next*.

If you have yet to install Artec Installation Center, a login dialog will appear, as [Figure 9](#) shows. If you are not connected to the Internet, consult [Offline Activation](#) regarding offline activation of Artec Studio.

If you have yet to link to your account the computer on which you are installing Artec Studio, you will see the activation confirmation shown in [Figure 17](#).

When the installation is complete (see [Figure 18](#)), the installer will offer to launch Artec Studio.

4.5 Offline Activation

If the computer on which you are installing Artec Studio lacks an Internet connection for security or other reasons, you may use the offline activation procedure to activate the software.

Note: Copies of Artec Studio activated offline cannot be deactivated, so use this option only if absolutely necessary.

Note: Before conducting offline activation, make sure the scanner (see [Scanner Activation](#)) and Artec Studio are tied to your [my.artec3d](#) account.

For offline activation, you need the following:

- Another computer connected to the Internet
- Artec Studio installation package (preferably, download it from [my.artec3d](#))
- Flash drive or another storage medium to transfer files from the Internet-connected computer to the computer that will run Artec Studio

Installation and activation procedure:

1. Start Artec Studio installation.




Figure 20: Artec Installation Center authentication dialog




Figure 21: Artec Installation Center – Activate offline




Figure 22: Offline-activation window

2. During installation the login/password dialog will be displayed as **Figure 20** shows. Click *Continue offline*.
3. Click the *Activate offline* button in the pop-up window.
4. In the offline-activation dialog (**Figure 22**), click *Save...* and save generated Activation ID file to a flash drive or other storage medium.
5. Log into your *my.artec3d* account and open *My software* page using the Internet-connected computer.
6. Find Artec Studio and click on it. A new page will appear, as **Figure 23** shows.
7. Click the *Activate application offline* link then the *Select file* button and specify the Activation ID file path. Next, click *Activate*.
8. A new dialog will allow you to download an Offline Activation Data file; save it to the flash drive.
9. Return to the computer on which you are installing Artec Studio. Click *Activate and Continue* and specify the Offline Activation Data file.

Note: Once you create the Offline Activation Data File, *my.artec3d* will decrease the number of available activations by one.

Once you complete all the steps described above, your copy of Artec Studio will be activated and all of your Artec 3D scanners will be installed on the non-Internet-connected computer.



Figure 23: Offline activation at *my.artec3d*.

Note: If later you purchase another Artec 3D scanner, you must reinstall the application and repeat the activation procedure described above to copy the new scanner's data files to your computer.

4.6 Deactivation

Note that deactivation is only possible for computers on which you activated Artec Studio online as *Artec Studio Installation* describes. Artec Studio installations activated offline cannot be deactivated.

Note: The number of deactivations may be limited, so deactivate Artec Studio only if you absolutely must move it from one computer to another.




Figure 24: Deactivation of Artec Studio.

To deactivate a license on your computer, follow these steps:

1. Make sure the computer is connected to the Internet.
2. Go to *Control Panel* → *Uninstall Applications* and click on Artec Studio. The uninstallation process will start.
3. The dialog shown in *Figure 24* will appear. Select the *I understand. Deactivate Artec Studio* checkbox.
4. Click *Next* to complete the uninstallation.

4.7 Managing Artec 3D Scanners and Products

Artec Installation Center manages applications and 3D scanners linked to your account.

It's a multifunctional supplement to Artec Studio that connects with *my.artec3d* and helps you install new applications, download updates and manage your 3D scanners. To launch Artec Studio for the first time, you must log into *my.artec3d*. After this one-time authentication, you need not provide your email address or password each time you launch the application.

When Artec Studio launches, Artec Installation Center checks for new updates; if an update is available for any installed product, the software will display a notification like the one shown in [Figure 25](#).




Figure 25: An Artec Studio update is available for download.

Once you log in, Artec Installation Center displays information about your products.




Figure 26: Artec Installation Center.

The *Software* section of Artec Installation Center provides all information about your software products:

- A list of all applications available to you
- Activation status of each application (application may or may not be activated)
- Total number of activations and number of activations you've used so far
- *Activate*, *Install* or *Update* buttons for any of these actions that are currently available to you
 - *Install*—appears if the software is not installed on the computer (installation usually means activation)
 - *Activate*—appears if the software is not currently activated on the computer. Activation decreases number of licenses by one for each computer.

- *Update*—appears if a new version of installed software is available for download

The *Hardware* section contains a list of the scanners that you own or have otherwise connected to your computer. For the first case, the *Activated* status or *Activate* button will be displayed, while in the second case, the *On loan* status or *Rent* button will be displayed.

A row of buttons appears at the bottom of the Artec Installation Center window:

Refresh –refresh the data displayed by Artec Installation Center

Close –exit Artec Installation Center

5.1 Scanner Buttons and Capture Modes

Your 3D scanner may be in one of the following capture modes (each of which has a corresponding color and flicker rate of the LED indicator on the device if you're using an Artec scanner):











Figure 27: Understanding capture modes (colors correspond to scanner LED indicator colors).

Idle—the LED is steady green . This mode indicates either that the application has detected the scanner or that the user has clicked the *Stop* button in the *Scan* panel or pressed the  button on the scanner body (see [Figure 3](#)). In this case, the 3D scanner is not flashing.

Preview—the LED is flashing red . In this mode, the 3D scanner is capturing images, but the software is neither performing alignment nor recording captured frames. To start this process, either click the *Preview* button in the *Scan* panel (see [Figure 40](#)), press the  button on the scanner body or hit the **F7** key on the keyboard. This mode is useful when doing the following:

1. Checking the 3D scanner's field of view

2. Determining the best position for the object
3. Preparing to recording and developing a scan procedure
4. Adjusting texture brightness

Recording—the LED is steady red  Scanning takes place in this mode, with the software storing 3D data to disk or RAM. Activate this mode either by clicking the *Record* button in the *Scan* panel, hitting the `Space` key on the keyboard or pressing the  button (do so once for *Preview* and a second time for *Recording*). To pause recording, either click *Pause* in the *Scan* panel, press  on the scanner body or hit the `Space` key.

5.2 Selecting and Preparing Objects for Scanning

Artec 3D scanners employ the structured-light method of 3D reconstruction. Since they capture 3D frames using optical technology, some types of objects are difficult to scan. Certain techniques, however, enable successful scanning of such objects. For example, you can cover a transparent or dark object with a light paint or dust it with talcum powder. You can also use other easily removable substances or a special anti-glare spray.

Table 1: Hard-to-scan Surfaces

Surface Features	Possible Solutions
Black or very dark	Dust with anti-glare spray
Shiny or reflective objects	Dust with anti-glare spray, tilt scanner when capturing
Transparent (glass, certain kinds of plastic, etc.)	Dust with anti-glare spray
Thin edges	Add background geometry (e.g., crumpled paper)

5.3 Technique

Artec 3D scanners capture objects at a rate of 15 frames per second to ensure that adjacent frame areas overlap as you gradually move the scanner. Artec Studio uses features in overlapping areas to automatically align captured frames. It performs this task in real time, providing immediate access to the frames in a single coordinate system. You can evaluate the captured area after the scanning session to determine which parts of the object require additional scanning.

To accurately capture an object or scene, follow these steps:

1. Pay closer attention to the object on the screen rather than looking at the actual object.
2. Ensure that Artec Studio can accurately register frames from the scanner. To this end, do the following:




Figure 28: Scanner orientation and reconstructed surfaces.




Figure 29: Distance meter and distance color showing surfaces that fall within the optimal range for Artec Spider.

- Don't move the scanner too fast
 - Keep the object as close to the center of the field of view as possible
 - Maintain the scanner orientation in such a way that the field of view is sufficiently filled with surfaces (see [Figure 28](#))
 - Try to position the scanner in the way the most surfaces in the field of view are colored in green which corresponds to the center of the range meter¹ ([Figure 29](#))
3. If you're capturing an object over several scans, remember to capture a common area in each one to ensure successful alignment
 4. If you're capturing an object in one scan, do so all the way around the object—regardless of direction—plus a little more (360+ degrees)
 5. Avoid capturing any objects that may change shape during the scanning process. When the geometry of the scene is changing, the system may fail to find the correct position of new frames relative to previously aligned ones. If you have captured unwanted objects, you must remove them later during the editing stage (see [Editing Scans](#)).
 6. Don't record too many frames: ensure that you have sufficiently scanned all regions, but avoid scanning them twice, except when providing overlapping areas for subsequent alignment.


5.4 Scanning Procedure

Ins and Outs

- Artec Studio creates a new scan in the *Workspace* panel at the beginning of each session.
- When you start *Preview* mode, Artec Studio will hide all uploaded scans. This mode helps you to determine how well the 3D scanner sees the object, and it helps you to identify areas that may cause trouble during the scanning session. To begin the scanning process, click the *Record* button in the *Scan* panel or press the ► button on the device body.
- If your 3D scanner is equipped with a texture camera, Artec Studio will activate the scanner's texture flash and capture color images that it will later use to texture

¹ Technically, the center of the range meter is the center of the depth of view. The 3D scanner has near and far cutting planes (see [Figure 2](#)) that determine the optimum distance between the scanner and the target object. Artec Studio offers the *Range meter* feature so you can easily visualize the distance between the scanner and the object during the recording process. The *Range meter* comprises a set of semitransparent diagrams located on the left side of the *3D View* window (see [Figure 29](#)). Each histogram displays the distribution of captured surface points by distance from the scanner. The color corresponds to the set of surfaces from which it was obtained: by default, gray indicates registered key frames, dark green indicates the last successfully registered frame and red indicates a registration error.

the 3D model.

1. Prepare the object and make sure it has enough geometry and texture details (see *Selecting and Preparing Objects for Scanning*).
2. Provide even lighting without using direct sunlight.
3. If you have connected just one 3D scanner to the computer, Artec Studio will select it automatically; otherwise, you must select the appropriate device from the dropdown list under the *Advanced* section of the *Scan* panel.
4. Create a new project before getting started: use the  button in the *Workspace* panel, select *File* → *New project* from the menu, or use the shortcut `Ctrl + N`. Once you have saved the project, you will be able to load or unload the scans as necessary and thereby limit RAM usage (see *Projects, Scans and Models* for details).
5. Decide how many sessions you need in order to capture the entire object. By using a special third-party rotating table, you may be able to avoid interrupting the session and eliminate the need to turn the object by hand. Depending on your choice, you may
 - Turn the object
 - Position yourself to gain access to the other area
 - Use a rotating table
6. Click *Preview* or press **▶** on the scanner. Direct the scanner at the object and practice your movements around the object, taking into account the proper *Technique*.

Note: If you wish to use the *Enable automatic base removal* option, first direct the scanner at the surface that supports the object.

7. Click *Record* to start capturing.
8. Gradually move the scanner while monitoring the process in the *3D View* window
9. Capture what you can and pause or cease recording by clicking the *Pause* or *Stop* button, respectively. Choose *Stop* if you must make adjustments to the object's positioning (see the next step).
10. Turn the object or otherwise adjust it as necessary, then capture any remaining un-scanned regions.
11. Once you have successfully captured the object from all sides, click the *Stop* button or press **■** on the scanner body.

5.5 Tracking Modes

Ins and Outs

- Artec Studio still records texture in *Geometry* tracking mode if the scanner incorporates a texture camera
- Continuous scanning in the hybrid tracking mode is easier with the *Scan using auto-alignment* option.

The software provides three *tracking* modes and one option:

Geometry + Texture, or hybrid The optimal (and default) algorithm for 3D scanners equipped with a texture camera. It uses features from images obtained using the texture camera as well as geometrical features of the object and thus is more likely to successfully capture flat or textureless objects. The only possible drawback is greater CPU utilization compared with other algorithms, potentially decreasing the frame rate for less powerful computers. You can use this mode with Artec MHT, Artec EVA, Artec Spider and third-party 3D scanners.




Figure 30: Texture tracking renders color object (scanner's current field of view outlined in green).

Geometry The default algorithm for all 3D scanners that lack a texture camera (Artec EVA Lite). It uses only object geometry to align the scanned frames, making it suitable for objects that have a rich geometry but not objects with large flat, spherical or cylindrical parts. The Geometry tracking algorithm is the least CPU hungry.

Targets A special algorithm for scanning objects with special targets placed on their surfaces.

Real-time fusion (option) Available for both Artec 3D scanners and third-party 3D sensors, this option fuses the results immediately after scanning.

See also:




Figure 31: Main window when using Geometry tracking to scan objects.

Tweaking Scanning Options

5.5.1 Base Removal: Erasing a Supporting Surface

Ins and Outs

- Base removal is available for all tracking modes.
- If you click *Stop* or press **■**, you should again identify the supporting surface.
- If the scene remains unchanged, you can also use the *Auto-align new scans with those marked in Workspace* option. In this case, the application won't prompt you to identify the base.
- If base detection is successful, the base will always render in *Recording* mode.

When you capture an object, you can often omit from the scan any surface that supports the object. The *Base removal* option serves this purpose. To employ this option, first indicate the surface on which the object is resting and then capture the object. If this approach is unsuitable for your situation, clear the *Enable automatic base removal* checkbox.

1. Open the *Scan* panel.
2. Make sure the *Enable automatic base removal* checkbox is selected.
3. Click *Preview* and direct your scanner at the surface that supports object (e.g., a table or the floor). A gray wireframe plane will appear, indicating the scene's base.

4. Once the application detects the base, it will display a message: “Now scan the object.”

Important: If Artec Studio fails to detect a supporting surface, you can still start recording.

5. Click *Record* (▶) and then direct the scanner at the object.
6. Scan the object freely. You can pause and resume the session as necessary.
7. Click *Stop*; all scans will move to the coordinate system with the Z axis normal to the base.
8. Close the *Scan* panel. The *Base removal* algorithm will remove the previously detected supporting surface. If not, *erase it manually*.




Figure 32: Scanning with the *Enable automatic base removal* option.

5.5.2 Resuming Scan After Lost Tracking

Artec Studio records adjacent frames on the basis of common surface features. If the scanner stops recognizing common features, it will stop capturing the scene. This situation

is called lost tracking; if it happens, just direct the scanner at a recently captured region. There are, however, nuances, which we address below.

Table 2 lists several causes of lost tracking. The most common is moving the scanner too fast.

Table 2: Causes of lost tracking.

Reason	Possible Solutions
Moving the scanner too fast	Move the scanner more slowly or increase the <i>Scanning speed</i>
Scanner sees too few surfaces	Apply an anti-glare spray or direct the scanner at a larger part of the object; increase <i>Sensitivity</i> of Artec Spider
Object doesn't have enough features for successful tracking	Apply masking tape or draw markers on the surrounding surfaces, and/or move the scanner more slowly




Figure 33: Alert message: tracking lost.

The *Scan using auto-alignment* option may ease the process of resuming tracking (this option is enabled by default in the application settings). Note the following:


- Artec Studio switches almost instantly from displaying *Tracking lost* mode (see [Figure 33](#)) to *Searching for position*, which appears on a green background.
- To continue scanning, direct the scanner at a region you've already captured.
 - Try to maintain the original scanner orientation toward this region

- You need not necessarily use the most recent one, but it should have sufficient texture features.
- If the application successfully resumes tracking, it will start recording in a newly created scan. This new scan will already be aligned with the previous one.

The *Scan Using Auto-Alignment* section describes system behavior when this option is disabled.

5.5.3 Auto-align new scans with those marked in Workspace

Auto-alignment is a great timesaver and may help simplify further processing. But for projects that involve scans using *Geometry + Texture tracking* and for which the actual scene is unchanged, you can continue scanning immediately:

1. Ensure that the *Scan using auto-alignment* option is turned *on* in *Settings* (see *Capture*).
2. Mark previously captured scans using the  icon in the *Workspace* panel.
3. Select *Geometry + Texture tracking* as well as the *Auto-align new scans with those marked in Workspace* checkbox in the *Scan* panel.
4. Click *Preview*, direct the scanner at a textured region you've already captured textured region—maintaining the original scanner orientation—and then click *Record*.
5. If tracking resumes successfully, Artec Studio will align the newly recorded scan with the selected ones.

5.5.4 Scanning With Real-Time Fusion

Real-time fusion is a special mode in which Artec Studio builds a 3D model in real time while you're scanning. It's the easiest and fastest way to obtain a model, but it cannot completely replace the normal workflow for processing raw scans after capturing them. Thus, we recommend avoiding *Real-time fusion* in the following cases:

- The scene is large and the amount of GPU memory is limited
- Objects have complicated shapes that cannot be captured in one scan session
- The object has small geometric details
- Extra-high accuracy is required

The *Real-time fusion* feature is available for each tracking method.

1. Open the *Scan* panel.
2. Select the required tracking mode.
3. Select the *Real-time fusion* checkbox².

² If you selected the *Targets* mode and cleared the *Disable hybrid tracking for .obc* checkbox (see the *Photogrammetry Settings* section), Artec Studio will clear the *Real-time fusion* checkbox because it doesn't





Figure 34: Real-time fusion model.

4. Click *Preview* and then *Record*. Observe the recommendations in *Scanning Procedure*.
5. Pause and resume the session as necessary.
6. When you stop scanning, the *Workspace* panel will add one or more raw scans named *Eva Scan1*, *Eva Scan2*, *Eva Scan3* and so on, as well as one model named *Eva Scan1-Fusion*. The number of these raw scans corresponds to how many times you pause and resume scanning (see *Figure 35*).

Figure 35: *Workspace* panel after using Real-time fusion.

You can access the *Settings* window and use the *Performance* tab to configure the following *Real-time fusion* settings (see *Real-Time Fusion Settings*):

Voxel size 3D resolution of the model (i.e., the size of the triangulation-grid step in millimeters). The smaller the value, the more geometric details you can detect and capture in 3D.

5.5.5 Target-Assisted Scanning

Generally, you don't need any special equipment to record using an Artec scanner. If the object has hard-to-scan regions, however, *targets* may be useful. In some cases, they can improve tracking and further registration.

support this combination of options.

5.5.5.1 Placing Targets

Whatever the method chosen, you should place at least non-coded *targets* on the object.

Attach non-coded targets (Figure 36) to the object using the following rules:

- Try to place them on flat elements
- Avoid uneven surfaces
- Avoid obstructing significant geometric elements



Figure 36: Non-coded targets placed on an object.

Note: You can specify the target size in the *Settings* dialog of Artec Studio, as *Photogrammetry Settings* describes. If you use non-coded targets from the *Scan Reference* kit, specify 5 mm for the inner diameter and 10 mm for the outer diameter. You should measure targets from other suppliers and specify both diameters in the appropriate fields of the *Settings* dialog.

Place coded targets if your choice is photogrammetry (*Using Photogrammetry Solution (Scan Reference)*).

1. Prepare the objects and surrounding scene. All objects must remain stationary during measurement and capture.
2. Place the cross (Figure 38) on the scene, ensuring that it rests firmly, and it is seen from most points of view. Also double check that all targets on the cross are clearly visible.
3. Place the coded targets on the object and the surroundings. Note that you should distribute them such that at least six to eight coded targets are visible in each image. Random placement is preferable; avoid symmetry and target alignment.



Figure 37: Coded targets.

5.5.5.2 Using Artec Scanners Only

You don't necessarily need a photogrammetry kit to benefit from targets placed on the object you're scanning; Artec 3D scanners can do all the work. This mode employs extra-hybrid (Geometry + Texture + Targets) tracking and doesn't require you to upload an OBC file.

1. Open the *Scan* panel in Artec Studio. Select *Targets* under *Features to track*.
2. Scan the object from all sides
3. Run *Global registration*

Note: As you scan (without having uploaded an OBC file), the application registers the target coordinates. You can then *save an OBC file* and use it in later scanning sessions. We strongly recommend running *Global registration* first, however.

5.5.5.3 Using Photogrammetry Solution (Scan Reference)

By using a combination of special reference *targets* and photogrammetric measurements, you can scan large areas in one session, improve the accuracy of captured surfaces and boost productivity by reducing postprocessing time. The only downside of this method is the preparation. After scanning, however, you need not align the scanned surfaces, so you can immediately proceed to *Fusion* (see the order of postprocessing steps in *3D Scanning at a Glance*).

This synergy of technologies is possible thanks to Artec 3D-scanner and photogrammetry solutions. Several third-party photogrammetry offerings are available on the market. *Scan Reference* photogrammetry is one example. The *Scan Reference* kit includes hardware and software (see *Figure 38*), a digital camera, a reference-scale cross, non-coded sticky *targets* (which Artec Studio uses to match the captured 3D data to the photogrammetric measurements), and reusable magnetic coded targets (required to automatically carry out measurements in the *Scan Reference* software).

To perform scanning using targets, follow these steps:

1. Take several photos of the object from different angles. To determine the appropriate number of photos, angles and targets for each image, as well as required settings for a calibrated digital camera, consult the *Scan Reference* user manual and *FAQ article*. General recommendations are as follows:
 - a) Take photographs at a distance of 0.5–1.5 meters with enabled flash
 - b) Each photograph should contain as much targets as possible and each target should be captured at least in 10 photos
 - c) Entire cross should be captured in first 10–12 photographs
 - d) Capture the object from all sides
1. Move the cross and the coded targets away from the scene.



Figure 38: *Scan Reference* kit

The kit includes (from left to right) coded targets (foreground), a digital camera, a scale cross, a roll of tape with non-coded targets and a carry case.

2. Connect the camera to a PC, then transfer and process the photos using the *Scan Reference* software. Once the calculations are complete, the software will display measurement results on the screen. These results can appear as a point table or a 3D model.
3. Save the point model in an *.obc file. This format is the software's default.
4. Open the *Scan* panel in Artec Studio. Select *Targets* under *Features to track*.
5. Click *Load targets from file* and specify the OBC file path.
6. Scan the object. When you finish, the software will align all scans.

Important: If you don't want the texture and geometry features to assist target scanning, select the *Disable hybrid tracking for .obc* checkbox (*Photogrammetry Settings*).

5.6 Using Certain Scanner Types

5.6.1 Notes on Scanning With Spider

Because Artec Spider has smaller field of view and provides higher accuracy in comparison with Artec EVA, scanning using it can pose difficulties. Consider the recommendations given in *Technique* and also the following:

- Opt for rotating table if possible
- Use a piece of paper with text on it as artificial texture
- Double check that objects don't change their shape and position
- Try tuning sensitivity in particular cases (see *Sensitivity*). Avoid extreme values.

We recommend using the Artec Spider scanner only after it reaches its normal operating temperature. As soon as you plug Artec Spider in or connect it to a PC, it starts warming up. If you open the *Scan* panel, you will see two lines that provide the device's current and optimal temperatures. Artec Spider will warm up faster when it's in *Preview* mode. The *Scan* panel also displays additional information about the time remaining until the scanner reaches its optimal temperature.

Note: Artec Spider can operate at temperatures beyond its optimal range, but the accuracy of captured surfaces may be lower.

5.6.2 Notes on Scanning With Third-Party 3D Sensors

Important: Support for third-party 3D sensors is only available in Artec Studio Ultimate 13 and older.

Third-party 3D sensors are not specifically designed to serve as 3D scanners. Because they are multipurpose devices made from inexpensive components, they can scan objects, but the texture and surface quality is far worse than that of professional Artec 3D scanners (see [Figure 39](#)).

When using third-party 3D sensors, bear in mind the following:

Providing good lighting is critical because none of the sensors offers built-in flash. Also, use of these devices precludes the ability to adjust the brightness of the texture you are scanning, so good lighting is crucial to obtaining a decent model. Avoid using too much illumination, and avoid using direct light or fluorescent lamps. Intel RealSense R200 is particularly sensitive to direct sunlight.

When using PrimeSense and Asus Xtion sensors, a special technique can help you capture surfaces with consistent brightness:

1. Click the *Preview* button
2. Direct the sensor at the object and hold it for 5 seconds while the sensor adjusts white balance and exposure
3. Click the *Record* button
4. Move the scanner slowly to capture the scene
5. While scanning, keep the sensor as close to the object as possible

Most third-party devices work in the Real-time fusion mode, except for *Kinect v2*. Moreover, this mode is default for Intel RealSense 3D sensors.




Figure 39: Object captured and processed
(Artec EVA scan on left and *PrimeSense* on right).

5.6.3 Notes on Scanning With MHT

The flash feature in an Artec MHT scanner has a very large but limited number of operation cycles, so ensure that you disable the scanner when it's not in use. Avoid leaving the Artec MHT on for a long time when using the maximum capture rate (15 frames per second). Artec Studio will automatically turn off the Artec MHT after five minutes of continuous operation. Normally the active mode/rest mode is 3 minutes of scanning and 7 minutes of rest; this mode is optimal and significantly increases the lifetime of the flash.

5.7 Tweaking Scanning Options

5.7.1 Disabling Distance Color

The *Show distance color* option ([Figure 29](#)) highlights the reconstructed surfaces in the field of view based on the working range of a particular scanner.

Red	Surfaces are too close to the object.
Orange, green	Corresponds to the middle of range. Green represents the optimal distance.
Blue	Surfaces are too far away from the scanner and about to disappear.
No color	Surface is not being recorded.

In some cases you may need to observe how well texture is being recorded. Disabling this feature would then help. Clear the *Show distance color* checkbox in the *Scan* panel to this end.

Click "Preview" to begin

Features to track

☒ Geometry + Texture
☐ Geometry
☐ Targets

☐ Real-time fusion
☐ Auto-align new scans with those marked in Workspace
☒ Enable automatic base removal
☒ Show distance color

Scanning speed

1 fps 16 fps

Advanced ▲

☐ Hide this panel during scanning

Depth of field

Near (mm): 400 600 800 1000

Far (mm):

Scan name: Start with:

☒ Add scanner type in prefix

Sensitivity

Sensitivity will be adjusted automatically

Texture brightness

Use

Artec Scanner [EV.30.05131500]

☐ Don't record texture
☐ Disable flash bulb

Delay before recording:

seconds

☐ Save scans directly to disk

Figure 40: Scan panel in Artec Studio.

5.7.2 Tuning Texture Brightness

Note: This option is available only for Artec 3D scanners equipped with texture cameras.

You can adjust the *Texture brightness* setting in *Preview* mode. Use the slider to increase or decrease the brightness of frames captured by the color camera (see [Figure 41](#)). Note that the texture brightness affects texture quality as well as tracking steadiness. Observe the recommendations in the [Table 3](#).

Table 3: Adjusting texture brightness.

Surface Color	Recommendation
Dark or black	Increase brightness
Light-colored or white	Decrease brightness




Figure 41: Color-camera brightness adjustment

The brightness is lower on the left and higher on the right (slider from *Scan* panel overlaid on image for clarity).

5.7.2.1 Preventing Overexposure

Artec Studio has error-proofing against overexposure. If the *Auto-adjust brightness* checkbox is selected and the specified value of *Texture brightness* causes texture to overexpose, the application will automatically decrease brightness to avoid damaging texture.

5.7.3 Sensitivity

You can tune the *Sensitivity* of Artec Spider scanner if the application fails to reconstruct particular surfaces. Increasing this setting enables the scanner to more easily capture black, reflective, translucent and fine objects (such as human hair). The higher the sensitivity, the noisier the recorded surfaces will be. Higher values may also reduce the scanning speed. For Eva and other Artec scanners, this setting is automatically adjusted.

5.7.4 Frequency for Capturing Texture Frames

Specify the frequency for capturing texture frames by using the corresponding spinner in the *Settings* dialog (see *Texture-Recording Mode* and [Figure 126](#)).

5.7.5 Deactivating Scanner Flash

If circumstances prohibit you from using the scanner flash, follow the directions below.



Figure 42: Influence of ambient light on captured results.

On left: flash is turned off; ambient light is poor; results—dark texture. On right: flash is turned off; lighting conditions are improved; results—good texture.

Note that if you disable the flash, you should compensate by using bright ambient light. According to our tests, acceptable texture quality is obtainable with the flash disabled if the surface illuminance is at least 1 000 lux. Compare the models shown in [Figure 42](#), which were recorded under different lighting conditions.

The following procedure captures the textured model without using the scanner flash:

1. Open the *Scan* panel and click the *Advanced* link
2. Turn off the texture flash by selecting the *Disable flash bulb* checkbox
3. Use good illumination. Avoid fluorescent lamps.
4. Click *Preview* and direct the scanner at the object
5. Adjust *Texture brightness* and *Texture exposure time*. In most circumstances, values should be as low as possible, because increasing the brightness also increases a texture noise, whereas increasing exposure time can blur the texture. Instead of adjusting sliders, try to further improve the lighting conditions.
6. Capture the scene

7. Perform required postprocessing as described in *Data Processing* to get a textured model
8. Adjust texture parameters for this model as described in *Texture Adjustment*. Pay particular attention to the *Hue* and *Saturation* sliders. The *Hue* slider allows you to correct unwanted texture color.

5.7.6 Tuning Exposure Time

You can alter texture exposure time in the *Preview* mode. Adjust this parameter in tandem with the *Texture brightness*. Increasing exposure time can blur the texture. Don't alter the default value unless it's necessary.

5.7.7 Disabling Texture Recording

Clear *Don't record texture* checkbox if you don't want to store texture information in your scans. It is located in the *Advanced* section of the panel and disengages both texture camera and texture flash in the scanner. Note that this option is unavailable for Artec EVA Lite. Don't forget to select this checkbox once you have completed textureless scanning; otherwise, next time you want to start regular scanning the hybrid tracking mode could be unavailable.

Important: Just using the *Geometry* tracking mode it is still not sufficient for the application to don't record texture. Make sure you clear the eponymous checkbox.

5.7.8 Decreasing Scanning Speed

Artec EVA captures objects at up to 15 frames per second, whereas Artec Spider at 7.5. Default values ensure comfortable scanning with smooth movements. However, if you find scanning speed inappropriate, you can decrease it. In this case, Artec Studio will record fewer identical frames and register them faster. To this end, use the *Scanning speed* slider in the *Scan* panel.

Important: Decreasing scanning speed may hinder scanning. Don't use this slider unless it is absolutely necessary.

5.7.9 Supplementary Settings

Customize scan names and starting number by entering your own values in the *Scan name* and *Start with* fields and changing the state of the *Add scanner type in prefix* checkbox. The software uses these values to create a scan title in the *Workspace*

panel (see [Figure 43](#), left). You can change the default values *Eva Scan* and *1* to, for example, *Capture* and *14*.

Set saving scan data to disk Trigger a capture mode that simultaneously records scanning results to a disk by selecting the *Save scans directly to disk* checkbox. This option is enabled when you're working with an existing saved project (see [Saving a Project](#)) and can be useful when capturing large amounts of data on a computer with insufficient memory.

Specify a delay (in seconds) before recording using the *Delay before recording* spinner under the *Advanced* section of the *Scan* panel. The countdown begins as soon as you click the *Record* button. To eliminate the delay, set the value to zero.

Decrease specified operating-zone (*Depth of field*) by using the *Near (mm)* and *Far (mm)* sliders under the *Advanced* section of the *Scan* panel. Here you can only decrease range within the specified boundaries.

Specify the operating-zone boundaries (in millimeters) By default, Artec Studio provides the correct values for the minimum and maximum limits within which the cutoff planes are to be positioned. These values are different for each 3D scanner model, and they ensure that you capture good-quality 3D data. If high accuracy is a secondary concern, you can manually adjust the depth boundaries, allowing you to capture objects using an Artec L scanner or third-party 3D sensors positioned closer to or further from the object than is recommended. To do so, select the *Override default depth range* checkbox in the *Settings* dialog in the *Scan* tab, then specify new boundaries for the scanning range (For more details about scan settings, see [Capture](#)).

Warning: Custom depth-range settings may reduce accuracy.

Configure hiding *Scan* panel during scanning To widen the viewport during scanning, software automatically closes the *Scan* panel once you start recording using Artec EVA or Artec Spider scanners. The *Hide this panel during scanning* checkbox is located in the *Advanced* section and is cleared by default.

5.8 Troubleshooting

Issue	Possible Resolution
<i>Geometry + Texture</i> radio button missing from <i>Scan</i> panel.	You were probably scanning without texture. Clear the <i>Don't record texture</i> checkbox in the <i>Advanced</i> section.
Final model contains noticeable noise.	You likely scanned the affected areas improperly, or the scanner was too far from the object. Rescan those areas.
<i>Tracking lost</i> error persists.	Make sure <i>Scan using auto-alignment</i> is enabled in the <i>Settings</i> dialog and use <i>Geometry + Texture tracking</i> .


CHAPTER 6

First Steps

6.1 Getting Started With Artec Studio

6.1.1 Windows, Panels and Bars

When you launch Artec Studio, you will see the main application window, which allows you to perform all operations on scans and models.




The main window is divided into several sections:

1. *3D View*
2. *Navigation cube*
3. *3D toolbar*
4. *Workspace* panel
5. *Log window*
6. Left panel (figure depicts optionally open panel *Tools*)
7. Left toolbar
8. Not marked in the figure: menu bar (top) and status bar (bottom).

The *3D View* window displays all 3D data. You will use this window regularly. When the application launches, a coordinate grid with coordinate axes will appear in the center. Your scans and models will employ this global coordinate system.

To the left of the *3D View* window is the left toolbar that contains icons for various application modes, including *Scan*, *Autopilot*, *Editor*, *Tools*, *Align*, *Fix holes*, *Measures*, *Multi*, *Texture* and *Publish*. These modes are mutually exclusive: the application can work only in one of them at any given time, except for *Autopilot*. Some modes will lock the *Workspace* panel when you use them.

To the right of the *3D View* window is the navigation cube and the *3D toolbar* containing the following commands: *Fit to view*, *Grid*, *Lighting*, *Color*, *Render mode* and *Backface*.

The *Workspace* panel displays and manages all data uploaded to the application. Here you will find your scans as well as project-manipulation commands, such as saving, erasing, moving and renaming. You can reveal the hidden *Workspace* panel by clicking  at the top right of the *3D View* window.

The *Log* panel sits at the bottom of the application window. The log is the software's report on any executed commands, specifying the time and details of each operation. It also stores all error and troubleshooting messages generated by the algorithms.

The status bar contains information on memory availability and current usage by Artec Studio. It also has a progress indicator for any currently running task, such as algorithm execution, model and scan exporting, and so on.

6.1.2 Primary Settings

To access the settings dialog, select *Settings...* in the *File* menu. The settings window has several tabs for various groups of application settings. To switch between the tabs, click the icon at the top of the dialog. For a detailed description of the tabs, see [Settings](#).

To change the language, select the *Miscellaneous* tab ([Figure 130](#)) and then the required language from the list and click *OK*. You will be asked to confirm the operation and restart the application. Once you agree, Artec Studio will automatically restart using the new interface language. If you choose not to restart, the changes will be applied the next time you start the application.

Under the *Performance* tab you can specify the maximum number of alterations to be saved, or specify maximum the size (in MB) of the history to be saved. The *Data-compression level* slider enables you to adjust the compression level when saving project data to a disk.

6.2 Object Types

After each scanning iteration, Artec Studio saves a separate *scan*. The list of all scans for a given project appears in the *Workspace* panel (see [Figure 43](#)). Afterwards, the algorithms, primarily *Creating Models (Fusion)*, yield *models*.

Artec Studio can accommodate the following types of objects in *Workspace*:






Table 4: Object types in Artec Studio.

Type	Content	Origin	Example Name
Scan	Set of frames	From scanners Eva, Spider, Leo and Micro	Eva Scan 1
Point-cloud scan	Point-cloud	From Ray scanner	Ray Scan 1
Model	Polygonal mesh	Algorithm output or imported mesh	Sharp fusion 1






6.3 Workspace Columns

Data in the *Workspace* panel is arranged in several columns:

6.3.1 Scan list





	Scans marked with  in this column will appear in the <i>3D View</i> window and will undergo processing by all Artec Studio algorithms and tools.
	Algorithms won't reposition frames of the locked scans (marked with )
<i>Title</i>	When a scan is created, Artec Studio automatically assigns it a name, such as <i>Eva Scan 1</i> , <i>Eva Scan 2</i> and so on, according to the values in the <i>Scan name</i> and <i>Start with</i> fields as well as the state of the <i>Add scanner type in prefix</i> checkbox in the <i>Scan</i> panel. To rename a scan, select it by left-clicking on its name. Then either hit F2 or right-click on the scan name to open the dropdown menu. Select the <i>Rename...</i> option. Both approaches open a dialog that allows you to specify the new name.
<i>Frames</i>	The number of frames loaded into memory along with the total number of frames constituting the scan (see <i>Selectively Loading Project Data</i>)
<i>Size</i>	The size of a particular scan (in MB).
<i>Err.</i>	The largest registration-error value among all frames in the scan. <i>More information.</i>
<i>Color</i>	In this column, each scan has a colored square  next to it. The square's fill depends on the number of scan frames loaded into the application. When all frames are loaded, the square will be completely filled in. When only key frames are loaded, it will be half filled, and when all the scan data is unloaded, it will be unfilled (see <i>Selectively Loading Project Data</i>). You can change the scan color by clicking on the corresponding square and selecting the desired color from the palette.

6.4 Workspace Toolbar Commands

Toolbar located at the top of the *Workspace* panel duplicates commands from the menu bar and helps to quickly create , open  or save  project, undo  operations of the command history, access *Settings* .

You can also access project statistics. Call a context menu (RMB) of any object in *Workspace* and select the *Project info* command.

6.5 Selecting Scans and Models

To view a scan or model in the *3D View* window or to *process* it, you need to mark it with the  icon in the *Workspace* panel. To navigate scans and models, use keys **↑** and **↓** or click an arbitrary area except those in ,  or color column ().




Figure 43: *Workspace* panel: scan list (original view) on left and surface list on right.

Purpose	Method	Alternate Method
Highlight scan in <i>Workspace</i>	Left-click on the scan name	—
Toggle visibility and availability for processing (👁️ flag)	Left-click in the leftmost column	Hit Space on the highlighted scan or select scan name using Shift+Alt+LMB
Batch selection (deselection) of scans for display and processing	Click	Hit Ctrl+A (Ctrl+D)
Select a single scan for processing and deselect others	Select the scan name using Ctrl+Alt+LMB	Use Ctrl+LMB in the empty area of the leftmost column



In addition to the methods in the table above, you can use commands from the dropdown menu of the button. See also the full list of hot keys in *Workspace*.



6.5.1 Selecting Frames

Double-clicking the scan name opens the *Surface List* panel, revealing all frames in that scan (see Figure 43, right).

Highlighting specific frames will make them (and only them) appear in the *3D View* window. When the *Show other selected scans* option at the bottom of the panel is checked, the selected frames from other scans will also appear in the *3D View* window.

You can select frames in a number of ways:

- Click **LMB** on the frame name to select it while clearing other selections.
- Click **LMB** while holding the **Ctrl** key to select several frames at once.
- Click **LMB** while holding the **Shift** key to select a sequence of frames in the specified range.
- Click the  icon in the *Surface list* panel to select all frames or to clear the selection.
- Use the dropdown menu for  to quickly select all key frames or all textured frames.
- Click **Ctrl + A** to select all frames.

To start a sequential frame demonstration, use the *Play* command of the scan context menu,  button in the *Surface list* or **Ctrl + P** shortcut. To stop the demonstration, select *Stop playback* from the scan menu, click  or hit **Ctrl + P** again.

6.5.2 Selecting Models

Double-clicking the model that contains no frames will bring a panel with its properties (see [Figure 44](#)).




Figure 44: Model properties.

6.5.3 Selecting Point-Cloud Scans

Point-cloud scans contain only one surface. To access scan summary list, double click its name in the *Workspace*. It includes the following data:

- Polygon and vertex count. Since Artec Studio doesn't display all the points constituting the scan, you can only see a mesh obtained from a simplified copy of the actual point cloud.
- *Points in point cloud* Total number of points.
- *Sections in point cloud*. When you scan with Ray, you may select particular regions (sections) to narrow down the actual scene. This parameter stands for the number of these regions.

Context menu for a point-cloud scan has the *Go to scanner viewpoint* command that moves camera to the exact position where Ray captured this scan.

6.6 Memory Management and History

6.6.1 Selectively Loading Project Data

When working with a large data set, you may often find it necessary to free up RAM without deleting any of the project data. To this end, Artec Studio implements a mechanism for selectively loading scans. You can move to disk any currently unused scans to free up extra RAM. If a particular algorithm later requires any of the unloaded scans, the application will automatically reload them. Frames that are not currently loaded into the memory won't show in the *3D View* window.

Any scans or frames that are completely unloaded from memory will appear in a gray italicized font in the *Workspace* window (see [Figure 45](#)).








Figure 45: Selectively unloading scans.


Note: Before you can change a scan's loading status, you must save the project.

To change the loading status, select the scans in the *Workspace* window (using the `Ctrl` key), click `RMB` and then select one of the scan-loading options in the pop-up menu (see [Figure 45](#)):

Table 5: Workspace menu commands and corresponding icons.

Menu Command	Function	Resulting Icon Appearance
<i>Unload scans</i>	Fully unload scans from memory	
<i>Load key frames only</i>	Only load key frames into memory	
<i>Load scans</i>	Fully load scans into memory	
<i>Load textures</i>	Fully load texture images into memory	—
<i>Unload textures</i>	Fully unload textures from memory	—
—	Scan loaded partially (some frames not loaded)	

Algorithms may automatically change the loading status of project data in the following cases:

- You have selected unloaded scans for processing by clicking the  button. Artec Studio will load these scans into memory.
- Execution of the algorithm requires large amounts of memory. Artec Studio will unload unused scans, frames, textures or a combination thereof.
- Algorithm needs certain frames and it loads only them.

Note: In addition to 3D data, the change history can also consume a large portion of memory. For information on how to control the history size as well as how to unload or clear it, consult [History of Project Changes](#).

Viewing Scans and Models

7.1 3D Navigation

When you have finished scanning, Artec Studio displays the results in the *3D View* window.

7.1.1 Moving, Rotating and Scaling

You can control the observer's perspective in the *3D View* window by moving or rotating the observation point, or by zooming in or out. Use the mouse to control these effects.

Tip: You can also use 3D mouse to navigate 3D content (see *3D Mouse*).

7.1.1.1 Moving

Move the mouse pointer over the *3D View* window. Hold down the left (LMB) and right (RMB) mouse buttons simultaneously, then move the mouse to relocate the model. You can also use the middle mouse button to perform the same operation.

7.1.1.2 Rotating

To rotate around any possible axis, move the mouse pointer over the *3D View* window. While holding down LMB, move the mouse in the desired direction to rotate the model.

7.1.1.3 Flipping

To quickly rotate (flip) 3D data around a specific axis (or rather the axis perpendicular to the screen plane) in a specific direction, use the dedicated arc arrows (↶↷) near the navigation cube (see Figure 49) or the **O** key:

Using arrows

1. Click (**LMB**) one of the arrows (↶↷)
2. Still holding down **LMB**, move the mouse cursor in the direction of either of the arrows.

Using the **O** key

Press and hold the **O** key and drag the mouse cursor outside an imaginary ellipse that inscribes the **3D View** window.




Figure 46: Imaginary ellipse inscribing the **3D View** window.

7.1.1.4 Scaling

Hold **RMB** and move the mouse. Moving left or up will zoom out, whereas moving right or down will zoom in. You can also use the mouse wheel to produce the same effect.

7.1.2 Global Coordinate System and Rotation Center

To enable or disable the global coordinate-system axes, select the *Show grid* option in the *View* menu or *Grid* in the *3D View* toolbar, or press *G*.




Figure 47: Custom rotation center.

When you rotate the model, the scene always turns around a certain point—the rotation center. By default, the rotation center coincides with the origin of the main axis grid. To change its location, double-click **LMB** at any point on the 3D model: the rotation center will move to this point. Setting the rotation center can be useful when you wish to view a particular object from all sides. Once it is set, rotate the view using **LMB**.

Artec Studio displays the rotation center as a small purple sphere with the three small coordinate axes (see [Figure 47](#)). If the rotation center coincides with the origin of the main axis grid, the purple sphere lacks small axes. If the rotation center hasn't been altered, it even lacks the sphere.

Application can set the rotation center to the center of mass of the object. Access the following menu command: *Edit* → *Cursor* → *Set to mass center*. To go back to the default state, select *Set to origin of axis grid*.

7.2 Choosing Projections

The *View* menu allows you to choose between perspective and orthogonal projections when displaying the model in the *3D View* window.

Perspective view is the central projection on a plane produced by direct rays that focus on one point: the projection center. This method produces a visual effect similar to human eyesight.

Orthogonal view is when the projection center resides infinitely far from the plane of projection; in this case, the projection rays are perpendicular to the observation plane. This method preserves parallel lines and is more commonly used for measurement (see *Measurement Tools* for details).

You can also change projection type in other ways:

- Hit `Ctrl + 5` on the main keyboard
- Hit `5` on the extended numeric keypad (numpad)

7.3 Viewpoints

To quickly toggle a camera view between several predefined positions, use navigation cube, *View* menu or the keyboard combinations listed in [Table 6](#).

In comparison with the other ways, navigation cube provides more flexibility in orienting objects in the window. Apart from using labeled faces (*TOP*, *FRONT*, *LEFT*, etc.), cube allows one to orient scene to intermediate positions with the help of controls located on the edges and vertices (see [Figure 48](#)).




Figure 48: Navigation-cube controls (face, edge, vertex).

Table 6: Key combinations for switching viewpoints.

Viewpoint	Keyboard	Extended Numpad
Front	Ctrl + Shift + 1	1
Back	Ctrl + 1	Ctrl + 1
Right	Ctrl + Shift + 3	3
Left	Ctrl + 3	Ctrl + 3
Top	Ctrl + Shift + 7	7
Bottom	Ctrl + 7	Ctrl + 7





Figure 49: Navigation cube and arc arrows.


The *Home* command of the *View* menu or **H** keystroke restores the view to its original position.

The *Fit to view* menu option,  button or **F** keystroke automatically fits the object to the *3D View* window.

For point-clouds, you can have a look at scan from the Ray perspective. Open the right-click menu for this scan and select the *Go to scanner viewpoint* command to this end.

7.4 Displaying 3D Data

The toolbar on the right of the *3D View* window features controls for data-display modes.

If minimized, it can be opened by clicking button  in the *3D View* window (see [Figure 49](#)). All the commands for viewing and switching between modes are also available in the *View* menu.

7.4.1 Rendering and Shading Modes

Both the *View* menu and the *3D View* toolbar allow you to choose one of the following 3D rendering options for scanned frames:

Render solid the most common way to render with a solid fill on all faces using your selected shading method

Render wireframe display polygonal-mesh edges without applying a solid fill to the faces

Render points display polygonal-mesh vertices

Render wireframe over solid apply a solid fill to the faces and use a different color to display edges. This method enables you to visually assess the quality of the polygonal model (see [Mesh Simplification](#) for details).

Render points and solid automatically display scans in point view, but display models in solid-fill view. This mode eliminates the need to switch to another mode in order to find the best rendering approach for each surface type. It is enabled by default for the Artec Spider scanner.




Figure 50: Examples of model using different rendering modes.
Point model on left and wire over solid on right.

For some examples of the various model-rendering modes, see [Figure 50](#).




Figure 51: Smooth versus flat shading (respectively).

To choose a shading method for the solid fill, use the *View* menu:






Smooth shading the color value for each point in a triangular face is calculated using color interpolation at the vertices

Flat shading all the points on a triangular face are assigned the same color

7.4.2 Lighting, Color and Texture

The *Lighting* option in the *View* menu or in the toolbar, or \perp hot key toggles the lighting in the *3D View* window. This option may be useful when you must turn the lighting off to see only the outline of the model or to assess texture quality.

The *Color* subgroup in the *View* menu or *Color mode* section in the toolbar list the methods for assigning colors to the surfaces in the *3D View* window:

<i>Texture</i>	displays textured data; otherwise, the software uses the scan's default color		Ctrl+Alt+1
<i>Scan color</i>	displays the default color of the scan; the figure depicts two scans		Ctrl+Alt+2
<i>Surface color</i>	displays each frame in a scan using a different color		Ctrl+Alt+3
<i>Max error</i>	colors the frames from Eva and Spider in accordance with their <i>registration quality</i> from green to red via yellow and orange; red indicates unacceptable values and registration errors		Ctrl+Alt+4
<i>X-ray</i>	beneficial for noisy data since it highlights only areas with high point density; it features a slider for adjusting its intensity		Ctrl+Alt+5

7.4.3 Back-Face Rendering

Artec Studio offers three methods for rendering a frame's back face:

Show assigns the back face the same color as the model

Cull the back face is not displayed

Black renders the back face in black

You can choose the mode from the *View* menu or from the toolbar in *3D View* window. See [Figure 52](#) for examples that illustrate the different methods of back-face rendering. *Black* is the default mode.



Figure 52: Examples of different methods for back-face rendering.
Show back-face mode on the left, hide (*Cull*) in the middle and *Black* on the right.

7.4.4 Representation of Normals and Boundaries

The *Show normals* option in the *View* menu enables or disables rendering of normals for each vertex. By default, the normals point away from the model surface and toward the 3D scanner. You can change this direction using the *Invert normals* command. You can also switch between modes for displaying normals by hitting the **N** key with the *3D View* window active.

When working with edges, the *Show boundary* feature in the *View* menu allows you to enable and disable highlighting of the model's edges. To toggle this feature, hit the **B** key with the *3D View* window active.




7.4.5 Rendering and Texturing Untextured Polygons

Textured models may have some untextured areas (for instance, the green area in the middle of [Table 7](#)). The *Render polygons without texture* option in the *View* menu allows you to toggle rendering of such areas.

If the texture of the imported model is smaller than the model itself, Artec Studio can wrap it to fill the untextured areas (see [Table 7](#)). The wrapping effect is similar to floor tiling

or a repeating wallpaper pattern—that is, the texture repeats periodically. To activate this option, enable the *Wrap texture coordinates* option in the *View* menu.

Table 7: Rendering and texturing untextured polygons.

Options Enabled	Result
None	
<i>Render polygons without texture</i>	
<i>Wrap texture coordinates</i>	

7.4.6 Displaying Boundaries of Texture Atlas

Textures applied to 3D models are obviously two-dimensional. You may, however, want to see the boundaries of each texture patch on the actual 3D surface. Artec Studio can display a texture-atlas file, such as the the middle image in [Figure 96](#), with its boundaries highlighted (see [Figure 53](#)). Identifying the way in which the boundaries lie on the surface may, for example, help you determine whether you must simplify the model to get better texture application.

To enable boundary display, access the *View* menu and select *Show texture boundaries* or hit the **Shift+B** keys with the *3D View* window active. To disable this feature, make sure this menu command is unchecked.

Technically, this command also works for textures produced by triangle methods, but it provides no usable information.



Figure 53: 3D model with texture-atlas boundaries.

7.5 Saving Screenshots

You can capture surfaces displayed in the *3D View* window and save them in a graphics file. Unlike the conventional system `Print Screen` command, this option saves only the contents of the *3D View* window and uses the specified background color (see *Background for screenshots* transparent, black or white).

Tip: When saving screenshots in *X-ray* mode, avoid using transparent background.

To capture a screenshot, follow this procedure:


1. Select the *Save screenshot...* option in the *View* menu, or hit `Shift+Ctrl+S`.
2. In the dialog, specify the destination folder and file name, then click the *Save* button. Artec Studio will save the file in `PNG` format.

Note: If you save a screenshot using an existing file name, Artec Studio will overwrite that file without warning. Be sure to specify a unique file name to avoid overwriting other files.

CHAPTER 8

Projects, Scans and Models


A project encompasses all 3D data obtained by scanning and postprocessing that can be saved to disk and accessed for later use. In addition, it contains *command history* and *measurement* results. For each project, a corresponding folder contains all project data as well as a project file describing the structure of that data.


Artec Studio can display project statistics. It includes information on number of scans, surfaces (frames), polygons, vertices and UV coordinates. To access this data, call a right-click menu for any *Workspace* object and select *Project info*. If you want to collate data on the selected scans with the total numbers for the project, first mark the required scans using with the  flag.

8.1 Creating a Project

To start a new project, select the *File* → *New project* menu option. It is a best practice to *save this project* to a specific folder before you start scanning. If you start scanning with the *Save scans directly to disk* option enabled or import scans from Ray, a temporary project is created in the Windows temporary folder or another directory if you specified one in *Settings*.

8.2 Saving a Project


You can save your project using the *File* → *Save project* menu option, by clicking  at the top of the *Workspace* panel or by hitting `Ctrl + S`.

While you're working with a saved project, the header of *Workspace* panel displays its name and the application window its full path. Save project  from time to time in the course


of processing or otherwise using the scanned material.

Note: Artec Studio saves data incrementally, meaning that if you save an existing project, the application will only save newly changed or added data.

8.3 Opening Project and Scans

To open an existing project, use the *File* → *Open project* menu option, click  at the top of the *Workspace* panel or hit `Ctrl + O`.

Note: Files from Artec Studio versions 8, 9, 10 and 11 are mutually compatible. Earlier versions, however, may be unable to open projects saved in a later version using the `SPROJ` format.

By default, when you open a project, the application will restore it to the state in which it was last saved (the three scan-loading states include loaded, unloaded and key frames only—see *Selectively Loading Project Data*). To load faster by opening the project without loading any scans, use the *Open project (scans not loaded)* dropdown menu option under the  button. Alternatively, use the same option from the *File* menu or hit `Ctrl + Shift + O`.

Note: When Artec Studio opens a project, it will determine the amount of available memory. If the scan you are trying to load requires more memory than is available in your system, the application will process it as an “unloaded” scan.

8.3.1 Opening a Project from Leo

You can obtain projects from Leo via direct connection to the scanner or using an SD card installed in the device.

8.3.1.1 Connecting to Leo

1. Ensure that your Leo scanner and your computer are connected to the same network and you authenticated using the same credentials
2. Click *File* → *Import* → *Leo project (connect to scanner)*
3. Select the required device from the list and click *Connect*¹

¹ If Artec Studio doesn't list your Leo, try connecting to the device by manually specifying the IP address. Click *Connect by IP* to this end.

4. Then using either **LKM** or **↑** and **↓** select the project that you want to load (Figure 54)
5. Click *Import*. Wait for scans and real-time fusion models (RTF) to appear in the *Workspace* panel. If the scans contain information on *supporting surface* and the *corresponding option* is enabled in *Settings*, application will also launch base removal.




Figure 54: Dialog for selecting Leo projects to import.

8.3.1.2 Using SD Card

If you want to open Leo scans without having to connect to the device, use the following method:


1. On Leo, first copy a project to SD card.
2. Then insert the card into the computer with installed Artec Studio.
3. Click *File* → *Import* → *Leo project*
4. Browse for the required project folder
5. Select the folder containing Leo project and click *Select folder*. Import will start.

8.4 Importing Models and Scans

Importing is another way to load data into Artec Studio in place of capturing or opening a project. You can import scan files created in earlier versions of the software, individual

frames, as well as point cloud data in the following formats:

SCAN	Artec 3D scan format
PLY	Stanford polygon file format
STL	Stereolithography file format
VRML	VRML file; actual extension is *.wrl
OBJ	Wavefront OBJ file format
PTX	Disney per-face texture mapping format
C3D	Artec Ray original point cloud
BTX	Artec Ray point cloud

To import a file, use the *File* → *Import* → *Scans, meshes or point clouds* menu option, **Ctrl** + **I** or the dropdown menu option for the  button. Next, select a file for importing. You can also drag and drop a file into the main Artec Studio window, or just double click on it.

Note: The import process runs in the background, so you can continue working with the scans you've already loaded. The progress indicator for the import operation will appear at the bottom of the main application window. To abort the operation, click *Cancel* in the bottom-right corner.




Figure 55: Dialog for selecting surfaces to correct.


Artec Studio will import frame files as individual single-frame scans. After importing each scan, the application calculates the *key frames* for any scan that contains more than one surface. Also, the application will check the surfaces for defects when the appropriate setting is enabled (see *Surface-Consistency Detection During Import*). If it finds defects, it will show a dialog with a list of defective surfaces once the import operation is complete. You can then choose which ones should be corrected (see *Figure 55*).

8.5 Exporting Models, Scans and Point Clouds

When you want to store data for future processing, the best approach is to save the project as an *SPROJ* file or to export the data to the *SCAN* format. Any Artec Studio version can



open the latter format. If you plan to use the data in other applications, however, you should save scans and individual frames in another format.

You may also need to perform one of the following tasks:

Export one or more scans	<i>File</i> → <i>Export</i> → <i>Scans</i>	Doing so will save all frames to folders with names that match the corresponding scan names. An exception is the <i>SCAN</i> format; in this case, Artec Studio not only stores the frame-by-frame scan structure, but it does so in a single file.
Export a single surface	<i>File</i> → <i>Export</i> → <i>Meshes</i>	It works for models. If you, however, marked several scans, models or frames using the  button, Artec Studio will suggest merging them.
Export Ray scans	<i>File</i> → <i>Export</i> → <i>Point clouds</i>	It works for point-cloud scans from Ray.

8.5.1 Exporting Scans

To export scans:

1. Mark any scans you want to export using the  button.
2. Select the *Export scans...* command in the dropdown menu option of  in the *Workspace* panel.
3. Click the ... button to open and specify the destination folder.
4. Select *Scan export format* using the eponymous dropdown list.
5. If the selected format supports textures, also specify the texture format.
6. Select the *Apply transformation* checkbox, or leave it cleared (for more information, consult [Understanding How Artec Studio Applies Transformations](#)).
7. Click *OK*.



ply	Stanford polygon file format
stl	Stereolithography file format
obj	Wavefront OBJ file format
wrl	VRML file; actual extension is *.wrl
x	Direct X file format
scan	Artec 3D scan format
plyVC	Stanford polygon file format with vertex colors, actual extension is *.ply
obc	OBC point-cloud file

Note: The export process for models and scans runs in the background, so the application will allow you to continue working with the scans. The progress indicator for the

export operation will appear at the bottom of the main application window. To abort the operation, click *Cancel* in the bottom-right corner.

8.5.2 Exporting Meshes (Models)

To export a mesh:

1. Mark one or more models using  or select frames in the scan by clicking on them while holding the `Ctrl` key.
2. Select the *Export meshes...* command in the dropdown menu of the  button in the *Workspace* panel.

Tip: *File* → *Export* → *Meshes* command and `Ctrl+Shift+E` hot key also work.

3. Specify the destination folder, enter the file name, and select the appropriate mesh format from the dropdown list².
4. Click *Save*.
5. If the model has texture and the format supports it, specify the *Texture export format* in the new dialog (see *Storing and Exporting Color Information*).
6. Click *Export*.

PLY	Stanford polygon file format (standard and with the support for vertex color)
STL	Stereolithography file format
VRML	VRML file (1.0 and 2.0); actual extension is *.wrl
OBJ	Wavefront OBJ file format
ASC	Point cloud 3D format
AOP	American Academy of Orthotists and Prosthetists file format
PTX	Walt Disney Ptex: mesh with per-face texture mapping
X	Direct X file format (binary and text)
XYZRGB	XYZRGB file format
E57	ASTM E57 3D file format

See also:


Model Placement

² If you type an extension in the file name field, application will use it rather than the selected mesh file format.

8.5.3 Exporting Point Clouds

You can export point-cloud scans obtained from Ray scanner to either of the following formats (respective units are given in the third column):

PTX	Leica Geosystems Cyclone Point Cloud. Important! Don't confuse with <i>Disney Ptex</i> .	Meter
XYZ	XYZRGB file format	Specified in <i>settings</i>
BTX	Artec Ray point cloud; various versions (v2, v3, v5, v6).	Micron

1. Mark one or more point-cloud scans using  flag in *Workspace*. Ensure that you have selected a point-cloud scan by double-clicking its name: the panel must show point-cloud properties.
2. Select *File* → *Export* → *Point clouds*.
3. Specify the destination folder and required format and click *Save*.

8.5.3.1 Merging Sections

When exporting to PTX, ensure the *Export point clouds to PTX with merged sections* checkbox is marked in the Artec Studio settings. This option merges all sections (selections made during scan with Ray scanner) so that third-party software products can open the exported file.

8.5.4 Understanding How Artec Studio Applies Transformations

Artec Studio offers two options for exporting surfaces:

1. Store surfaces using the scanner coordinates and create XF text files that contain the coordinates calculated during registration. To use this approach, clear the *Apply transformations* checkbox.
2. Store surfaces that are relocated to the positions calculated during registration. In this case, XF files contain no relevant data. To use this approach, select the *Apply transformations* checkbox.

8.5.4.1 Special Aspects of Scan Placement

In most cases when you're exporting a scan to a common 3D-graphics format, you should select the *Apply transformations* checkbox. By doing so, you instruct third-party applications to display surfaces in the same way that Artec Studio does: that is, with the origin at the center of mass. If for some reason you need to store a scan in the scanner's coordinate system—in other words, with surfaces located at a distance from the origin that is equal to scanner's operating range—clear the *Apply transformations* checkbox.

Technically, Artec Studio saves scans in the scanner's coordinate system, but it displays them in a user-friendly manner by placing the origin at the center of mass. The actual positions of surfaces calculated during registration are stored in text (`.XF`) files. Therefore, when you're importing files using Artec Studio, it makes no difference whether the checkbox was cleared when Artec Studio exported them. It does make a difference, however, for third-party applications that cannot read `.XF` files simultaneously with 3D geometry.

8.5.5 Storing and Exporting Color Information

You can transfer color information for 3D surfaces in three ways. The most common is through a texture using a separate bitmap file (see [Applying Texture \(Procedure\)](#)). Another option is to save color information in each vertex of a mesh. The third is to assign a small textured fragment to each polygon. The two latter methods produce no texture files.

Colors stored in a vertex are blended throughout the polygon. As a result, you should avoid oversimplifying the exported mesh; otherwise, colors blended over a large face may fail to render true texture information.



Table 8: Formats that support color-information transfer.

Texture stored as a bitmap	PLY, VRML (*.wrl), OBJ, X, e57
Model file contains separate texture for each face	PTX
Formats that support vertex color	plyVC, XYZRGB

When exporting texture as a bitmap image, you can select one of the following formats: PNG, BMP or JPG. PNG format provides the best quality for a given file size thanks to its lossless image compression. JPG is the most compact format.

8.5.6 Exporting Target Coordinates

If you scan while in the *Targets* tracking mode *using only Artec scanners*, you can save an OBC file containing the target coordinates. Once you finish scanning, run *Global registration*, then do the following:

1. Use the  button to mark any scans that you captured without having uploaded an OBC file.
2. Select the *Export scans...* command from the *File* menu, or select the corresponding dropdown menu option of  in the *Workspace* panel.
3. Click the ... button to open and specify the destination folder.
4. Select *obc* from the *Scan export format* dropdown list.
5. Click *OK*. The `targets.obc` file will appear in the folder you specified.

For more information on the OBC file structure, consult the [FAQ](#).

8.5.7 Exporting to Leios

Artec Studio enables you to export files to *Leios* by accessing the *File* menu if the *Leios* software is already installed on your computer.

1. Select a model in the *Workspace* panel
2. Open *File* → *Export to Leios*
3. Then, in *Leios*, select millimeters as the length unit for the imported files.





Figure 56: Model exported to *Leios*

8.5.8 Exporting to Geomagic Design X

Polygonal models created in Artec Studio are insufficient for most design needs. Geomagic Design X (formerly Rapidform XOR) is purpose built to create manufacturing-ready *CAD models* directly from meshes.

To export a model,

1. Make sure Geomagic Design X is installed on your computer
2. In the *Workspace* panel, mark one model using the  flag
3. Select the *Export to Design X* command from the *File* menu
4. Wait for the model in OBJ format to open in the reverse-engineering system.





Figure 57: Model exported to *Geomagic Design X*

8.5.9 Exporting to SolidWorks





Artec Studio allows you to export models to SolidWorks by using third-party plug-ins. It supports the following plug-ins:

- Geomagic for SolidWorks
- DeziGNWorks for SolidWorks

To export a model,

1. Make sure SolidWorks and either of the plug-ins are installed on your computer
2. In the *Workspace* panel, mark one model using the  flag
3. Select the *Export to SolidWorks* command from the *File* menu
4. Wait for the model to open in the CAD system.

8.6 History of Project Changes

Artec Studio stores all data changes and you can later undo most of them. To undo an operation, click the  button in the *Workspace* panel. To perform the previously undone operation, click . You can also use `Ctrl + Z` or `Ctrl + Y`. Use the dropdown menu of commands  or , respectively, to undo or redo several operations at once.

When you save a project, Artec Studio stores 3D data together with the history of changes. You can select the maximum length of the history in the settings window under the *Performance* tab (see [Command History](#)). In addition, the *Compact memory* button allows you to save the history of changes on a local drive and thus free up RAM. Also, the *Clear command history* button clears the change history, likewise freeing up RAM, and makes the undo operation for the most recent changes unavailable. To clear the history, you can use the *Edit* → *Clear history* menu option in the main window or hit `Ctrl + Alt + H`.

8.7 Autosaving a Project

A project can be saved by either the user or Artec Studio. The latter case is called autosaving. For temporary (i.e., unsaved) projects, autosaving is unavailable. The application autosaves a project in the following cases:

- Before running the texturing algorithm (see [Texturing](#))
- When scanning is complete and the *Save scans directly to disk* option is selected (see [Scanning Procedure](#))
- When unloading scans with unsaved changes (see [Selectively Loading Project Data](#))
- When the *Save project before starting algorithms* setting is selected (see [Autosave Options](#)):

- Before launching algorithms from the *Tools* panel
- Before and after running the Global registration algorithm (*Global Registration*)
- Before starting *Autopilot* (*Use Autopilot*).

CHAPTER 9

Data Processing

Once you have captured an object from all desired angles and created a sufficient number of scans, you can then build a 3D model. This chapter offers a detailed description of the process.

The process of creating the final model includes the following stages:

See also:

3D Scanning at a Glance.

- *Revising Scans* and *Editing Scans*
- *Scan Alignment*
- *Global Registration*
- *Creating Models (Fusion)*
- *Editing Models*
- *Texturing*

9.1 Maximum Error and Registration Quality

Err. is the parameter that reflects frame registration quality. For scans, it shows the maximum value among all the frames. The larger the value, the less accurate the alignment. Artec Studio displays noteworthy values only for scans that have passed *Fine registration*, *Align* and *Global registration*.

Table 9: Max error (Err.) values.

Scanner type	Err.	Recommendations
All	0–0.2	Good results
All	>10	Run <i>registration</i>
Spider	0–0.3	Acceptable unless high resolution is required
Spider	0.4–0.5	Acceptable for large objects
Spider	>0.6	Unacceptable
Eva	0.4–0.7	Acceptable for small objects
Eva	0.8–1.2	Acceptable for large objects and unacceptable for small ones
Eva	>1.2	Acceptable for large objects
–	<i>Warning!</i>	Check the frame list
–	<i>Failed</i>	Indicates unregistered frames

9.2 Revising Scans

As you begin building a 3D model, you may want to start by preprocessing your scans: separate misaligned areas (if any) into separate scans and cut out unwanted objects from the scene.

You may encounter the following problems:




Figure 58: Possible scan errors.

Bad geometry on the left, scan misalignment in the middle and hands captured in frames on the right.

- Misaligned frames (see [Figure 58](#), left)—may occur because of small size, an insufficient number of geometrical features on the object or an insufficient number of polygons in a frame.
- Misaligned parts (see [Figure 58](#), middle)—occurs when the real-time alignment algorithm incorrectly determines the position of the new frame relative to previous ones.
- Unwanted objects in the frame (see [Figure 58](#), right).

A visual inspection of the frames can be very helpful in determining problematic areas. To perform a visual inspection, select the scan and view all the frames that it contains by holding ↑ or ↓ on the keyboard. This technique can easily detect misaligned frames.

When viewing scans, application generally shows only *key frames* and textured frames. To display all the frames, select the *Show all frames* option in the *3D toolbar*.

See also:

Misalignment Detection.

9.2.1 Separating Scans

During the fine-alignment process, frames in certain scans may be misaligned. Sometimes it's possible to divide the problematic scan into several scans, where each part is registered fairly well. In this case, divide the scan. To move some of the frames into a new scan, use the following procedure:

1. Select in the *Surface List* panel the frames you want to move (see *Selecting Frames*).
2. Click RMB and select *Move to new scan* (Figure 43, right).

You can also fix alignment errors in another way: reset the current frame-transformation values and repeat the registration, making any appropriate changes to the settings. Select the desired scan in the *Workspace* panel, click on it using RMB and select *Reset transformations* from the dropdown menu. Doing so will reset the computed positions of individual frames in the scan. A dialog will then appear, prompting you to confirm the operation. To compute new positions, run the *Rough serial registration* and then *Fine registration* algorithms (see *Fine Registration*).

9.3 Alignment and Registration at a Glance

Registration and alignment tools perform similar tasks, however, they differ. Use the table below to get an insight into the details.

Table 10: Understanding registration and alignment modes.

Type	Purpose	Details
<i>Fine registration</i>	Adjusting frames' positions	Treat scans in <i>batch</i> separately. Starts once you leave <i>Scan</i> panel.
<i>Align</i>	Assembling scans	See also Table 11
<i>Global registration</i>	Optimizing frames within scans	Launch it for a pre-aligned batch of scans or for a single scan
<i>Rough registration</i>	Preliminary registration performed during scanning	No need to start it manually

9.4 Editing Scans

To edit scans, open *Editor* from the side panel and select the *Eraser* tool. You can also use *Positioning tool* or *Transformation tool* to orient the scanned data.





Figure 59: *Editor* panel.

9.4.1 Eliminating 3D-Noise (Outlier Removal)

During the scanning process, so-called outliers may appear in the scene. Outliers are small surfaces unconnected to the main surfaces. They require removal because they may spoil the model or produce unwanted fragments. Artec Studio provides two ways to remove outliers: erase them before fusion (preventive approach) or after fusion (“furthering” approach—see *Small-Object Filter*). We advise using the former approach because it decreases the possibility of improper fusion by preventing noisy features from attaching to the main surface.

This outlier-removal approach is based on a statistical algorithm that calculates for every surface point the mean distances between that point and a certain number of neighboring points, as well as the standard deviation of these distances. All points whose mean distances are greater than an interval defined by the global-distances mean and standard deviation are then classified as outliers and removed from the scene.

For better results, we recommend running global registration before starting the algorithm. If you begin *Outlier removal* before doing so, a dialog will appear prompting you to perform global registration.

In most cases, none of the parameters accessible through the  button requires adjustment. But if necessary, you can change the values of these parameters:

- *std_dev_mul_threshold* is a standard-deviation multiplier. We recommend choosing the value for this parameter according to the following guidelines:
 - 2 for noisier surfaces
 - 3 for less noisy surfaces





Figure 60: *Outlier removal*: before and after.



- *resolution* should be set equal to the resolution of the *Fusion* process that you expect to run later.

Click *Apply* to run *Outlier removal*.







9.4.2 Erasing Portions of Scans (Eraser)

Nearly always, the scanning process will capture unwanted elements, such as walls, the operator's hands, surfaces on which the object is located and other extraneous objects. This unwanted data can hinder postprocessing. To avoid this problem, we recommend eliminating these objects before processing. Eraser offers several options to quickly and easily remove unwanted elements from the scene (see *Selection Types*).

1. Open the *Editor* panel using the side toolbar.
2. Open the *Eraser* tool by clicking  or by hitting **E**.
3. Select one or more scans in the *Workspace* panel.
4. In the *Editor* panel, choose the required *selection type*.
5. Consult the *instructions* for a specific mode and select regions on the scans that you want to erase. To clear all selections, click *Deselect*.
6. Click *Erase* to eliminate the area highlighted in red or to apply cutting plane (*Cutoff-plane* or *Base* selections).

To undo changes, click  in the *Workspace* panel or menu *Edit*, or hit **Ctrl + Z**. Each click of the *Erase* button generates a command history entry. To undo several operations, use the dropdown menu of button  and select the lowest entry.

9.4.2.1 Selection Types

2D		Hold down Ctrl and use Scroll wheel to adjust the tool size. Paint with Ctrl+LMB to create a selection.
3D		See above.
Rectangular		Use Ctrl+LMB to select a rectangular region.
Lasso		Use Ctrl+LMB to freely outline an irregular region.
Cutoff-plane		Create selection as in 2D mode. Once you have released the mouse button, a plane will appear. If necessary, adjust the plane level by using Scroll wheel while holding down Ctrl+Shift or orient the plane freely in 3D space. To this end, hit Alt to display the <i>designated control</i> . Then still holding the key, drag the required control ring.
Base		Select a flat area as in 2D mode. The tool will automatically fit the base plane and select everything below it.

If the *Select through* checkbox is selected, all surfaces throughout the scan are affected. If not, the brush only works on the visible surface.

Use the following general procedure to erase unwanted elements:

See also:

Hot keys in Editor.

9.4.2.2 More Actions With Selections

Apart from erasure, you can perform the following action with the selected regions:

- **Clear selection** to create a new one. Click *Deselect* or reselect the region manually while holding down **Ctrl+Alt**.




Figure 61: *Select through* in *2D selection*: disabled in the middle, enabled on the right.

- **Invert selection** (clear the highlighted region and select the rest). It might be useful when working with large scans. Click *Inverse* or hit I .
- **Temporarily hide selection** if it obstructs the region you want to erase. Click *Hide* to this end. To display hidden polygons, click *Show*. Then select the region you want to erase.

9.4.2.3 Erasing Supporting Surface

Artec Studio offers two selection modes that differ from conventional brushes in the way how you select the area for erasure. First, you indicate the flat surface (table, floor or base) on which the object is resting. Then, application either determines the base plane and select the area underneath it (*Base selection*), or creates a cutting plane (*Cutoff-plane selection*) that divides the scan into two parts: the first will remain and the second will be erased (see Figure 64). You can orient this plane in any way you need.

Tip: Consider using the *Enable automatic base removal* option when scanning since it deletes the flat surface automatically after you close the *Scan* panel.




Figure 62: Various controls for orienting cutoff plane: around axes (X, Y and Z) and view direction.



Figure 63: Selecting a flat region in the *Cutoff-plane selection* mode.




Figure 64: Cutting plane






Figure 65: Erasing results

9.5 Fine Registration

Fine registration is an algorithm designed to precisely align captured frames.

In a number of cases you can start the Fine registration algorithm manually using the *Tools* panel. To access a list of parameters, click the  button in the *Fine registration* section. The algorithm affects all scans marked with the  icon in the *Workspace* panel (see *Selecting Scans and Models* for more information on scan selection), but it processes them separately.

registration_algorithm is a type of registration algorithm.

Geometry_and_Texture takes both texture and geometry into account. If the scan lacks texture information, the algorithm will run on geometry only.



Geometry uses geometry only. Unless your scan entirely lacks texture, we recommend avoiding this option.

9.6 Scan Alignment


Although Artec Studio features continuous scanning, there may be some cases where the application lack sufficient information about the relative positions of multiple scans. To assemble all scans into a single whole, you must convert the data to a single coordinate system—that is, you must perform alignment using the *Align* tool.

Hint: First refer to *Auto-Alignment* and take a glance at the *Summary of Alignment Modes* section as well.

9.6.1 Selecting Scans for Alignment

In the *Workspace* panel, use the  flag to mark all scans that you intend to work with. Once you click *Align* in the side panel; the marked scans will appear in the left panel already selected in the same order as they appear in the *Workspace* panel. During the *Align* operation, Artec Studio divides the selected scans into two sets: aligned (registered) scans and unaligned scans. The first set initially contains only one scan (the first one in the list), which is highlighted in blue. Its name appears in bold and uses the same color icon (). *Auto-Alignment*, however, may produce several groups of aligned scans.

The user's task is to align all scans to those that are already registered and to “assemble a model”. In general, the procedure includes the following steps:

1. Click the required tab in the *Align* panel.
2. Select one scan from the unregistered group in the *Align* panel. The name of unregistered scan appears in a regular typeface. When selected, the unregistered scan is marked by the green icon . You can select several scans using either of the following methods:

- Press and hold down the `Ctrl` key, and then click each scan that you want to select
 - Click the first item, press and hold down the `Shift` key, and then click the last item.
3. If necessary, specify point pairs (for two scans) or sets of points (for more than two scans)
 4. Click the desired alignment-command button (*Auto-Alignment* is the most recommended one). The command affects all scans selected in the *Align* panel plus the first one (●).

Since each mode varies in its effects, see the details in the corresponding subsections for more information. Note that you can use either one mode or a series of modes (see comparison table in *Summary of Alignment Modes*): drag alignment, rigid alignment with and without point specification, automatic rigid alignment, and alignment with surface deformations.

9.6.1.1 Changing Scan Status

If you have already aligned several scans, you should move them to the registered group. Select them in the *Align* panel using `LMB`. Next, click `RMB` on the name of any scan and select the *Mark as registered* option from the dropdown menu, or just double-click its name in the list. At this point, Artec Studio will treat registered scans as one, so you cannot move them independently.

If you accidentally mark a scan as aligned, remove it from the registered group by selecting the *Mark as unregistered* item from the dropdown menu, or just double-click it.

9.6.2 Displaying Scans in 3D View

Scans selected in the *Align* panel appear in the *3D View* window. Keys 1, 2 and 3 switch among scans in the *3D View* window:

1	Shows aligned scans and groups
2	Shows scans that are currently under alignment
3	Shows all scans

Navigation in align mode is similar to navigation in the *3D View* window:

Rotate	Hold <code>LMB</code> and move mouse
Zoom in/out	Scroll the <code>Mouse wheel</code> , or hold <code>RMB</code> and move mouse
Move freely	Hold <code>LMB</code> and <code>RMB</code> simultaneously, or hold the middle button, and move mouse

9.6.3 Summary of Alignment Modes

The table below provides basic information on the various alignment modes (see *Scan Alignment*).

- **Scan type** lists which scans you can use in a particular mode.
- **Scans per operation** is the number of scans required to use a particular mode.
- **Markers in set** prescribes how many markers (points) you can map in one point set. Some modes require point (marker) sets, but some don't.
- “—” means that markers are unnecessary.
- “0 or 2” means point specification is optional and, if you do specify them, only marker pairs are allowed.
- “At least 1” means you can specify an unlimited number of markers in one set.

Table 11: Parameters for alignment modes.

Mode	Scan Types	Scans per Operation	Markers in Set	Notes
Rigid (markers)	Any	2	2	Considers only coordinates, not geometry
Rigid (meshes)	Any	2	0 or 2	Considers geometric features
Rigid (texture)	Multiframe with poor geometry	2	0 or 2	High resource consumption
Rigid (auto)	Any	Any number	—	Works if surface is well textured
“Drag”	Any	2	—	Interactive
Non-rigid	Models	Any number	0 or 2	Deforms surfaces and textures; pre-alignment required
Complex	Any	1 (at least 2 for models)	At least 1	Precise and flexible

9.6.4 Drag Alignment

Drag alignment is always available, regardless of which tab is active in the *Align* panel. This mode allows you to align scans by manually dragging them in the *3D View* window.

Owing to the low accuracy of this approach, however, you can optionally use it for preliminary alignment before running more-accurate modes.

1. Select the scan you want to align, keeping in mind the recommendation in *Selecting Scans for Alignment*. Artec Studio allows you to select multiple scans, but note that it will align them with the registered scans as a single unit.




Figure 66: Dragging a scan




Figure 67: “Drag” alignment result

2. Holding down the `Shift` key and one mouse button, move and rotate the scan you're aligning (a green one ●) close to the registered scan (a blue one ●). Here is a list of allowed movements and corresponding buttons:
 - `Shift+LMB` to rotate
 - `Shift+LMB+RMB` to move
 - `Shift+RMB` or `Shift+Scroll` to move only unregistered scan along the view direction
3. To confirm the alignment, release the mouse button(s) and the `Shift` key, then click *Apply*. Note carefully that any scans you are registering won't automatically move to the registered set ● (see [Figure 67](#)). You can do so manually as the *Changing Scan Status* describes.
4. If you have several scans to align, repeat these steps for each one individually.

9.6.5 Auto-Alignment

Rigid alignment is a universal mode suitable for aligning most scans. Auto-alignment is the easiest approach, however. The advantages of this latter mode include the ability to align several scans at once and avoid the need to specify points; the only disadvantage is minimum requirements for the size of the overlapping areas in the scans you're aligning.

To perform auto-alignment, follow these steps:

1. Make sure the *Rigid* tab is selected in the *Align* panel (see [Figure 68](#)). The tool will automatically select all scans. Clear unnecessary selections by using the `Ctrl` key (see *Scan Alignment*).
2. Click *Auto-alignment*. Ideally, Artec Studio aligns all the scans and marks them using the ● icon. It may, however, mark scans as registered even though the 3D surfaces failed to join properly.

Important: Auto-alignment may be unsuccessful if the scans have small overlapping area.

Auto-alignment may produce the following results:

- Aligned scans, marked with the ● icon (basic group of registered scans)
- Unregistered scans, marked with the ● icon
- One group (●) or several groups (●, ●) of registered scans. Scans forming this group failed to align with the basic registered group (●), although they succeeded in aligning with each other.

We recommend resolving issues with unregistered scans or registered groups by aligning them manually as *Manual Rigid Alignment Using Point Specification* describes. Other methods may also help.

9.6.5.1 Managing Groups and Scans


You can perform the following actions on the scans from the list in the *Align* panel (right-click on the item to open the context menu):

- *Mark as registered*. Only available for single unregistered scans (● → ●)
- *Mark as unregistered*. Use this command to discard the alignment state of a particular scan (unavailable for ● scans)
- *Select group* highlights the respective group (●, ●, ● and so on)
- *Mark group as registered* converts all scans from the group into the basic registered group (● → ●)

9.6.6 Manual Rigid Alignment Without Specifying Points

You can perform rigid alignment either with or without specifying points. If the scans are close to each other in distance (e.g., after “drag” alignment), or if they have a large overlapping area or rich texture, you can skip the task of point specification when aligning them.

Perform the following steps:

1. Make sure the *Rigid* tab is selected (see [Figure 68](#)).
2. Select the scan you want to align, as the beginning of [Scan Alignment](#) describes.
3. Click *Align*. The result should be as [Figure 70](#) depicts. If you are dissatisfied with this result, click  and follow the recommendations in [Manual Rigid Alignment Using Point Specification](#).
4. Select another scan from the list of unregistered scans and repeat the above procedure.
5. Click *Apply* to confirm your alignment results or *Cancel* to reject them.

9.6.6.1 Texture Alignment

If the object was scanned with texture, the texture-alignment feature may ease the alignment process. It uses texture-image characteristics of scanned objects and greatly decreases the possibility of incorrect alignment. This feature also helps to align objects with few or no geometrical features, such as round or flat objects with no corners. If an object has rich, nonrepetitive geometry, however, we recommend disabling texture alignment to reduce the algorithm’s running time. Also keep in mind that texture alignment will be useless if the object texture is monochrome.

To enable texture alignment, select the *Enable texture alignment* checkbox at the bottom of the *Align* panel just before you perform Step 3 of the [procedure](#) above.

Note: Texture alignment is a resource-intensive algorithm that slows down the alignment process. We recommend using it only in cases where the object's geometrical features are insufficient.

9.6.7 Specifying Points and Editing Their Positions

Before considering how to align scans using points, it is helpful to highlight point-pair specification. The alignment algorithm uses pairs of point, or point sets in “Complex alignment” mode (*Complex Alignment*), to detect scan areas that should be brought close together.

To do point alignment, create several point pairs. To create one pair, mark one point on the aligned scan and then mark another one on the unaligned scan. Ensure that in each case the points for a given pair match a corresponding point on the surface of a real object; note, however, that high matching accuracy is unnecessary, since Artec Studio only uses the pairs to gain a rough approximation before performing precise registration. In the *Complex* mode, you can create a set of points (instead of just a pair), i.e. you can simultaneously specify more than two points in one or several unregistered scans and only one in the registered scan. All these points are connected by polylines and form a set.

When specifying points in the *Rigid* and *Nonrigid* modes, the application automatically creates pairs. Having specified one pair, you can immediately create the next one. In *Complex* mode you must confirm set creation by hitting `Space` or by clicking *New set* from the left panel, because the set may comprise multiple points (see [Figure 69](#) and [Figure 75](#)).

You can toggle between the point pairs (sets) by hitting `Space` and `Backspace`, or by clicking `RMB` in the *3D View* window and selecting the relevant options from the menu. You can also relocate points in the pair (set). Hover the mouse cursor over the point until the pair (set) is highlighted in white, then drag the point to the proper position using `LMB`, or select the pair (set) and specify a new position using `LMB`. To confirm your actions and deselect the pair (set), hit `Space`. You can also remove either a pair (set) or one of its individual points: click on the point using `RMB` and choose the appropriate command from the menu. Alternatively, you can use `Del` to remove the selected pair (set).

9.6.8 Manual Rigid Alignment Using Point Specification

We advise using this mode when scans are located at a significant distance from each other.

To use this approach, follow these steps:

1. Make sure the *Rigid* tab is selected (see [Figure 68](#)).
2. Select the scan you want to align, as the beginning of *Scan Alignment* describes.



Figure 68: *Align* panel: *Rigid* tab.

Figure 69: Creation of point pair.




Figure 70: Alignment result.

3. Specify several point pairs (Figure 69), keeping in mind the recommendations from *Specifying Points and Editing Their Positions*.
4. Click *Align markers*. This mode takes into account only the coordinates of specified points and tries to reduce the distance between the markers for each pair.
5. Carry out Steps 3–5 of the *procedure* in *Manual Rigid Alignment Without Specifying Points*.

9.6.9 Nonrigid Alignment

Whereas rigid alignment can only perform such transformations as translation and rotation, the nonrigid algorithm can deform 3D data. This algorithm is intended to process so-called nonrigid objects: objects whose shapes have changed during the scan (e.g., models of animals or humans—see Figure 72, left). Keep in mind that the surface Artec Studio produces as a result of the deformation may differ from the surface of the actual object.

Note: Nonrigid alignment works on models only. Thus, before you run it, prepare models by fusing the source scans. It is also necessary to first align models in rigid mode (see *Manual Rigid Alignment Without Specifying Points*, *Auto-Alignment* or *Manual Rigid Alignment Using Point Specification*).

To run the nonrigid alignment, follow these steps:

1. Make sure the *Nonrigid* tab is selected (see Figure 71).
2. Select the models you want to align, as the beginning of *Scan Alignment* describes.
3. If the models differ significantly from each other, we suggest that you specify several point pairs, keeping in mind the recommendations in *Specifying Points and Editing Their Positions*.




Figure 71: *Align* panel: *Nonrigid* tab.





Figure 72: Two models after rigid (left) and nonrigid alignment (right).

- Where necessary, adjust the deformation degree using the flexibility slider. The greater the flexibility value (i.e., the more “flexible” the deformation), the longer the computation will take.

Warning: Avoid extreme *Flexibility* values. Applying very large values may result in major surface distortions and may slow down the algorithm. Extremely low values, on the other hand, barely deform surface and often fail to produce the expected nonrigid-alignment results.

- Click *Align...* The algorithm will align models by deforming one of the model (see [Figure 72](#), right). If you are dissatisfied with the alignment results, click  and specify additional point pairs, or reposition the current pairs.
- Select another model from the unregistered set and repeat the steps above.
- Click *Apply* to confirm your alignment results or *Cancel* to reject them.




Figure 73: *Flexibility* slider in action: original model (left), nonrigidly aligned model with low *Flexibility* value (middle) and with high value (right).

Note: This version of Artec Studio does not support texture mapping on nonrigidly aligned models.

9.6.10 Complex Alignment

Complex alignment allows you to align not only scan to scan, but surface to surface within a given scan (see the mode comparison in [Summary of Alignment Modes](#)). Relative to other modes, this one supports multipoint-set definition—that is, you can link more than two points. It’s useful for aligning scans obtained during circular movements of the 3D scanner in cases where fine or global registration fails to align them. To run the *Complex* alignment, perform the following steps:

- Make sure the *Complex* tab is selected (see [Figure 74](#)).
- Select the scans you want to align, as the beginning of [Scan Alignment](#) describes. This mode allows you to work even with just one registered (●) scan.




Figure 74: *Align* panel: *Complex* tab.




Figure 75: Before alignment: two point-set added.






Figure 76: Alignment result.

3. Specify one or more point sets on the scan surface (see [Figure 75](#)), keeping in mind the recommendations in [Specifying Points and Editing Their Positions](#).
4. Click *Align...* to run the alignment with your specified constraints ([Figure 76](#) shows example results). If you are dissatisfied with the alignment results, click  and specify additional point sets, or reposition the current sets. To redo an operation that you have undone, click .
5. Click *Apply* to confirm your alignment results or *Cancel* to reject them.


9.7 Global Registration

Once you have aligned all your scans, proceed to the next stage: global registration. The global-registration algorithm converts all one-frame surfaces to a single coordinate system using information on the mutual position of each surface pair. To do so, it selects a set of special geometry points on each frame, followed by a search for pair matches between points on different frames. To perform correctly, the algorithm requires an initial approximation, which a user ensures in the course of the *Align* operation.

Note: Global registration is a resource-intensive operation. Processing of large data sets may take a long time and require a large amount of RAM.

To launch the algorithm,

1. Select all aligned scans in the *Workspace* panel.

Hint: If you want to use features of a particular scan but freeze its frames' relative positions, lock it using the  flag (see [Workspace Columns](#)).

2. Open the *Tools* panel.
3. Locate the *Global registration* section.
4. Check the *Preset* field. It must display the actual scanner that was used to obtain the selected scans.
5. Click *Apply*.

9.7.1 Global-Registration Parameters

<i>registration_algorithm</i>	<i>Geometry_and_Texture</i> or <i>Geometry</i>	The type of algorithm that will perform scan registration. If an object has rich texture and poor geometry, consider using the <i>Geometry_and_Texture</i> option. For objects with rich geometry, you can choose <i>Geometry</i> mode to increase the registration speed.
<i>key_frame_ratio</i>	0–0.6	Determines how many surfaces are treated as key frames. Decreasing this parameter when processing a feature-rich object may speed up registration. Increase it if only the previous attempts to register scans failed. Technically, values higher than 0.7, including 1, are possible, but they may significantly slow down the algorithm.
<i>feature_search_radius</i>	3–5 mm (Spider); 5 mm (Eva/Leo) and 50 mm in <i>Geometry_and_Texture</i> mode	Controls how sparse the features are located. Objects with many repetitive features may require decreasing this setting, whereas large values will ensure algorithm robustness on the big objects. Increase this parameter sparingly since large values may cause erroneous registration and hinder calculation. Adjust it if <i>Fine Registration</i> completes with inappropriate values of <i>maximum errors</i> .

9.7.2 Global Registration for Point-Cloud Scans

Global registration with the *Artec Ray* preset only runs on several point-cloud scans. Artec Studio offers three modes:

- *Targets* considers only targets (spheres and checkerboard targets)

- *Geometry_Ray*. The prerequisite step for this mode is alignment. The scans must be have sufficient initial approximations and may not have targets.
- *Targets_Geometry*. Global registration first runs on the basis of targets, then on geometric features.
- *Geometry_alignment* is suitable for point-cloud scans captured without targets. It doesn't require an alignment, but you need to run *Geometry_Ray* afterwards.
 - *effective_distance_from_scanner* is a radius around the scanner viewpoint from where the algorithm will take points. Alter it when you need to ignore the background 3D noise.
 - *voxelSide* is a volume measure to cull the extra points from the algorithm input. The more the value, the more the points will be culled and the faster the algorithm. Increase it sparingly since it affect the algorithm accuracy.
 - *minDistBetweenDescriptors* is a factor to adjust the point culling. Decreasing it will result in increasing the algorithm robustness and duration.

9.7.3 Possible Global-Registration Errors

- After the global-registration algorithm finishes, the frames are in disarray (see [Figure 77](#), left) or the frame positions are unchanged. This error occurs because the application is configured for a different scanner type than the one that captured the data. Change the device type in the application settings (see [Algorithm Settings](#)).
- The algorithm has completed successfully, but a gap exists between two or more scans (see [Figure 77](#), right). Select just these scans in the *Workspace* panel and run the global-registration algorithm. If the scans have drawn closer to each other but have failed to align after the algorithm finishes, increase the number of iterations and rerun the algorithm. Repeat this process until you achieve full alignment, then run global registration once again for all data. If you are unable to align several problematic scans, try aligning just two of them, then gradually increase the number of scans until all of them are aligned.

9.8 Ray Scan Triangulation

Application offers two ways to convert point-cloud surfaces to the commonly used models:

- *Fusion* operation
- Special triangulation algorithm

The latter approach is preferable to fusion in terms of speed. It generates a polygonal mesh from the original point cloud by simplifying its structure.

To launch this algorithm, follow the steps:

1. Mark a scan from Artec Ray using flag  in the *Workspace* panel.




Figure 77: Global-registration errors: wrong settings on left and gap between scans on right.

2. Access *Tools* from the left toolbar.
3. If necessary, specify the *decimationStep* and set either of the threshold filters.
4. Click *Apply*.

<i>method</i>	<i>Simple, Adaptive</i>	Adaptive takes into account the distance from the scanner, whereas Simple removes points with the fixed step (<i>decimationStep</i>)
<i>decimationStep</i>	1–10	The larger the value, the more the points will be culled. 1 leaves the point cloud unchanged. 2 culls half of the points, 4 keeps some 25% of the total amount of points, 10 about 10%.
<i>useWholeCloudTriangulation</i>	On/Off	Enable it to stitch sections of the point-cloud scans
<i>colorMode</i>	<i>SourceColor, SectionColor, None</i>	It can color an output model on the basis of vertex colors (<i>SourceColor</i>) or sections constituting the point-cloud scan. The latter yields multicolor model.
<i>edgeLength</i>		<i>Adaptive</i> method tries to maintain this edge length for triangles within the entire model.
<i>maxEdgeLength</i>	Above 0.1 mm ¹	Algorithm will remove triangles whose edge lengths are greater than the specified value.
<i>minTriangleAngle</i>	1–60 ¹	Triangles with angles smaller than specified limit (in degrees) won't be created in the resulting mesh. Extremely large values that are out of the recommended range may yield no mesh.
<i>maxIncidenceAngle</i>	0.1–90 ¹	If the angle between the normal to triangle and the scanner view direction is larger than the specified one, this triangle is subject to removal.
<i>maxTriangleAngularSize</i>	0.1–90 ¹	The algorithm will remove triangles whose edge lengths form angles (toward the scanner viewpoint) greater than the specified limit (in degrees).

9.9 Creating Models (Fusion)

Fusion is a process that creates a polygonal 3D model. It effectively melts and solidifies the captured and processed frames. Fusion is the most interesting part of the processing task because a polygonal 3D model is what most people expect to see when performing a 3D scan. To this end, you can use one of the following algorithms, each of which has a self-explanatory name (see also the summary in [Table 12](#)):

- *Fast fusion* produces quick results.
- *Smooth fusion* is good for scanning the human body because of its ability to com-

pensate for slight movements by the person you're scanning.

- *Sharp fusion* perfectly reconstructs fine features and is suited to both industrial objects and human bodies. It is the only mode that allows you to use all the capabilities of a Artec Spider scanner.



Figure 78: Models of a human subject obtained using various algorithms: *Fast fusion* (left), *Smooth fusion* (middle) and *Sharp fusion* (right).




Figure 79: Models of a shoe sole obtained using various algorithms: *Fast fusion* (left), *Smooth fusion* (middle) and *Sharp fusion* (right).

Table 12: Comparison of fusion modes.

	Fast Fusion	Smooth Fusion	Sharp Fusion
Usage	Fast results for large data sets; also for measurements	Large, noisy data sets with patchy missing regions; scans of moving objects	Scans from Artec Spider; scans having regions with fine details and sharp edges
EVA	resolution no less than 0.5		
Spider	resolution no less than 0.15		
L	resolution no less than 1.5		
<i>Fill_holes</i>	Not applicable	Available	
Features	Resulting surfaces are relatively noisy.	Smoother results. Can compensate for slight movements, but not recommended for accurate measurements. Relatively slow.	Higher level of detail. Faster than <i>Smooth fusion</i> , but may intensify existing noise.

To obtain a model:

- Make sure the scans you intend to fuse have passed *Global registration*.
- Select the scans in the *Workspace* panel using .
- Enter the *Tools* panel.
- Select the necessary mode; optionally, specify parameter values.
- Click *Apply*.
- View the model in the *3D View* window and in the *Workspace* panel once the algorithm finishes. The model name will match the algorithm name.

The fusion algorithms use the following parameters:

- *resolution* is the step of the grid (in millimeters) that the algorithm uses to reconstruct a polygonal model. In other words, this parameter defines the mean distance between two points in a model. The lower the *resolution* value, the sharper the shape. When specifying values, keep in mind the default values, lower limits in [Table 12](#) and [Err.](#)
- *Fill_holes* instructs the algorithm to fill holes in the mesh being reconstructed; option unavailable for *Fast fusion*. The methods for filling the holes are as follows:
 - *By_radius* fills all holes with radius less than or equal to the specified value in the *max_hole_radius* text box (in millimeters)
 - *Watertight* automatically fills all holes in the mesh
 - *Manually* prompts you to fill holes manually in the *Fix holes* panel, which opens automatically
- *remove_targets* allows you to erase small embossments from surfaces on which targets are placed (see [Target-Assisted Scanning](#)). Parameter can assume either the *On*

or *Off* value; unavailable for *Fast fusion*.

9.9.1 Fusion-Algorithm Errors

Occasionally, defects appear in the 3D model after fusion; some are correctable by creating additional scans, whereas others are correctable by using the model-processing tools described in the next section.




Figure 80: Surface noise caused by insufficient data (left) and improved model after adding one more scan (right).

Errors that can be corrected by capturing additional scans include low-amplitude noise on the surface (see [Figure 80](#), left). Normally, this error indicates that the affected area has a small number of frames. The number of frames needed to eliminate the noise depends on the reflective properties of the object's surface. To correct the error, you need one more scan to cover the noisy area (see [Figure 80](#), right).

Sometimes the cause of noise is an insufficient number of scanning angles. Areas captured at a larger angle have more noise than areas captured at a direct angle (i.e., 90 degrees). You can correct this error by scanning the area again using a better angle.


When the scanning conditions or the object features are such that you are unable to capture additional data, you can correct errors using the *Fix holes* (see [Hole Filling](#)) or *Smoothing* ([Smoothing Tools](#)) tools. If such errors are frequent, reduce the speed at which you move the scanner around the object, or increase the capture rate (see [Decreasing Scanning Speed](#)).

9.10 Editing Models

The resulting fusion model may contain surface defects due to scanning or registration errors. Artec Studio provides a number of tools to correct such errors:

- *Repair* corrects the model's triangulation errors.

- *Small-object filter* removes small objects located near the model surface.
- *Fix holes* semiautomatically fills holes and smooths the model edges.
- *Hole filling* fills holes in the model automatically
- *Smoothing* filters low-amplitude noise over the whole model
- *Smoothing brush* enables manual smoothing of the surface areas with the most noise
- *Mesh simplification* reduces the number of polygons in a model while minimizing lost accuracy
- *Isotropic remesh* creates isotropic mesh while keeping the processed mesh as close to the original as possible


Each algorithm processes all scans selected in the *Workspace* panel and replaces the original data with the results. If the algorithm is unsuccessful, you can restore the original data by clicking  (*Undo*) in the *Workspace* panel.

9.10.1 Small-Object Filter

If you forgot to erase outliers before fusion (see *Eliminating 3D-Noise (Outlier Removal)*), Artec Studio may solidify and preserve them in the scene as small, distant fragments.

You can effectively remove these remaining outliers by using a filtering algorithm.

To remove these artifacts, select in the *Workspace* panel only the model you are currently editing, then open the *Tools* panel. Click *Apply* next to *Small-object filter* to run the algorithm (see *Figure 81*). A window containing algorithm settings will appear when you click

. You can adjust the following parameters:

- *mode*
 - The *Leave_biggest_objects* option from the dropdown menu instructs the algorithm to erase all objects except the one with the most polygons
 - *Filter_by_threshold* erases from the scene all objects whose number of polygons is less than the amount specified in the *threshold* parameter.
- *threshold* is the maximum number of polygons for *Filter_by_threshold*.

9.10.2 Defeature Brush (Editor)

Erasing certain geometrical imperfections often demands further processing of the resulting holes in the model. The *Defeature brush* combines functions of the *Eraser* and *Hole filling* tools and may boost your productivity. To use it, follow these steps:

Warning: If you edit a textured model, note the following. Since the texture will incorrectly fit the altered surface, the Defeature brush will remove it from the model. So you will need to repeat *texturing* after you finish editing.




Figure 81: Filtering of small objects: before (left) and after (right).











Figure 82: *Defeature brush*: imperfection on the scanned surface (left), results of applying the tool (right).

1. Select one model in the *Workspace* panel.
2. Open the *Editor* panel using the side toolbar and click either *Defeature brush* or hit **D**.
3. In the *Editor* panel, choose the required selection type.
4. Consult the *instructions* for each mode and select regions on the model that you want to modify. To clear all selections, click *Deselect*.
5. Click *Apply*. The software will delete the feature, close up the hole and smooth the surface.

To undo changes, click  in the *Workspace* panel or menu *Edit*, or hit **Ctrl + Z**. Each click of the *Apply* button generates a command history entry. To undo several operations, use the dropdown menu of button  and select the lowest entry.

9.10.2.1 Selection Types

2D		Hold down Ctrl and use Scroll wheel to adjust the tool size. Paint with Ctrl+LMB to create a selection.
3D		See above.
Rectangular		Use Ctrl+LMB to select a rectangular region.
Lasso		Use Ctrl+LMB to freely outline an irregular region.
Cutoff-plane		Create selection as in 2D mode. Once you have released the mouse button, a plane will appear. If necessary, adjust the plane level by using Scroll wheel while holding down Ctrl+Shift or orient the plane freely in 3D space. To this end, hit Alt to display the <i>designated control</i> . Then still holding the key, drag the required control ring.

If you need to deselect any region, hold **Ctrl + Alt** and reselect this region. To clear all selections, click *Deselect*.

If the *Select through* checkbox is selected, all surfaces throughout the model are affected. If not, the brush only works on the visible surface.

See also:

Hot keys in Editor.

9.10.3 Smoothing

9.10.3.1 Smoothing (Tools)

The smoothing algorithm evens out noisy areas in the 3D model. Artec Studio provides two such tools: automatic smoothing of the entire model and manual smoothing of specific areas identified using a brush (see *Smoothing Brush (Editor)*).





Figure 83: Applying *Cutoff-plane selection* in *Defeature brush*.


To run the automatic smoothing algorithm, open the *Tools* panel and select *Smoothing*. You need only set the *steps* parameter (the number of algorithm iterations to be performed).

9.10.3.2 Smoothing Brush (Editor)

The *Smoothing brush* is a tool that you can employ selectively in specific areas without touching areas that require no alteration (for more information about automatic smoothing, consult *Smoothing (Tools)*).

To use the *Smoothing brush*,

1. Select just one model.
2. Open the *Editor* panel, and click the  icon or hit *S*.
3. Hit *Ctrl*, an orange region will appear around the cursor in the *3D View* window.
4. Change brush size if necessary:
 - Use either the *Ctrl* + *[* and *Ctrl* + *]* shortcuts or
 - Use *Scroll wheel*.
 - Enter a size (in millimeters) in the *Brush size* field.
 - Alternatively, you can adjust the slider bar in the *Smoothing brush* panel.
5. Set the smoothing strength if necessary:
 - Enter the desired value in the *Smoothing strength* field or
 - Adjust the slider bar.
6. Hold *LMB* and paint the surface region in order to smooth it. The tool will smooth the affected areas (see *Figure 84*, right).

To undo changes, click  in the *Workspace* panel or hit *Ctrl* + *Z* as many times as needed to return to the original state of the model since each brush stroke generates a command history entry.





Figure 84: Before smoothing (left) and smoothing out a poorly captured area (right).

9.10.3.3 Smoothing Edges

The *Edges* tab allows you to smooth ragged edges of the model.

To smooth an edge or any part of it, follow the steps:

1. Open *Fix holes* → *Edges*. It will show the list of edges detected on the surface. These defects are sorted by their full length.
 - Mark the checkbox next to the edge in the list to select **a whole edge**².
 - In *3D View* window, hold down **LMB** and drag the square control to specify **a part of the edge**.
 - Use the *Select all* button to select **all edges**.
2. Artec Studio will highlight these edges in red and draw yellow curves alongside them depicting smoothed boundaries.
3. Use the *Strength* slider to control the edge-smoothing intensity as necessary.
4. Click *Smooth edges*.
5. Click *Apply* to confirm the results. If the results aren't satisfactory, use the  button to cancel recent changes.

9.10.4 Hole Filling

Sometimes the shape of an object or the scanning conditions prevent you from properly capturing of all parts of the scene. As a result, the fused 3D model will have holes. In such instances, you can use either of the hole-filling tools to interpolate the surface.

- *Bridges or Smart Hole Filling*
- *Automatic Hole Filling*
- *Fixing Holes*

² If the *Move camera to selection* option is checked, the model will automatically rotate to display the selected hole.




Figure 85: Boundary selection for edge smoothing




Figure 86: Edge-smoothing algorithm results.

9.10.4.1 Bridges or Smart Hole Filling

The *Bridges* tab is intended to connect a pair of the edge fragments by constructing a surface that follows the curvature of the neighboring surfaces.

To create a bridge, follow the procedure:

1. Open *Fix holes* → *Bridges*. All holes will outline in red.
2. Specify two opposite fragments³ between which a bridge will go (Figure 88). There are two ways to do this:

Quick method	Ctrl-key method
Perform the steps below for each fragment :	Click once anywhere in the <i>3D View</i> to activate this method and then perform the steps below for each fragment :
<ol style="list-style-type: none"> a. Point the cursor at the edge. A part of this edge will be automatically highlighted indicating a future fragment. b. Drag the cursor along the edge to find the desired fragment location. c. Click LMB to confirm the fragment. 	<ol style="list-style-type: none"> a. Press and hold Ctrl and then point the cursor at the edge. b. Press and hold Ctrl+LMB to specify a fragment beginning. c. Still holding Ctrl+LMB, drag the cursor to specify the entire fragment. d. Release Ctrl+LMB to confirm the fragment.

3. Once you've confirmed the second fragment, a bridge preview will appear.
4. Drag the red sizing handles to adjust the bridge width and position as necessary.
5. Adjust *bridge curvature* on both sides and *Bridge smoothness* as necessary.
6. Click *Build bridge* to confirm your bridge.

The table below lists the possible actions matched with the options and commands for this tool.

³ Normally a bridge goes between two opposite fragments of one hole. In complex cases, you may use fragments on different holes or edges.




Figure 87: From left to right: original surfaces, bridge preview, actual bridge.




Figure 88: Specifying fragments. Correct fragments can resolve original geometry.

Prepare edges by removing raggedness	Select the <i>Smooth edges first</i> checkbox
Preserve the original geometry (Figure 88)	Clear the <i>Smooth edges first</i> checkbox
Smooth bridge surface	Use the <i>Bridge smoothness</i> slider
Edit bridge-preview position	Drag the square controls around the corners of the bridge preview
Adjust bridge tension	Use interactive sliders <i>Curvature (start, end)</i>
Delete bridge preview	Click <i>Clear preview</i> or <i>Delete</i> key

Smoothing or Keeping Edges

Smoothing edges might not always be beneficial to you. If the bridge failed to recreate the original geometry, try one or several actions from the following list:

- Clear the *Smooth edges first* checkbox.
- Use small or medium values of the *Bridge smoothness* slider (Figure 89).
- Select fragments correctly.





Figure 89: Small smoothness values on left and maximum on right.

9.10.4.2 Automatic Hole Filling

To quickly and automatically fill holes, use the *Hole filling* algorithm in the *Tools* panel. The algorithm only processes holes with perimeters below the threshold specified in *max_hole_len* (maximum length of the hole perimeter in millimeters).

Use button  to access this parameter.




Figure 90: Hole-filling algorithm: original model on left, processed on right.


9.10.4.3 Fixing Holes

Unlike *Bridges*, the *Holes* tab provides flat hole filling.

1. Open *Fix holes* from the side panel.
2. Select the *Holes* tab. It will show the list of holes detected on the surface. These defects are sorted by their perimeter length.
3. Select a hole either in *3D View window* or mark the checkbox next to it in the list. Artec Studio will highlight these holes in red (see [Figure 91](#)).

Note: If the *Move camera to selection* option is checked, the model will automatically rotate to display the selected hole.

Hint: Use the *Select all* and *Deselect all* buttons in the panel to select or clear all selections, respectively.

4. Click *Fill holes* to repair your model.
5. Click *Apply* to confirm the results. If the results aren't satisfactory, use the  button to cancel recent changes.

If you try to exit the *Fix holes* mode without accepting changes, the software will ask you for confirmation.

9.10.5 Mesh Simplification

The mesh produced after fusion may be less than optimal for some applications because it will contain a large number of polygons. This complexity will increase the amount of memory the model occupies, hindering further processing. To optimize the model size while retaining accuracy, use the *Mesh simplification* algorithm.

Select the model and open the *Tools* panel. You can choose from two algorithms.




Figure 91: Two holes marked for correction.




Figure 92: Result from running the *Fill holes* algorithm.





Figure 93: *Mesh simplification*: original mesh on the left, optimized mesh on the right.

9.10.5.1 Conventional Algorithm

Open the dropdown algorithm settings by clicking the  button next to *Mesh simplification*. Select the appropriate processing method (determined by the *stop_condition*):

- *Accuracy* optimizes model to a predetermined accuracy: the *error* parameter defines the optimized model's maximum allowable deviation (in millimeters) from the original model. When the algorithm reaches this value, the optimization stops.
- *Remesh* performs simple mesh optimization, removing triangles whose edge lengths are less than the *remesh_edge_thr* value (in millimeters).
- *Triangle_quantity* simplifies the model by targeting the number of triangles specified in the *tri_num* parameter. The algorithm minimizes the resulting model's deviation from the original model, but the final deviation value will remain unknown until processing concludes. Use this method when you know how many triangles the resulting model should have.

Tip: To determine the number of triangles, double-click the appropriate model from the list in the *Workspace* panel (see [Figure 44](#)).

- *UV_Triangle_quantity* is similar to the *Triangle_quantity* algorithm, but intended for meshes with textures mapped by the *Atlas* method (see [Applying Texture \(Procedure\)](#)). This approach not only simplifies the polygon grid, reducing the number of triangles, but it preserves texture.
- *UV_Verex_quantity* simplifies a textured model by targeting the number of vertices specified in the *vrt_num* parameter.

Tip: Since the UV methods tend to slightly reduce texture resolution, we recommend using either of them only when no raw scans are available. It is generally better to simplify models using one of the regular method and then reapply texture.

The three first algorithms in the list above have additional parameters:

- *keep_boundary* maintains the model boundary. Mesh simplification on the scan edges may affect their geometry. Thus, if the shape of the boundaries is more important than the optimized mesh, select the *On* value. Otherwise, select *Off*, and the algorithm will simplify the boundary mesh.
- *max_neighb_normals_angle* is the angle between the normals of two neighboring faces. You can specify an angle (default value is 120°) to prevent Artec Studio from creating degenerate triangles. If the angle measure in some region exceeds the specified value, the algorithm will leave the mesh unchanged in that region. Note that the default value is appropriate in most circumstances.





Figure 94: Boundary-appearance options: *keep_boundary* enabled (left) and disabled (right).

After adjusting the algorithm settings, click *Apply* to start processing.

Note: Mesh simplification may take a long time when the parameters of the original and optimized models are significantly different (for example, if the deviation value is high in *Accuracy* mode or if the required number of polygons in *Triangle_quantity* mode is much smaller than the number in the original model). For very large 3D models the operation requires extensive memory resources and may fail owing to insufficient RAM. Free the memory by closing unused applications and by optimizing memory usage in Artec Studio, keeping in mind the recommendations in *Memory*, *Command History* and *Selectively Loading Project Data*.

9.10.5.2 Fast Mesh Simplification

The *Fast mesh simplification* algorithm works faster than the conventional one. To run it, perform these steps:

1. Open the dropdown algorithm settings by clicking the  button next to *Fast mesh simplification*.
2. Specify in the *tri_num* text box the desired number of triangles for the resulting model. You can determine how many are in the actual model by double-clicking it in the *Workspace* window.
3. Set the *force_constraints* option:
 - If this option is set to *Off*, the value specified in the *tri_num* text box remains constant.
 - If this option is set to *On* and the algorithm is unable to produce a surface with the specified number of triangles (*tri_num*), Artec Studio will automatically update this value. In other words, improving the quality of the resulting surface is the primary objective.

4. Click *Apply* to run the algorithm.

9.11 Texturing

Artec scanners are equipped with a color camera, allowing you to capture 3D surfaces with texture and expanding the range of objects available for scanning. Texturing is a process that projects textures from the individual frames onto the fused mesh.

9.11.1 Preparing Model

To take advantage of texture, do the following:

1. Make sure the *Don't record texture* checkbox is cleared.
2. Adjust the capture frequency for texture frames (see *Texture-Recording Mode*) if necessary.
3. Avoid turning off the flash bulb.
4. Adjust the texture brightness in *Preview* mode by using the eponymous slider in the *Scan* panel.
5. Scan the object using a tracking algorithm of your choice. Captured frames are marked with the letter "T" in the *Workspace* panel (surface-view mode) (see [Figure 43](#), right).
6. Process the data and create a model, consulting the list in the beginning of *Data Processing* or *Use Autopilot*.
7. Run a mesh-simplification algorithm for the resulting model (see *Mesh Simplification*) to accelerate the texturing process.
8. Use the *Texture* panel to apply the texture to the model.

9.11.2 Applying Texture (Procedure)

The 3D model obtained after fusion contains no texture information. To apply textures onto a model, do the following:

1. Open the *Texture* panel
2. Choose a model from the first list (see [Figure 95](#)); Artec Studio will apply the textures to this model
3. Select from the second list the scans from which you created the model (these scans have the required textures)
4. Next, choose a method for applying textures to the model. Artec Studio offers two methods:
 - *Preview* (triangle map)

- *Export* (texture atlas)
5. Select the required *Output texture size*⁴ and other options as necessary (*Supplementary Settings*)
 6. Click *Apply* to start the texturing process⁵
 7. Finally, when the texture is ready, *adjust it* as necessary.

To reduce or increase the resolution (*Output texture size*) of the already applied texture, you can re-apply it several times faster by enabling the *Export (reuse UV map)* option.




Figure 95: Choosing a texture-application method and adjusting its parameters.

Warning: We recommend that you avoid applying texture to models that have undergone major changes in geometry or orientation. The algorithm will apply the texture incorrectly if you have done any of the following:

- *Position* or *transform* the model relative to its source scans
- *Nonrigid Alignment*
- Erase major parts of the model

⁴ Texturing with the 16K resolution (16384x16384) is only available if your graphics card features at least 3 GB of GPU memory.

⁵ To optimize resource utilization, Artec Studio unloads all surfaces from memory, except those needed for texturing, before running the applying procedure. For a more detailed description of selective project-data loading, see *Selectively Loading Project Data*.

Perform these operations only after texturing.

9.11.3 Modes

Table 13: Comparison of the texture-applying methods.

Mode	Texture Distortion	Speed	Number of Textures	Texture-Resolution Management
For pre-view	Does not preserve aspect ratio of triangles	Fast	One or more	Adjust triangle size and texture-image resolution
For export	Preserves aspect ratio of triangles	Slow	Only one	Adjust texture-image resolution

9.11.3.1 Texturing for Preview (Triangle Map)

The *Preview* method transfers all textured triangles to a square texture image (or a series of images). You can adjust the *Triangle size (in pixels)*⁶ using the eponymous slider (see [Figure 96](#), right). To select the resulting texture size, use the dropdown list (maximum texture size depends on the capabilities of your graphics card). After changing the triangle/texture size, the estimated number of textures will appear in the *Estimated* area at the bottom of the panel; the actual number may differ slightly, however.

9.11.3.2 Texturing for Export (Texture Atlas)

The *Export* method cuts the surface into pieces, then unfolds and nests these pieces flat and fits them into the specified image size (see [Figure 96](#) (middle) and [Figure 53](#) in *Displaying Boundaries of Texture Atlas*). This method takes longer to run than *Preview*, but the resulting texture is much more convenient for manual editing.

9.11.4 Supplementary Settings

To modify a texture using an inpainting technique, use one of these two options:

9.11.4.1 Inpaint Missing Texture

This option allows you to apply a texture to regions with no texture information by spreading it from the neighboring regions.

⁶ Triangle size is determined by the number of pixels per side.



Figure 96: Texture mapping methods: mesh with texture applied (left), texture-atlas sample (middle) and triangle-map sample (right). The latter covers only a portion of the mesh surface (the rest two images not shown).

9.11.4.2 Remove Targets

Remove targets is similar to inpainting. It paints out targets by applying surrounding texture information (targets are used to facilitate scanning—see *Target-Assisted Scanning*). This option makes sense if you enabled *remove_targets* before producing this fusion model (see *Creating Models (Fusion)*).

9.11.4.3 Enable Texture Normalization

Enable texture normalization aims to compensate for uneven lighting caused by movement of a scanner's flash unit during capture. We don't recommend clearing this checkbox.

9.11.4.4 Reduce Glare

Reduce glare is intended to eliminate glare spots on texture. This option is only available for *Texturing for Export (Texture Atlas)* and requires many texture frames captured from different perspectives.

1. Check whether the source scans include sufficient number of frames (especially those marked with "T"). If necessary, increase *texture-frame rate* and rescan.
2. Select the *Reduce glare* checkbox.
3. Adjust the *Reduction level* slider as necessary. Avoid extreme values.

Hint: Glare reduction is a time consuming algorithm. If you plan to obtain a high-resolution texture, we advise you to first tweak the settings on low values (for example, 512 x 512) and then reapply texture with the required *Output texture size*.

9.11.5 Texture Adjustment

After the texturing is complete, you can adjust the texture on the model (see [Figure 98](#)).




Figure 97: Hue, saturation and brightness representation.

You can adjust the following texture parameters by way of the corresponding sliders (see [Figure 97](#) for details):

- Brightness
- Saturation
- Hue
- Contrast
- Gamma correction




Figure 98: Texture adjustments.

The initial position of the *Hue* slider corresponds to the current texture color. Dragging it left or right corresponds to rotation counterclockwise or clockwise, respectively, on the

color wheel.

After making the necessary changes, click *Apply* to transfer the resulting textured model to the *Workspace* panel.

To reopen the texture-adjustment dialog, follow the steps:

1. Select a textured model in *Workspace*.
2. Use **RMB** to call the context menu.
3. Select the *Adjust texture* command from the list.

9.12 Texture-Healing Brush: Manual Inpainting

You can manually inpaint missing textures by using the *Texture-healing brush*. This tool is based on the same algorithm as the *Inpaint missing texture* option covered in *Applying Texture (Procedure)*. The inpainting algorithm uses texture information from neighboring regions to fill in areas with missing or incorrect texture. Left image in *Figure 99* shows a small texture imperfection: a felt-tip pen mark on the figurine. Results of inpainting this region appear in *Figure 99* (right).





Figure 99: Texture-healing brush: before application (left) and after (right).

To launch the tool and inpaint a texture, do the following:

Hint: We advise you to first back up your model by selecting the *Duplicate scans* command from its context menu since the undo function is unavailable in this tool.

1. Mark the model textured for *Export* with the  flag.

Important: This version of Artec Studio does not support texture restoration on the models 'textured for *Preview*' (triangle map) and in regions of any models that have been corrected using the *Defeature brush*.

2. Open the *Editor* panel by clicking its icon in the side toolbar.
3. Select the *Texture-healing brush*.
4. Hold down **Ctrl** while using **Scroll wheel** or **[** and **]** keys to adjust the tool size. It should not exceed the size of the region that needs texture correction.

5. Paint over the region of interest using **LMB** while holding down **Ctrl** so that the tool (a circle or a spot) only rolls over the problem area. Try to avoid touching neighboring areas. Use the *Deselect* button to clear all the selections.
6. Repeat the previous step as necessary.
7. Click *Apply* to accept the changes or close the panel to reject them.


Note: If you paint an area in which the number of polygons exceeds the value specified in the settings dialog (see *Warnings*), a message will appear prompting you to either ignore the value, which means that processing may take longer, or cancel the operation.

9.13 Preparing Models To Export

9.13.1 Moving, Rotating and Scaling (Transformation Tool)

The *Transformation tool* allows you to move, rotate, scale and mirror objects relative to the global coordinate-system axes.

To access this tool, open the *Editor* panel and select *Transformation tool* or hit **T**. The panel will open, displaying four tabs that correspond to different modes for altering the object position in the global coordinate system. The name of the active mode appears at the bottom of the *3D View* window.

To revert your changes inside the tool, use the *Reset* button. Artec Studio applies changes when you leave the tool. Use the  (*Undo*) button in the *Workspace* panel or hit **Ctrl+Z** to reset changes after you close the tool.

Hint: To quickly move objects to the origin and align them with the camera viewport, use the *Auto-position* button.

9.13.1.1 Translate

To enter translation mode, click the *Translate* tab or hit **T**. Three input fields will appear in the *Editor* panel showing the current origin coordinates (in millimeters) of the local coordinate system. The initial position of the local coordinate system will be in the center of the global one. To translate an object, do either of the following:

- Enter the new coordinate values for the local system using the input fields in the *Editor* panel. To adjust the position only along a specific axis, first hit the corresponding **X**, **Y** or **Z** key.
- Translate the object in the *3D View* window by dragging the corresponding control (see *Figure 100*):
 - *Square* in the center to move it freely

- *Arrow* to move it along a specific axis
- *Lines between arrows* to move it along the two axes simultaneously

Note: Orienting the object may be easier if you first specify a new position for the origin of the local coordinate system: double-click on the desired surface point in the *3D View* window.




Figure 100: Translation control

9.13.1.2 Rotate

To enter rotation mode, click the *Rotate* tab or hit **R**. Three input fields containing the Euler-angle values will appear in the *Editor* panel. Initially, all values are set to zero. To rotate the object, do either of the following:

- Enter the new angle values (in degrees) using the input fields in the *Editor* panel.
- Drag one of the three circles (see [Figure 101](#)) to rotate the object. Hitting the key that corresponds the required axis (**X**, **Y** or **Z**) will hide the controls for the other axes.

Note: Orienting the object may be easier if you first specify a new position for the center of the local coordinate system: double-click on the desired surface point in the *3D View* window.

9.13.1.3 Scale

To enter scaling mode, click the *Scale* tab or hit **S**. A single input field with the current scale value (1.000) will appear in the *Editor* panel. You have two options for scaling the object:

- Enter the new scale value in the field.
- Drag the origin of the control ([Figure 102](#)) or either of its round ends in the *3D View* window.




Figure 101: Rotation control




Figure 102: Scaling control

9.13.2 Placing Objects on Coordinate Plane (Positioning Tool)

You may need to place the model on one of the coordinate planes (e.g., for aesthetic reasons or when preparing the model for measurements, for capturing a screenshot, for exporting and so on). Instead of adjusting the model position using the *Rotate* and *Translate* modes of the *Transformation tool*, you can use the special *Positioning tool*. To do so, follow these steps below.

Tip: The *Enable automatic base removal* option may come in useful to position scans automatically after the scanning completes (see [Base Removal: Erasing a Supporting Surface](#).)

1. Open the *Editor* panel from the side toolbar and click either *Positioning tool* button or hit **P**.
2. Ensure that the coordinate axis grid is shown. Otherwise hit **G** or select the *Grid* command from 3D toolbar.
3. Choose the coordinate plane in which you want to place the model by activating one of the following options: *XOY*, *YOZ* or *ZOX*. Note that you may skip this step and return to it after Step 3.
4. Use **LMB** to specify at least three points on the surface; the plane will automatically pass through their center of mass (see [Figure 103](#)). The following conditions will then apply:




Figure 103: Positioning the model in the global coordinate system.

1. For each additional point you specify, Artec Studio rebuilds the plane. Click *Clear points* at any time to redefine the points.

Note: Three points determine a plane. When you're dealing with nonplanar surfaces, however, three points may be insufficient. In that case, the more points you specify, the more precisely a plane will fit the surface.

2. In addition to the plane passing through the center of mass of the points you select, the coordinate origin will shift to that location as well.
3. The position of the coordinate origin is adjustable, as described below.
5. Invert the direction of the coordinate axis, if desired, by clicking the *Invert Z* button for the XOY plane, *Invert X* for YOZ, or *Invert Y* for ZOX.
6. If appropriate, adjust the model's position relative to the coordinate origin:
 1. **Shift + LMB**—rotate the model around the axis that is currently normal to the plane
 2. **Shift + RMB**—move the model along the plane in a fixed direction
 3. **Shift + LMB + RMB**—move freely along the plane
7. Hit *Apply* to fix the model on a specified plane or close the panel to cancel positioning.

To discard changes of object position, click  in the *Workspace* panel or hit **Ctrl+Z**.


9.14 Advanced Techniques

9.14.1 Automatic Processing

See also:

Use Autopilot

Automatic processing is a special mode for the *Tools* panel that saves time and simplifies postprocessing. It allows you to run all postprocessing algorithms from the *Tools* panel (*Rough*, *Fine* and *Global registration*; *Fast*, *Smooth* and *Sharp fusion*; *Small-object filter* or *Outlier removal*; *Hole filling*; *Mesh simplification*; *Remesh*; and *Smoothing*) with a click of just one button.

To switch from manual to automatic mode, open the *Tools* panel and choose the *Auto* option from the *Mode* dropdown list. Click the  button near *Go!* to view all options available in automatic mode. Note that only *Global registration*, *Fast fusion* and *Small-object filter* are enabled by default. To perform other actions automatically, choose the *On* option in the dropdown list next to the required function, or choose *Off* to exclude




Figure 104: The extended Auto postprocessing menu.

a function from automatic processing. Click *Go!* or hit `Ctrl + G` to begin automatic processing.

Each algorithm setting and parameter is based on the values for a preset configured in the manual mode. To change these values:

1. Switch to *Manual* mode,
2. Select a specific scanner type via the *Preset* dropdown list,
3. Make the necessary alterations,
4. Click *Apply*, and then
5. Run automatic processing—Artec Studio will apply all changes.

Changing the scanner preset type resets all the parameters to the default ones (for the selected preset).

Keep in mind that the algorithms run in the order in which they are listed, starting with *Rough serial registration* and ending with *Isotropic remesh* (see [Figure 104](#)). Thus, if you want to run the *Small-object filter* before *Fast fusion* or *Global registration*, for instance, you must do so manually.

Unlike manual processing, automatic processing runs without the need for constant user attention, so it is more convenient when processing large objects: you can configure the settings, start the process and leave it unattended. It can also process objects of any size, reducing the number of mouse clicks to get the result.

9.14.2 Mirroring

Artec Studio allows to mirror the 3D data. The application uses the local rotation center as a mirroring center (see [Global Coordinate System and Rotation Center](#)). If it isn't specified, Artec Studio employs the global coordinate center.

To mirror the model, follow the steps:

1. Open *Editor*
2. Access [Transformation tool](#)
3. Select the *Mirror* tab
4. If necessary, double click the model to specify a rotation center
5. Select an axis to mirror the object along. Press the respective button—for example, *Along axis Y*.

To revert your changes, use the *Reset* button. For details, consult [Moving, Rotating and Scaling \(Transformation Tool\)](#).

9.14.3 Isotropic Remesh




Figure 105: Manual adjustment for the specific scanner type.



Figure 106: Mirroring in action.

Note: Don't confuse it with the *remesh* parameter in *Mesh simplification*.

Isotropic remesh is an operation that modifies 3D model in the way that new mesh triangles have uniform size. Software packages where the models from Artec Studio are intended to be used may impose these requirements.

The algorithm produces an isotropic mesh, but doesn't necessarily decrease the polygon count. However, the output file is often smaller than the original one through the uniform triangles.





Figure 107: Isotropic remesh operation in action: original model on left, processed one on right.

To produce a uniform mesh,

1. Mark the model using the  flag

2. Open the *Tools* panel
3. Locate the *Isotropic remesh* section
4. Click  and specify *resolution* as necessary
5. Click *Apply*.

9.14.4 Normal Inversion

Normal direction determines the visibility of a surface in 3D graphics. Learn how to show normals of the objects in Artec Studio *3D View*, see [Representation of Normals and Boundaries](#).

Normal inversion allows one to turn the model inside out. This operation may be useful when you need to manufacture some mating parts, like molds; or obtain a model based on its cast (e.g., turn the footprint cast into a shoe last, see [Figure 108](#)).





Figure 108: Normal inversion application: obtaining a foot model (right) from its cast (left).



To invert normals on a particular model,

1. Mark the model using the  flag
2. Open the *Tools* panel
3. Locate the *Normal inversion* section
4. Click *Apply*.

9.14.5 Correcting Triangulation Errors

Some algorithms may introduce triangulation errors into the resulting model. These errors include the following:

- *Unattached vertices*. Points that are not vertices of any of the triangles
- *Vertices with identical coordinates*. Vertices that have the same coordinates
- *Faces containing invalid vertices*. Triangles that point to nonexistent vertices
- *Singular faces*. Triangles for which at least two of the three vertices coincide.
- *Faces with equal signature*. Faces with fully coinciding sets of vertices
- *Edges incident to three or more faces*. Edges that are adjacent to three or more faces
- *Faces with wrong orientation*. Faces whose normals point in a direction opposite to those of the adjoining faces

To correct these errors, mark a model in the *Workspace* panel by using the  flag and hit **Ctrl + R** or select the *Window* → *Repair* menu command. If the algorithm detects no triangulation errors, Artec Studio will notify you that it has found no defects. Otherwise, the *Repair* panel will open, displaying the above-mentioned list of defects to be corrected. Next to the names of the defects, a column will appear stating the number of defects of a certain type found in the model. You can select all defects by pressing *View all*. Doing so will display in the model all the defective vertices and triangles using colored points. You can disable display of any particular defect type by removing the  icon next to the corresponding name, or disable them all by clicking *View none*. To correct the defects, click *Repair all*. Clicking the *Apply* button accepts the changes.

CHAPTER 10

Additional Modes

This chapter describes other Artec Studio modes, such as

- *Publishing to the Web*
- *Multicapturing*
- *Measurement Tools*

10.1 Publishing to the Web

Having models on a web may simplify the process of collaboration among users. Artec Studio allows you to publish your 3D models on the Web through viewshape.com. Viewshape is a service that uses WebGL to render 3D models in a web browser. You can see published models at viewshape.com or embedded at other websites, blogs or social networks. Models can be shared privately so that only those who know the unique URL can see, comment on and use them.

Most browsers currently support WebGL. If this feature is disabled or unsupported in a particular browser, viewshape.com displays the 3D geometry as a pre-rendered set of images that you can rotate using a mouse. Such images are called spin images.

To publish a model, use the *Publish* panel. It will open only if you have exactly one fusion selected in the *Workspace* window; otherwise, Artec Studio will display an error message. To log into viewshape.com, use your [my.artec3d](https://my.artec3d.com) account. If the process fails, you can access the login window from the link at the top of the panel (see [Figure 109](#)).

After you successfully login, you will see the window shown in [Figure 110](#). Follow the steps below to continue uploading:




Figure 109: Viewshape.com login window.




Figure 110: Publish panel.

1. Adjust model's position in the *3D View* window to see how it will appear on the Web.
2. Preview rotation when necessary.
3. Select visibility options (*Public* or *Private*).
4. Choose whether to employ WebGL: use *Show* to display a full-featured 3D model and rotate it freely, or use *Don't show (spin image only)* to display images of the model captured from different angles. You can rotate these images only around the vertical axis.
5. Select a license type for your model.
6. Specify the collection in your gallery to which you want to publish the model, or create a new one.

In addition to the above steps, you must also set the *Model name* and, optionally, the *Model description*. Once you have completed this entire process, click *Publish*; your model will appear on the site.

10.1.1 Model Requirements

WebGL is a progressive API, but it is not very powerful. If your model contains several million polygons and several very high-resolution textures, you will have difficulty rendering it in a browser. Therefore, to produce a model that looks good, you must first optimize it. We recommend the following model parameters:

- Fewer than 1000000 (300000 for Trial version) polygons
- Texture size of 4096×4096 (1024×1024 for Trial version) pixels
- Texture mapped using Atlas method (mandatory)
- Model positioned appropriately to rotate around Y axis

Using **LMB** in the *3D View*, you can rotate the model around its center of mass. Because translation is impossible here, you should rotate the model to the position in which you want it to appear on the web.

If the model parameters fail to satisfy the requirements and recommendations listed above, a yellow notification will appear at the bottom of the window, along with a button that instructs Artec Studio to fix the issue.

10.1.2 Fixing Issues

If your model suffers from one or more issues (as [Figure 110](#) shows), click the *Fix issues* button. The software will open the new panel shown in [Figure 111](#).

Artec Studio can currently identify two issues: very dense meshes and incorrect texture mapping. If the mesh is too dense, you must first simplify the model. The simplification tool is available in the *Issues found* dialog. If the texture is mapped using the *Preview* method (triangle map), you can remap it by clicking *Fix texture*, as [Figure 111](#) shows. The




Figure 111: Fixing model issues.

Texture panel will then open, allowing you to fix it using the *Export* method (texture atlas) and the recommended resolution.

Once you have resolved all the issues, click *Back to Publish* to return to the *Publish* panel and resume the publication process.

10.2 Multicapturing

Artec Studio enables synchronized scanning with multiple scanners. This mode is helpful when capturing a large object from several angles using more than one scanner simultaneously. Multicapturing with several scanners implies that the system knows their position in advance. This condition simplifies and accelerates data processing considerably. For this reason you must calibrate the relative positions of the scanners before capturing. The resulting calibration data, which includes scanner IDs and their spatial orientations, is referred to as a *bundle*.

Important: Using multiple Artec scanners requires your workstation to integrate as many independent USB host controllers as connected scanning devices.

Use the following procedure to prepare the devices and the environment to simultaneously capture 3D reality:

1. Calibrate the relative position of each device (i.e., create a bundle)
2. Use the *Multi* panel to capture scans

To create a bundle, perform the following steps:

1. Capture the test object using all bundled scanners (see object requirements in *Bundle Creation*)

2. Manually align the resulting scans using the *Align* tool to compute the relative position of all scanners
3. Create the bundle using the *Create bundle* panel

Note: Once you have created the bundle, you can no longer move the scanners relative to one another. If even one device has changed position, you must recreate the bundle!

10.2.1 Bundle Creation

Perform the following steps before creating a scanner bundle:

1. Select device positions. The scanners' combined field of view should cover the required area.
2. Fix the scanners in the chosen positions. If you plan to use hardware synchronization (see *Hardware Synchronization for Eva*), attach the scanners to the tripods by securing them with thumbscrews while allowing the wires to hang freely.
3. Select and set up the calibration object. Any object with a geometry-rich surface is a candidate. Avoid selecting objects with simple geometries for calibration (e.g., planes, spheres or cylinders). You may use several objects as a composition when creating a bundle. We recommend object installation at the distance corresponding to the middle of the operating range for the corresponding device type.

You can perform the scan using the *Capture* or *Multi* panel. The latter option is more convenient, as it allows you to capture the video data stream simultaneously from several scanners. For details regarding this mode, see *Performing Multicapture*.

If you install the scanners at small angles relative to each other (i.e., you can see the same object area simultaneously through different scanners), you need not rotate the object. In this case, you can take calibration scans either sequentially or concurrently.

Note: In case of sequential scanning, make sure the object is fixed safely and remains motionless during the scan.

If you set up the scanners at a large angle and their fields of view have no overlap, use the *Multi* panel to start the capture sequence and then turn (move) the object to enable all scanners to capture the same parts.

Note: It is important that all scanners capture a large portion of the object or scene (but not necessarily the same portion) in each frame, because the position of all subsequent frames—as well as the scanners themselves—will be determined by their predecessors. Also, the relative positions of the scans will determine the intercalibration of the devices.

If the cameras are far from each other and the object was moving, then you should register the scans using the *Fine registration* and *Global registration* algorithms. This requirement,





Figure 112: Bundle-creation window.

however, isn't applicable for 3D sensors: running *Global registration* may spoil the scans owing to low quality of the geometry obtained from the sensors.


4. Next, proceed to the *Align* panel and align the captured scans as *Scan Alignment* describes. At that point, everything will be ready for bundle creation.
5. From the menu, select *File* → *Create bundle*. A warning message will appear if you forget to align the scans. Otherwise, the bundle-creation panel will appear (see [Figure 112](#)). The *3D View* window will show the selected scans, the position and viewing direction of the scanners (by means of an appropriately colored pyramid), the device ID, and the scanner coordinates. It will display a list of connected devices and corresponding information.
6. Add a device to the bundle or remove one by inverting the  image in the leftmost column of the list. The order of devices in a bundle refers to the scan order in the *Workspace* panel.
7. A bundle name will appear in the field at the top of the bundle-creation panel. By default it contains the serial number of the bundled scanner. Before creating the bundle, you can easily change this name by typing in the corresponding field. Click *Apply* at the bottom of the panel to create and install the bundle.

10.2.2 Performing Multicapture

Multi mode allows you to capture 3D-data streams simultaneously from several devices. Selecting this mode activates the corresponding panel (see [Figure 113](#)) and lets you choose the device configuration: either use one of the existing bundles or specify the scanner list manually.

Note: In multicapture mode the system possesses information about the relative scanner positions. Therefore, scans captured by bundled scanners differ from manual scans in that the matching frames from different scanners are already in the same coordinate system.

1. Select the *Use bundle* checkbox. A dropdown list of all installed bundles will appear in the panel. Active bundles are highlighted in black, inactive bundles in gray. Artec Studio considers the bundle active if all bundled devices are installed and connected to the PC.
2. Select *Synchronization type* from the *Options* tab in the *Multicapture* panel.
 - In *Software* mode, scanners are synchronized via USB, *Windows* and Artec Studio, and the slave-scanner actuation time always varies (~10 milliseconds) owing to the numerous links in the chain.
 - In *Hardware* mode, scanners are synchronized via cables (see [Hardware Synchronization for Eva](#) for details). Hardware synchronization provides high precision and repeatability for slave-scanner actuation time (about 1 millisecond with a precision of less than 10 microseconds, thanks to microelectronic processes).

Figure 113: Multicapture panel: *Options* tab on left, *Device* tab on right.

Note: We recommend hardware synchronization in most circumstances; when capturing moving objects, it is mandatory.

3. Click *Preview* to start capture.

10.2.2.1 Tweaking Multicapture Options

You can store multicapture data either as separate scans (use the *Separate scans* radio button) or as a single scan in which every frame represents an aligned union of corresponding frames from all bundled devices (use the *Merge frames* radio button).

If you need to capture frames with a certain delay between the scanners, enter the delay value in the *Delay between frames* field. Unlike the *Scan* mode, the *Multicapture* mode captures each frame independently without attempting to align each subsequent frame with the previous one, so it makes sense.

Sometimes, limiting the cameras' field of view is necessary (e.g., to cut off extraneous distant objects). Two sliders in the *Depth of field* area set the near and far scanning boundaries. The application sets work-area boundaries for each device independently in the device tabs (see [Figure 113](#), right). By default, the minimum and maximum boundary values for the corresponding device type are set to the recommended range; we encourage you to avoid changing them. However, if you're using Artec L scanners or 3D sensors, it may become necessary. To change these values manually, mark the *Override default depth range* checkbox in the *Scan* tab of the *Settings* dialog and enter the appropriate values in the fields below.

Note: For most scanner types, redefining the recommended depth range may reduce accuracy.

Fast capture mode instructs Artec Studio to store raw scanned data in memory and processes frames after completing the capture sequence. It allows to save processor time on building and rendering surfaces. And if the number of processor cores is less than doubled number of scanners in the bundle, it can also increase scanning speed.

To enable it,

1. Check the *Fast capture mode* box.
2. Enter the desired capture duration in seconds. The application will automatically recalculate and display the required amount of memory.

Artec Studio saves multicapture parameters when you exit the application and reapplies them the next time you start it.

10.3 Measurement Tools

Artec Studio offers a number of measurement and commenting tools, including

- Linear measure
- Geodesic measure
- Sections (cross-sections)
- Surface-distance maps
- Annotations

The corresponding buttons reside in the upper part of the *Measures* panel (see [Figure 114](#)).

1. Choose a measurement tool, the application displays a list of scans you can work with
2. Select the checkbox of each desired scan. The scans will appear in the *3D View* window.
3. Click *Next*. The selected measurement-tool window will open.

The coverage below takes a closer look at the different measurement tools and their features.




Figure 114: *Measures* panel.

Hint: If your *Measurement* panel lists the previously created items, you can open one of them by double-clicking that item or clicking the *Edit* button.

10.3.1 Linear Distance

The linear-measurement tool (see [Figure 115](#)) allows you to measure distances between selected points and to measure the total length for a string of multiple points. Click the



button and select the scan to switch to the *Linear* window. You can enter a name for the new measurement by typing it in the *Name* field in the upper part of the window. The application creates new measurements with default names *Linear 1*, *Linear 2* and so on.

To measure distances between points,

- Use **LMB** to sequentially select the points on the model in the *3D View* window. The application will add these points to the current point list, which will also display linear dimensions and point coordinates.
- When you roll the cursor over any one of these points in the *3D View* window, the point will be highlighted in red; you can then drag it to another location using **LMB**. When you release the mouse button, the point will fix to its new location.

Warning: You can't set a point outside the object's surface; in this situation, if you release the mouse button, the point will return to its original position.

The total number of points and total length of the measurements appear in the *Measures* panel.

Table 14: Basic operations in the linear and geodesic measurement modes.

Purpose	Control Name
Hide scans in the <i>3D View</i>	<i>Hide source data</i> checkbox
Display order numbers of points	<i>Show numbers</i> checkbox
Display dimension results in the <i>3D View</i>	<i>Show labels</i> checkbox
Specify the label and line color	<i>Color</i> button
Start a new measurement chain on the same objects (clear <i>3D View</i> of all points and empty point list)	<i>Make another</i> button
Export measurements in a CSV or XML file	<i>Export</i> button
Export measurements to SolidWorks	<i>Export to SolidWorks</i> button ¹
Return to the original <i>Measures</i> tab	<i>Measurements</i> link in the upper part of the panel

After you click *Apply*, the application will return to the original *Measures* panel and will display a list of all saved measurements along with editing and deletion options.





Figure 115: Linear measurement.

10.3.2 Geodesic Distance

Geodesic distance is defined as the length of the shortest path over a surface between several given points. Click the  button in the *Measures* panel and select a point-cloud scan or model to start using the tool.

Working with geodesic measurements is similar to working with linear measurements (see [Figure 116](#)). Calculation of the shortest path is a time-consuming process that is accompanied by a progress-bar window. Also keep in mind that the shortest path between different surfaces or disconnected parts of the same surface is not defined. Therefore, the program will display an error if you select points on parts of a surface that are not connected to each other.

Note: The geodesic algorithm is complex, and computations for a large number of vertices may take a long time. Therefore, if you choose the first point on a surface containing more than 150000 points total, the software will warn you that it may be a lengthy operation. You can either use the mesh-optimization algorithm beforehand (see [Mesh Simplification](#)) or delete the parts of the surface that you don't need.

The left panel in this mode is similar to the one for linear-measurement mode (see [Linear Distance](#)).






Figure 116: Geodesic-distance measurement.

10.3.3 Using Sections to Measure Area and Volume

Section is the plane that splits model or scan into two parts. Once created, it can provide you with data on volumes and areas of these parts as well as area and perimeter of the contour, i.e. the line formed as an intersection of the plane with surface.

To create a section of the object, follow the steps:

1. Click the  button in the *Measurements* panel and select one or more models or scans. Models are preferable, since they contain only one surface.
2. Click *Next* and change the section name in the *Name* field as necessary.
3. Select constrain type in the bottom of the panel: *Parallel to* either plane or *Not constrained*
4. Use LMB to mark points on the object's surface:
 1. Mark only one point to specify a plane in parallel with one of the coordinate planes (XOY, YOZ, XOZ).
 2. Mark three points to specify the plane that passes through them exactly.
 3. Mark more than three points to specify the plane that passing through their center of mass.

Figure 117: Orienting new section in *Translate* mode.

5. Redefine your point selections, if necessary, before you use *Create section*; to do so, click the *Clear points* button.
6. Orient plane position as necessary. Choose a tool: *Translate*, *Rotate* or *Scale*. You can either specify numerical values (in the global coordinate system) in the text fields or drag the controls (see [Figure 100](#), [Figure 101](#) and [Figure 102](#)) in the *3D View* window. For instance, enlarge *Scale* to make the plane cross the whole surface.
7. Click *Create section*.
8. Create a series of sections, if desired. To do so,
 1. Click the *Change position* button.
 2. Specify the quantity of planes you want to create by entering the value in *Number of planes* and define the spacing in the *Section spacing, mm* field.
 3. Then select from the *Direction* list one of three directions (*Positive*, *Negative* or *Both*) in which to create the new planes².
9. Save your changes by clicking *Apply*, or click *Measurements* in the upper part of the panel. To save the changes and begin creating the next plane, click *Make another section*.

Once you have created the section, the *Section* panel will display its geometrical information. This information includes perimeter and area for contours as well as area and volume for parts of meshes. Besides displaying geometrical values, Artec Studio will show a list of meshes and contours that allows you to highlight them in the *3D View* window.

10.3.3.1 Switching Selections

A section splits model into two parts (selections). Artec Studio displays volume and area of the one highlighted in red. To display volume or area of another part, click *Invert direction*.

To determine volume or area of the entire model, put down both values and sum up them. You can also move your plane in order to situate it below the model (see the step about orienting plane in the [procedure above](#)). This operation will highlight the entire model in red and display the corresponding calculations.

10.3.3.2 Comparing Values

The *Section* panel allows you to compare contours and mesh parts. To this end, select either two contours or two mesh parts from the list using the **Ctrl** key. Artec Studio will calculate the differences between the areas and perimeters of the contours and the difference between volumes and areas for mesh parts. These values will be available in the lower part of the *Section* panel (see [Figure 118](#)).

² If you want to separate a set of sections into individual ones, click *Convert to multiple sections*. The software will notify you that the operation was successful, and the new objects will appear in the *Measurements* list.




Figure 118: Using sections.

10.3.3.3 Exporting Sections

You can export sections in the following formats: CSV, XML or DXF.

- To export each section individually, enter the *Section* panel and click *Export*
- To export several objects at a time, access the original *Measures* panel, select the checkbox next to desired sections and then click *Export*.

10.3.3.4 Displaying Only Sections

To display only planes and contours, select the *Hide source data* checkbox.

10.3.4 Surface-Distance Maps

You may often find it necessary to compare two models and assess the deviation of their forms. For instance, quality control may require comparison of the original model with the scanned one. You can handle these tasks by using *Surface-distance map*.

Note: Artec Studio can only compare models or scans containing a single surface.






Figure 119: Specifying parameters for surface-distance map calculation.

Use this tool as follows:

1. Click the  button from the *Measures* panel.

2. Select two models for comparison and click *Next*.
3. If necessary, specify the name of the distance map in the *Name* field of the *Measures* panel (see [Figure 119](#)). By default the application creates new distance maps under the names Map 1, Map 2 and so on.

Note: The direction along the normals of the first scan is considered positive; the opposite direction is considered negative. The  button swaps scans.

4. Specify the *Search distance (mm)* value, a maximum range in millimeters for calculating distances between surfaces. You can adjust the actual range subject to this maximum after the calculation finishes.
5. Click *Calculate*. Once the process is complete, the distance map will appear in the *3D View* window and the calculation results in the *Measures* panel (see [Figure 120](#)).










Figure 120: Surface-distance map calculated for two models.

You can analyze the calculation results and the distance map:

- On the basis of the *Search distance* value you entered, Artec Studio calculates the following:
 - *RMS* (root mean square)—the square root of the arithmetic mean of the squared distances
 - *Mean absolute deviation*
 - *Mean of signed distances*

- A distance map is a colored rendering on the particular surface regions. You can read the corresponding distance values and their distribution from the graduated scale and histogram that appear adjacent to the model. The map color changes from  blue, which corresponds to a negative distance, to  red, which corresponds to a positive distance.
 -  Green means the distance between surfaces in this region is close to zero.
 -  Gray highlights any surfaces with distances that exceed the specified *Search distance*.
 -  Orange and  bright blue correspond respectively to distances that are slightly above and below the limiting values of the scale.
- The graduated scale ranges from the positive value to the negative value of the *Error scale*. You can adjust this range using the *Error scale (mm)* slider or text box. Its maximum value cannot exceed the *Search distance*.
- If you move the mouse cursor to a particular point on the map, the exact distance will appear nearby and in the *Distance at cursor* field in the left panel.


To save the current distance map and quit this mode, click *Apply*. To save the current map and create another one, click *Make another map*.

Note: Surface-distance maps are supported by annotations. You can use any saved distance map in *Annotation* mode (see [Annotations](#)).

10.3.5 Annotations

Annotations tools allow you to mark noteworthy surfaces and surface-distance maps. The annotation can include one or more labels, which look like rectangular tags with connecting lines pointing to the corresponding surface elements (see [Figure 121](#)).


To create an annotation,

1. Click the  button in the *Measures* panel, then select one or more scans and click *Next*.

Note: If you want to annotate a previously obtained surface-distance map, select it from the *Distance map* list.

2. Specify the *Annotation name* in the upper part of the panel, or simply proceed with your annotation using the default name.
3. Click **LMB** on the surface's target point in the *3D View* window; the label will appear with a blinking text cursor in the *Annotation text* field of the *Measures* panel.

Note: Artec Studio doesn't enable you to redefine a label's target point. If you inaccurately specify a point on the surface, add a new one (repeat Step 3) and delete the old one (consult the instructions below).

4. Type any desired text for your annotation; this text will appear in both the corresponding field in the panel and the label in the *3D View* window.
5. Repeat Steps 3 and 4 to create a new label. In addition to tagging the surface, each new label will appear in the annotation list of the *Measures* panel (see [Figure 121](#)). You can show or hide labels in the list or change their colors by clicking RMB and selecting the appropriate option from the menu. Alternatively, toggle the selection flag  or click the square button to show/hide labels or change their colors, respectively.




Figure 121: Annotation of a model layered with a surface-distance map.

You can adjust the label position (meaning the rectangular tag, not the target point!) by holding **LMB** in the *3D View* window while moving the mouse cursor. To delete unnecessary labels, use any of the following approaches:

- Select the label in the *3D View* window; its border color will become red (see selected label in [Figure 121](#)). Hit the **Del** key.
- Select the label from the list, then either hit **Del**, or click **RMB** and choose *Delete* from the menu.

To export annotations (more precisely, label coordinates and titles) to a **CSV** or **XML** file, click *Export* in either the *Annotations* or original *Measures* panel. By default, the file name will be the same as the annotation name. Accept it or type in another name of your

choice. To complete the annotation, click *Apply* in the bottom of the *Measures* panel or click *Measurements* in the upper part.

CHAPTER 11

Settings

This chapter describes Artec Studio settings that you can change through the *Settings* dialog. To display this dialog, select *Settings...* from the *File* menu or hit the **F10** key.


The user-adjustable settings are divided into categories under separate tabs. These categories include the following:

- General
- Performance
- Scan
- UI
- Miscellaneous

11.1 General

The *General* tab contains basic Artec Studio settings and includes the following options (see [Figure 122](#)):

- *Project-storage folder*
- *Autosave options*
- *Import/export options*
- *Default import units* and *Default export units*
- *View control settings*

Figure 122: *General* settings page.

11.1.1 Project-Storage Path

Project-storage path is a default path which Artec Studio will use in the project saving dialog (*Saving a Project*). The default location is Windows user's `Documents` folder. You can alter this path by editing the field content or clicking *Browse...* and afterwards specifying the required folder.

11.1.2 Temporary Folder

A newly created and yet unsaved project is stored at the location specified in the *Temporary folder* field. The default path is the Windows temporary folder. To change this folder, use the *Browse...* button or enter a new path in the field.

Artec Studio automatically clears project folder. You can access Windows temporary folder and remove the unwanted projects as necessary.

1. Open the *Explorer* window.
2. Type `%temp%` in the address bar and hit `Enter`.
3. Locate folders that have GUID names in braces `{ }`.

11.1.3 Autosave Options

When the *Save project before starting algorithms* option is enabled, the application will always save your project before running any processing routines. The *Restore loading state of scans after algorithms finish* checkbox allows you to control loading of selected scans once the algorithm is complete. Artec Studio always loads selected scans into memory before launching an algorithm; if a scan is not loaded at this point, the application will automatically save it to the hard drive after the algorithm finishes, freeing up memory. For more information about autosaving projects, see *Autosaving a Project*.

11.1.4 Registering Artec Studio as Default Viewer

Artec Studio supports various file formats. To make it the default application for supported formats, click *Change...* and select the formats you want the application to open by default (see *Figure 123*):

<code>*.sproj</code>	Project files for Artec Studio
<code>*.scan</code>	Single-scan export/import format
<code>*.ply</code>	Format for saving polygonal models obtained using 3D scanners
<code>*.stl</code>	3D-model export format for fast-prototyping equipment
<code>*.wrl</code>	Virtual-reality files in VRML 1.0 and VRML 2.0 format
<code>*.obj</code>	Texturized 3D models; Wavefront OBJ format




Figure 123: Making Artec Studio the default application for various file types.

For more information on importing and exporting files, see *Exporting Models, Scans and Point Clouds* and *Importing Models and Scans*.

11.1.5 Opening Files

Artec Studio can serve as the default viewer for SPROJ, SCAN, PLY, STL, OBJ and VRML (*.wrl) formats. To open each subsequent file in a new application window, select *Open new model in a new window*. If the *Open new model in the same window* option is selected, Artec Studio will use existing windows to display subsequent files.

11.1.6 Surface-Consistency Detection During Import

The *Surface-consistency detection during import* option instructs Artec Studio to examine imported files for defects. Select one of the following parameters:

Do not detect. Disable automatic surface-consistency detection.

Detect & ask. Enable automatic surface-consistency detection; Artec Studio will prompt you to start defect correction.

Always detect & fix. Enable automatic surface-consistency detection and correction.

11.1.7 Model Placement

When exporting, the application can automatically center scans and models on the origin of the axis grid. To enable this option, select the *Move model to origin of the axis grid during export* checkbox. If the checkbox is cleared, the application will save the model's current placement on the axis grid when exporting surfaces.

11.1.8 Base Removal for Leo Scans

The *Enable automatic base removal* option in the *Scan* panel only works for scans from Eva and Spider and other handheld scanners connected to computer. To enable automatic base removal for scans from Leo, select the *Launch base removal for Leo scans* checkbox. The algorithm will start after the application *imports that project*.

11.1.9 Point-Cloud Export

The *Export point clouds to PTX with merged sections* ensures a successful import of the exported files in third-party software products. See [Merging Sections](#).

11.1.10 Units

In Artec Studio, all software operations use millimeters as the default measurement unit. If you need to import or export a model in other units, change the settings under *Units*. The software applies these settings only when importing or exporting a model or a point-cloud scan.

Selecting the *Show unit-selection dialog on import* option enables you to choose on import which measurement unit was used to create the scan (see [Figure 124](#)). Artec Studio supports units of millimeters, centimeters, inches and meters. If in most cases you import data in a particular measurement unit, but you might occasionally import models created using another unit, you should enable the *Only if object is less than __ mm* option and enter the threshold value. In this case, the unit-selection dialog will only appear if the model dimensions are below the threshold value.

The *Default import units* and *Default export units* dropdown lists determine the default measurement units for importing and exporting models. When exporting point-cloud scans (Artec point cloud and Leica Geosystems Cyclone Point Cloud), application will ignore the specified units. See [Exporting Point Clouds](#) for details.




Figure 124: Unit-selection window.

11.1.11 View-Control Settings

Artec Studio allows you to use `Scroll wheel` to zoom in on the model in the *3D View* window. You can take advantage of this capability in two ways:

- Clear the *Mouse-wheel zoom to cursor* checkbox to enable zooming to the center of the screen. In this case, you must keep the target area in the screen center and readjust its position from time to time.
- Select the *Mouse-wheel zoom to cursor* checkbox to enable interactive zooming to the mouse-cursor position. In this mode, you need only keep the cursor on the target area while spinning `Scroll wheel` forward and backward.

11.2 Performance

The following parameters are user adjustable by way of the *Performance* tab (see [Figure 125](#)): multithreading, memory usage, command-history storage, compression levels for stored data, texture-recording mode and *Real-time fusion* settings.




Figure 125: Performance-tab options.

11.2.1 Multithreading

On computers that feature multicore processors, Artec Studio uses all cores by default. If you would like to limit the number of cores the application employs, clear the *Use all available processor cores* checkbox and enter the number of concurrent threads manually.

11.2.2 Memory

Under *Memory*, the *Settings* dialog shows RAM availability. If the current amount is insufficient, you can try to increase it by clicking the *Compact memory* button. Artec Studio will clear the command history and attempt to optimize memory allocation. Clicking *Compact memory* won't permanently delete the history, but simply unload it from memory. The *Undo* command will reload it. For more information about saving projects, see [History of Project Changes](#).

Note: You cannot unload the command history from memory if you haven't saved the project. Save the project and try again.

Artec Studio automatically optimizes memory allocation after each algorithm finishes. This function is handled by the *Compact memory after algorithm completes* checkbox. In contrast to the button, it doesn't unload command history.

11.2.3 Command History

Under the *Command history* section you can limit the amount of history Artec Studio will save. By default, the maximum values are set as a certain number of commands and size on disk (in MB). If necessary, you can clear the *Max history length* checkbox. Doing so means the program will save all history for each project from the beginning. You can clear the project history by clicking the *Clear command history* button; the application will prompt you to confirm this action.

Note: Once you clear the history, you cannot return to an earlier project version.

11.2.4 Data-Compression Level

The *Data-compression level* slider allows you to change the amount of file compression when saving data. Higher compression saves disk space, but loading and saving these scans takes longer.

Important: Maximum compression settings are optimized to ensure that the shape of your models and frames will be preserved. Insignificant deformation may, however, occur. Change the slider position as necessary.

Table 15: File compression in Artec Studio.

Slider Position	Type	Compatibility	Output File Size
Left	No compression	All versions	Large
Middle	Medium compression (lossless)	All versions	Medium
Right	Maximum compression (lossy)	Artec Studio 12 and later	Small

11.2.5 Texture-Recording Mode

By default (*Automatic texture recording* enabled), Artec Studio doesn't capture texture for every frame. You can, however, manually specify the frequency for capturing texture frames by using the *Record texture every __th frame* spinner.




Figure 126: Spinner for adjusting capture frequency of texture frames.

11.2.6 Real-Time Fusion Settings

Real-time fusion offers two optional settings (see *Scanning With Real-Time Fusion*):

Voxel size (mm). The fusion resolution. It affects the algorithm's performance and quality. The lower the value, the sharper the shape of the model. Note that specifying low values may produce noisy surfaces.

Buffer size. Amount of GPU memory employed to reconstruct a Real-time fusion object in the scene. The default value depends on the computer's available GPU memory. Note that Artec Studio may fail to correctly determine the upper limit if your computer has an Intel HD Graphics card. The more memory you have, the larger the scene you can scan in Real-time fusion mode. The slider doesn't define the total finite memory size, however; the algorithm employs system memory (RAM) when GPU memory is consumed.

Note: Avoid altering the *Buffer size* unless you have started noticing artefacts while scanning.

11.3 Scan

The *Scan* tab allows you to edit the parameters that the application uses both while scanning and while postprocessing the results (see *Figure 127*).




Figure 127: Scan-settings tab.

11.3.1 Algorithm Settings

Artec Studio automatically selects and displays settings for each scanner type in the *Current scanner type* dropdown of the *Settings* dialog and in the *Preset* dropdown of the *Tools* panel. If it fails to correctly identify your scanner type or you process scans from different scanners, select the appropriate scanner type manually. To reset all settings to their default values, click *Reset to defaults*.

Current user preset allows you to save the current parameter values in the *Tools* panel. By selecting a saved preset, you can change all settings at once. Note that this option applies only to the selected device type.

11.3.2 Photogrammetry Settings

Photogrammetry settings allow you to define the target size. *Inner target diameter (mm)* corresponds to the diameter of the white circle in the middle of the target; *Outer target diameter (mm)* corresponds to the outer diameter of the target's black ring. The most popular targets have diameters of 6 mm and 12 mm; the values 5 mm and 10 mm correspond to the *Scan Reference* target. See *Target-Assisted Scanning* for details.

The *Disable hybrid tracking for .obc* checkbox ensures that tracking is purely based on targets. Select the checkbox if you don't want the texture and geometry features to assist target scanning (*Using Photogrammetry Solution (Scan Reference)*).

11.3.3 Capture

The *Capture* section covers settings related to the trigger button for the Artec MHT scanner, as well as the scanning-depth range and individual frames acquired during the scan.

The first option is the *Trigger mode for device button* checkbox, which changes the button behavior on the Artec MH and Artec MHT scanners. For details regarding these buttons, see [Scanner Buttons and Capture Modes](#).

The scanner has a defined depth range. If it's too close to the object, it may fail to capture all or part of the object. On the other hand, if the scanner is too far away, various types of 3D “noise” will appear in the scene, complicating the postprocessing effort and affecting the final results. Therefore, you should position the scanner as close as possible to the object without crossing the cutoff plane. Default settings for each 3D scanner contain minimum and maximum limits within which you can position the cutoff planes. The scanner model determines these values. If you are using an Artec L scanner or 3D-sensor and high accuracy is of lesser importance, however, you can adjust the depth boundaries manually, allowing you to scan closer to or further from the object than the recommended distances indicate. To this end, mark the *Override default depth range* checkbox and enter new range values.

Warning: Redefining the depth range may reduce accuracy.

11.3.3.1 Scan Using Auto-Alignment

The *Scan using auto-alignment* option is enabled by default and is covered in the [Resuming Scan After Lost Tracking](#) and [Auto-align new scans with those marked in Workspace](#) sections. The application's behavior varies depending on this option's value, as [Table 16](#) shows.

Table 16: Application behavior with option enabled and disabled.

Scan Using Auto-Alignment	<i>On</i>	<i>Off</i>
Tracking Mode	Geometry + Texture	Geometry or Geometry + Texture
Audio Notification?	Yes (see Audio Notification)	Yes
Message in 3D View	Searching for position: Point 3D Scanner at the object to continue	Tracking lost: Repeat scan using slower motions or additional features
Instructions	Direct the scanner at any already captured region with sufficient texture, maintaining the original scanner orientation relative to the object	Direct the scanner at the last captured region
Data Recording	Handled in a newly created scan	Handled in the same scan

11.3.4 Misalignment Detection

In some cases, Artec Studio may incorrectly determine relative frame positions, resulting in misalignment. When this error occurs, you must restart the scanning session and remove the misaligned scans. Alternatively, you can attempt to fix the misalignment by breaking the scan into several segments. Further information about addressing this problem by dividing scans is available in *Separating Scans*. To prevent possible misalignment and improve your scanning experience, Artec Studio features a *Misalignment detection for EVA scanner* setting that functions during the scanning process. However, if you have difficulty maintaining the tracking when scanning particular objects, you can disable this setting.

Options are as follows:

- *On (Hybrid tracking only)*. The default value, option works for *Geometry + Texture tracking* mode.
- *On*. The option works for all tracking modes, including *Geometry*.
- *Off*. The option is turned off for all trackers.

11.3.4.1 Default Capture Settings

Artec Studio allows you to change the characteristics of single-frame surfaces as the scanner captures them. To change the default parameters, clear the *Use default capture settings* checkbox and change the settings manually in the displayed window. The options below are user adjustable:

Important: We recommend using default settings. Poorly chosen settings may reduce data quality.

Triangles step. Point density for a frame mesh.

Minimum object size. The smallest object scanned, by number of polygons.

Length filter threshold. Triangle-filtration threshold by edge length (maximum possible size in mm).

Interpolate. Use interpolation for parts of surface that are missing data.

Max interpolated length. Maximum size of areas to be interpolated (in mm).

Max angle. Triangle-filtration threshold by maximum angle (in degrees) between the triangle's normal and the camera's sight vector.

Geometry registration threshold. The higher the threshold, the stricter the quality requirements for the geometry being scanned. Therefore, determining the proper geometry in the scene is more difficult in such cases. Subsequently, Artec Studio runs geometry registration less frequently, making way for texture registration. Works with *Geometry + Texture tracking* only, values are between 0 and 1.

11.4 UI

The *UI* page allows you to edit user-interface settings (see [Figure 128](#)) and covers the following categories:

- Audio notification
- Workspace colors
- Warnings
- Surfaces that Artec Studio displays during a scan




Figure 128: Interface-settings tab.

11.4.1 Audio Notification

Sometimes, automatic alignment in real time is impossible during the scanning process, and the program is unable to align the previous frame with the current one (see *Resuming Scan After Lost Tracking*). When this situation occurs, Artec Studio issues an audio warning that stops once you reposition the scanner and the software again finds its location in 3D. To enable or disable this feature, use the *Enable audio warnings in scan mode* checkbox. A standard “beep-sound” is the application’s default sound. You can choose any WAV file as the warning sound. To this end, click the ... and specify a file path.

See also:

Warnings in Tools and Editor.

11.4.2 Workspace Colors

Artec Studio automatically chooses display colors for newly created scans. You can select any of the standard palettes:

- Full palette
- Light colors
- Web-safe colors
- Random colors
- Monochrome

11.4.3 Warnings

The *Warnings* options allow you to toggle certain notifications. They include the following:

11.4.3.1 Startup Checks

Show OpenGL compatibility issues on startup. Artec Studio requires *OpenGL* version 2.0 and some *OpenGL* extensions to function properly; your PC may or may not currently support these capabilities. Selecting this option activates a display window on startup containing information regarding possible missing extensions.

11.4.3.2 Warnings in Tools and Editor

If you are familiar with these algorithm peculiarities, you may disable these notifications.

Texture-healing brush: warn if over __ polygons selected. This checkbox instructs the application to display a warning if you exceed the maximum number of polygons to be inpainted at one time. This limit reduces the potential for the computer to hang up. Specify a suitable value for your system, or clear this checkbox if you require no warnings of this kind.


Warn about texture removal by Defeature brush. Be ready that *Defeature brush* won't preserve texture in the corrected areas, so the application notifies you of this.

Recommend Sharp fusion for Spider scans. Artec Studio will recommend switching from *Smooth fusion* to *Sharp fusion* for scans from Spider, since the latter yields more detailed models.

Warn about scans in transformation tool. We advise that you refrain from repositioning source scans as it may result in the incorrect texture application. The message may remind you about it.

Inform about texture frames for Reduce glare. Since this option in the *Texture* panel requires many texture frames, Artec Studio will advise you to adjust frame-recording settings.

Play a sound on completion of algorithm lasting more than 30 seconds. This setting allows you to get distracted while the application is busy running algorithms and performing commands. Once the application finishes any of these processes, it chimes.

Inform about locked scans. Artec Studio will remind you that some of the scans selected for *Global registration* also have  marks (see *Workspace Columns*). This message allows you to unlock them or run the algorithm without changing scans' status.

11.4.4 Displaying in 3D View Window

You can change the way you see surfaces and points during the scanning process, adjust their colors as well as the background color, and specify the mode for frame playback. To these ends, use the settings below:

11.4.4.1 Display

Last scanned surfaces. Number of visible surfaces most recently captured that will appear in *3D View* during scan.

Visible surfaces. Total number of visible surfaces displayed during scan (equal to the number of most recently scanned surfaces plus the number of key frames to display).

Disable smart simple rendering mode. Smart simple rendering mode ensures that 3D content is rendered without simplification if computer resources allow it. Once the system experiences lags, it automatically turns on simplification.

Polygon limit for conventional simple rendering mode. Maximum number of polygons in the viewport beyond which Artec Studio will switch to simple rendering mode during 3D navigation.

Point-cloud polygon limit. If the polygon count of a point-cloud surface exceeds the specified value, Artec Studio will render a simplified copy of this surface having no more than specified polygons.

Spherical target diameters. List of diameters of the target spheres used during scanning with Ray. Use semicolon ; as a delimiter between values in millimeters in the field.

Point size. Number of pixels for rendering each point when using the *Points* or the *Points and solid* rendering mode.

Animate movements. It shows movement of the 3D data when Artec Studio repositions or reorients it. Disable this option on slow computers.

11.4.4.2 Colors

Last. Color of last scanned surfaces.

Registered. Color of correctly aligned surfaces.

Preview. Color of surfaces in preview mode.

Dropped. Color of unaligned (and thus dropped) surfaces.

Key frames. Color of key frames (surfaces).

11.4.4.3 Screenshots

You can specify the default screenshot size in pixels (see *Saving Screenshots*):

- *Width*
- *Height*

If your system configuration is incompatible with the specified settings, Artec Studio will save a screenshot of the maximum possible size.

11.4.4.4 Playback

See also:

Selecting Scans and Models

Repeat. Continuously loop the frame sequence in the surface-view mode of the *Workspace* panel.

FPS. Speed (in frames per second) at which frames appear during playback.

11.4.4.5 Background

Color. Background color; the application may automatically alter this color in certain modes, such as *X-ray*.

Dropped color. Background color when misalignment occurs while scanning.

Texture. Display patterned (*chessboard pattern*) or plain background.

Gradient. Gradient or monochrome background color.

Background for screenshots. Application will use this background color when *saving screenshots*, the actual background color will remain unaltered.



Figure 129: Example of altered background.

11.4.4.6 Welcome Screen

Don't show. Disable the welcome screen.

11.4.4.7 Autopilot

Don't show greeting screen. Disable the *Autopilot* screen showing the steps to pass in this mode

11.5 Miscellaneous

11.5.1 Usage Information

You can help us improve the quality and performance of Artec Studio by allowing us to collect and send usage information to Artec Group. This information will not be used to identify you, and it excludes your project data, 3D surfaces, textures and any other data that you obtain and process using Artec Studio. By default, the *Collect and send anonymous usage data to Artec* checkbox is selected. We recommend leaving this checkbox marked so we can better improve the application.

When installing Artec Studio, you can decide whether you want it to collect and send usage data. The same checkbox described above also appears in the final installation dialog (see [Figure 18](#)).




Figure 130: Miscellaneous-settings tab.

11.5.2 Language

The Artec Studio interface supports several languages:

- *Auto*—automatic language selection on the basis of system settings
- *Chinese (Simplified)*
- *Chinese (Traditional)*
- *Czech*
- *English (U.S.)*
- *French*
- *German*
- *Italian*
- *Japanese*
- *Korean*
- *Polish*
- *Russian*
- *Spanish*

To switch between languages, choose the one you want and click *OK*. The program will then prompt you to restart. If you agree, the application will restart automatically using the newly selected interface language. If you choose not to restart, the changes will take effect the next time you start the application.

Note: To change the language, Artec Studio must restart.

Scanner Calibration and Correction

The Diagnostic Tool is a special utility that enables you to calibrate Artec 3D scanners and correct an existing calibration. In general, calibration is the process of checking and adjusting a scanner's measurements by comparing them with the standard (etalon) values. Every Artec scanner is delivered pre-calibrated.

In some cases, owing to careless handling or transportation (jolts, accidental drops or some other reason), the scanner may fail to capture surfaces properly. The scanned surfaces may only be partially reconstructed or may contain holes (for example, the results of bad reconstruction are noticeable on the blue surface in [Figure 135](#)). You can resolve these issues by correcting or calibrating the scanner.

Depending on the scanner model, the Diagnostic Tool can operate in one of the three working modes:

- Correction for Artec MHT, Artec MH, Artec L and Artec EVA scanners
- Correction for Artec Spider scanner
- Calibration of Artec Spider scanner

Note: Calibration is available only for Artec Spider scanners.

12.1 Suggestions for Use

Correction differs from calibration in that it preserves the current calibration: it only changes the correction ratio so as to enable good reconstruction.

Important: Application of the correction does not guarantee that captured geometric shapes and linear measurements will be accurate. Use this procedure as a temporary measure until calibration is performed.

Table 17: Correction versus calibration.

Mode	Characteristics	Speed	For Spider?	For EVA, L, MHT?
Correction	Inexact	Fast	Yes	Yes
Calibration	Exact ¹	Prep required	Yes	No

12.2 Launching Diagnostic Tool

To launch the Diagnostic Tool, first ensure that the scanner you intend to diagnose appears in Artec Installation Center as either *On loan* or *Activated*. You can launch the tool either through the *Start* menu by clicking *Start* → *All Programs* → *Artec Group* → *Artec Studio* → *Diagnostic Tool* or in Artec Studio by selecting the *Run Diagnostic Tool* command from the *File* menu.

If you have several scanners connected, select the appropriate one from the dropdown list.




Figure 131: Diagnostic Tool window.

The utility window contains three sections: the *3D View* panel, the right panel and the

toolbar (see [Figure 131](#)).

12.3 Scanner Correction

Important: Apply correction sparingly as a temporary measure until calibration is performed.

12.3.1 Correcting Field of View for EVA, MHT, MH and L Scanners

The Artec EVA, Artec MHT, Artec MH and Artec L scanners only allow you to correct their current calibration data on field of view.




Figure 132: Artec EVA correction results.

1. Launch the Diagnostic Tool as [Launching Diagnostic Tool](#) describes.
2. Select the scanner you want to diagnose.
3. Click *Start diagnostic* or press the ► button. The scanner will start the preview, a range meter will appear in the *3D View* window and another panel will appear on the right showing a 2D camera preview.
4. Direct the scanner at the right angle to a flat, light (but not shiny) monochrome surface (e.g., a wall or floor) from a distance of 650–700 mm for an Artec MHT,

Artec MH or Artec EVA scanner or a distance of 850–900 mm for an Artec L scanner. The tool will render the surface in blue in the *3D View* window.

Note: If the rendered surface is not flat and contains holes, the correction is worth performing.

5. Click *Start correction* or press the ► button on the scanner. In addition to the blue surface, a yellow surface will appear in the *3D View* window. Blue corresponds to the surface captured using the original calibration data; yellow corresponds to the surface captured using corrected calibration data.
6. Two indicators in the right panel can help you assess the surface quality (green stands for good results, yellow for satisfactory and red for unsatisfactory). If the corrected (yellow) surface has no holes and is sufficiently flat, and if the correction results meet your expectations, click *Commit* or press the ► button on the scanner. Otherwise, click *Rollback* or press ■ on the scanner.

12.3.2 Correcting Calibration Data for Spider

Correction for Artec Spider differs slightly from correction for Artec MHT and Artec EVA scanners.




Figure 133: Artec Spider correction process.

1. Launch the Diagnostic Tool as *Launching Diagnostic Tool* describes.
2. Select Artec Spider from the dropdown list.
3. Click *Start diagnostic* or press the ► button; the scanner will start the preview, a range meter will appear in the *3D View* window and another panel will appear on the right showing a 2D camera preview.
4. Direct the scanner at the right angle to a flat light monochrome surface (e.g., a wall) from a distance of 190–270 mm. The tool will render the surface in blue in the *3D View* window.

Note: If the surface, when captured from a distance within the suggested range, fails to render as flat or contains holes, correction is worth performing.

5. Place the scanner on a desk or attach it to a tripod, keeping a distance of about 190 mm from the flat surface (see the range meter in the *3D View* window).
6. Click *Start correction* or press the ► button on the scanner. A red mark will appear on the range meter.
7. Move the scanner smoothly toward the flat surface such that the histogram peak coincides with the red mark on the range meter (see *Figure 134*).
8. Look for a new red mark to appear higher on the range meter. Smoothly move the scanner away from the flat surface to approach the red mark.
9. Repeat Step 8 three more times. Once you finish, the calculation will start. A yellow plane that corresponds to the surface you captured using the corrected calibration settings will then appear in the *3D View* window (see *Figure 135*).
10. If the yellow surface has no holes and is sufficiently flat, and if the correction results meet your expectations, click *Commit* or press the ► button on the scanner. Otherwise, repeat Steps 7–9, click *Rollback* or press ■ on the scanner. Two indicators on the right panel can help you assess the surface quality (green stands for good results, yellow for satisfactory and red for unsatisfactory).

12.4 Spider Calibration

To carry out the calibration, you will need the following additional equipment: a calibration rig, a scanner stand and a pattern. Assembly instructions for the scanner stand and calibration rig appear in *Assembling the Scanner Stand* and *Assembling the Calibration Rig*, respectively.

1. Unfold the pattern and place it on a desk or any hard, planar surface.
2. Align the scanner stand with the rectangle marked on the pattern, paying close attention to the orientation of the slots in the stand cover (see *Figure 136*).




Figure 134: Artec Spider scanner's position and corresponding distance on the range meter.

Approaching the read mark (at the top), reaching the required distance (at the bottom).




Figure 135: Artec Spider correction results.




Figure 136: Scanner stand resting on a pattern.




Figure 137: Placing Artec Spider on the stand




Figure 138: Calibration rig, pattern and scanner stand with Artec Spider.

3. Place the scanner on the scanner stand, making sure that you insert the three scanner stems in the three slots of the stand cover (see [Figure 137](#)).
4. Set the calibration rig on the pattern, turning its marker side toward the scanner as [Figure 138](#) shows.
5. Launch the Diagnostic Tool as [Launching Diagnostic Tool](#) describes.

Note: You should conduct the calibration only after the scanner has warmed to the optimal temperature.

6. Click *Start calibration*. A dialog box will open (see [Figure 139](#)); enter the serial number of your calibration rig (it appears on the board). If the scanner temperature is outside the optimal range—for example, you just connected the device to a power outlet—the tool will notify you of this condition (see [Figure 140](#)). We advise against clicking *Skip* and instead recommend waiting for the Artec Spider to reach its optimal temperature.
7. Place the rig in its initial position such that the front edge of its base coincides with the color line numbered 1 on the pattern. As you do so, also keep an eye on the *3D View* window for a red plane (current position) and a green plane (target position)—see [Figure 141](#). Once the red plane coincides with the green one, stop moving the rig and wait for the scanner to capture the plane.
8. Wait for the tool to instruct you to move the rig to the next position on the pattern;

the number for that position will appear on the screen. Move the rig and again wait for the scanner to capture the plane.

9. Repeat the preceding step for the remaining positions sequentially. Depending on the version of your calibration kit, the pattern will have 11 to 15 positions.
10. Once you have captured the last position and the calculations have concluded, a message will appear prompting you to either overwrite the existing calibration or keep the current one. Before you decide, direct the scanner at a flat, nonglossy surface (e.g., a piece of paper) from a distance of about 200 mm. Assess the quality of the reconstructed surface and check for any holes.
11. Click *Yes, apply the calibration* if no holes appear on the surface and you are satisfied with the reconstruction results. To reject the new calibration, click *No, keep the old one* (see Figure 142).




Figure 139: Entering serial number of calibration board.




Figure 140: Warming up the scanner.

12.5 Notes Regarding Scanner-Calibration Files

Calibration and correction results reside in files that you can access as follows. Their location is

C:\Users\%name%\AppData\Roaming\Artec\Artec Installation Center\Devices\SP.00.00000000.

Here, %name% is the current user folder and SP.00.00000000 is the folder corresponding to the scanner serial number. Note the following information regarding calibration and correction.

- Once you apply correction results, the software will create an ACD file.




Figure 141: Moving calibration rig to position number 1.




Figure 142: Assessing calibration results.

- Once you apply calibration results, the software will create `ACD` and `CORR` files.
- All newly created files have names of the form `YYYYMMDD_HHMMSS`, with the characters corresponding to the date and time of the file's creation.
- Original `ADD` and `CORR` file names are based on the scanner serial number and have the form `SP.00.00000000`.

Note: You can restore the initial calibration by removing the `ACD` and `CORR` files whose names have the form `20131121_101010`.

Note: If you use the scanner on several computers, you need not recalibrate it on every one. Simply copying the `ACD` and `CORR` files to the above-mentioned folder on each computer may be sufficient.

12.6 Assembling the Scanner Stand

The scanner stand comes unassembled with Artec Spider and consists of five parts (see [Figure 143](#)): two side walls, one front and one back wall (these parts are identical, however), and a cover. Before beginning assembly, lay them all out as [Figure 143](#) shows. Then follow these steps:




Figure 143: Parts of the scanner stand.

1. Raise the two side walls to the upright position, as [Figure 144](#) shows. Noting carefully the orientation of the T-shaped slot, install the front wall to the side walls using the two pairs of hooks. Press the front wall and slide it down against the stop. Make sure the three walls are properly aligned with each other.
2. Install the back wall in the same way (see [Figure 145](#)).

3. Paying attention to orientation of the slots, install the cover using the upper hooks of the side walls (see [Figure 146](#)).
4. Press your thumbs against the T-shaped holes on the cover and shift it toward the back wall until you hear a click (see [Figure 147](#)).




Figure 144: Assembling the front wall.




Figure 145: Assembling the back wall.

The scanner stand is now ready to use.

Note: To disassemble the stand, release the detents in the cover's T-shaped slots (see [Figure 143](#)) using a thin object like a ballpoint pen. Repeat the assembly steps in reverse order (from [Figure 147](#) to [Figure 144](#)), moving the parts in the opposite directions.




Figure 146: Mounting the cover.




Figure 147: Latching the cover.

12.7 Assembling the Calibration Rig

The calibration rig comes only with Artec Spider and consists of the base and the board. To assemble the rig, follow these instructions:

1. Press the hinge of the base against your forefingers.
2. Unfold the bent leaves of the base, pressing on their edges with your thumbs.
3. Insert the board into the slot, as [Figure 148](#) shows.




Figure 148: Assembling the rig.

CHAPTER 13

Hot Keys

13.1 Scanning

Open <i>Scan</i> panel	F7	Anywhere exc. modal dialog
Toggle between <i>Preview</i> and <i>Record</i> modes	Space	<i>Scan</i> panel
Open <i>Multicapture</i> panel	F8	Anywhere exc. modal dialog

13.2 Workspace

Select one scan and deselect the rest	Ctrl+Alt+LMB	<i>Workspace</i> panel
Select one scan and deselect the rest	Ctrl+LMB	<i>Workspace</i> panel, first column
Select/deselect scan	Shift+Alt+LMB	<i>Workspace</i> panel
Select all scans/models or frames	Ctrl+A	<i>Workspace</i> panel
Deselect all scans/models or frames	Ctrl+D	<i>Workspace</i> panel
Select/deselect the highlighted scan	Space	<i>Workspace</i> panel
Invert selection of scans/models	Ctrl+Alt+A	<i>Workspace</i> panel
Select only key frames	Ctrl+K	<i>Workspace</i> panel → Surface list
Select only textured frames	Ctrl+J	<i>Workspace</i> panel → Surface list
Rename scan/model	F2	<i>Workspace</i> panel
Start/stop playback scan frames	Ctrl+P	<i>Workspace</i> panel
Delete selected frames/scans	Del	<i>Workspace</i> panel (including surface list)

13.3 Save, Export and Import

Create new project	Ctrl+N	Anywhere exc. modal dialog
Save project	Ctrl+S	Anywhere exc. modal dialog
Open existing project	Ctrl+O	Anywhere exc. modal dialog
Open existing project with scans unloaded (to save memory)	Ctrl+Shift+O	Anywhere exc. modal dialog
Import 3D files	Ctrl+I	Anywhere exc. modal dialog
Export meshes	Ctrl+Shift+E	Anywhere exc. modal dialog
Clear command history	Ctrl+Alt+H	Anywhere exc. modal dialog
Save screenshot of <i>3D View</i> window	Ctrl+Shift+S	Anywhere

13.4 Viewing 3D Content

Fit to view	F	3D View window
Place coordinate origin to the viewpoint center (Home)	H	3D View window
Display/hide coordinate axis grid	G	3D View window
Set rotation center to the object's center of mass	Ctrl+Shift+C	3D View window
Set rotation center to the origin of axis grid	Ctrl+Shift+M	3D View window
Change rendering mode to <i>Texture</i>	Ctrl+Alt+1	3D View window
Change rendering mode to <i>Scan color</i>	Ctrl+Alt+2	3D View window
Change rendering mode to <i>Surface color</i>	Ctrl+Alt+3	3D View window
Change rendering mode to <i>Max error</i>	Ctrl+Alt+4	3D View window
Turn on/off lighting	L	3D View window
Display/hide normals	N	3D View window
Display/hide boundaries	B	3D View window
Display/hide texture boundaries	Shift+B	3D View window
Toggle between perspective and orthogonal views	5 (numpad) or Ctrl+5	3D View window

13.4.1 Switching Viewpoint

To front	1 (numpad) or Ctrl+Shift+1	3D View window
To back	Ctrl+1	3D View window
To left	3 (numpad) or Ctrl+Shift+3	3D View window
To right	Ctrl+3	3D View window
To top	7 (numpad) or Ctrl+Shift+7	3D View window
To bottom	Ctrl+7	3D View window

13.5 Editor

Activate <i>2D selection</i> mode	Shift+Alt+1	<i>Editor</i> → <i>Eraser</i>
Activate <i>3D selection</i> mode	Shift+Alt+2	<i>Editor</i> → <i>Eraser</i>
Activate <i>Rectangular selection</i> mode	Shift+Alt+3	<i>Editor</i>
Activate <i>Lasso selection</i> mode	Shift+Alt+4	<i>Editor</i>
Activate <i>Cutoff-plane selection</i> mode	Shift+Alt+5	<i>Editor</i>
Activate <i>Base selection</i> mode	Shift+Alt+6	<i>Editor</i> → <i>Eraser</i>
Display control for adjusting cutoff plane	Alt	<i>Eraser/Defeature brush</i> → <i>Cutoff-plane selection</i>
Move cutoff plane	Ctrl+Shift+Scroll	<i>Eraser/Defeature brush</i> → <i>Cutoff-plane selection</i>
Change tool size	Ctrl+[and Ctrl+] or Scroll Wheel	<i>Editor</i> panel → any tool
Select the entire surface below the cutoff plane	Ctrl+Q	<i>Eraser/Defeature brush</i> → <i>Cutoff-plane selection</i>
Clear selection of 3D regions	Ctrl+Alt+LMB	<i>Editor</i>
Invert selection	I	<i>Editor</i> panel → any tool → <i>3D View</i>
Delete selected region	Delete	<i>Editor</i> → <i>Eraser</i>

13.5.1 Transformation Tool

Enable <i>Translate</i> transformation	T	<i>Editor</i> → <i>Transformation</i>
Enable <i>Rotate</i> transformation	R	<i>Editor</i> → <i>Transformation</i>
Enable <i>Scale</i> transformation	S	<i>Editor</i> → <i>Transformation</i>
Translate (rotate/scale) the model along (around/in direction of) X axis	X	<i>Editor</i> → <i>Transformation</i> → any mode → <i>3D View</i>
Translate (rotate/scale) the model along (around/in direction of) Y axis	Y	<i>Editor</i> → <i>Transformation</i> → any mode → <i>3D View</i>
Translate (rotate/scale) the model along (around/in direction of) Z axis	Z	<i>Editor</i> → <i>Transformation</i> → any mode → <i>3D View</i>

13.6 Aligning Scans

Display aligned scans/models	1	<i>Align</i> panel
Display unaligned scans/models	2	<i>Align</i> panel
Display all scans selected for alignment	3	<i>Align</i> panel
Manually align scans	Shift	<i>Align</i> panel
Switch between point sets/pairs	Space and Backspace	<i>Align</i> panel → points
Confirm creation of point set	Space	<i>Align</i> panel → <i>Complex</i>

13.7 Starting Tools, Modes and Dialogs

Open <i>Autopilot</i>	F9	Anywhere exc. modal dialog
Start automatic processing (don't confuse with <i>Autopilot</i>)	Ctrl+G	Anywhere exc. modal dialog
Open <i>Tools</i> panel	Ctrl+T	Anywhere exc. modal dialog
Open <i>Align</i> panel	Ctrl+L	Anywhere exc. modal dialog
Open <i>Fix holes</i> panel	Ctrl+B	Anywhere exc. modal dialog
Open <i>Repair</i> panel	Ctrl+R	Anywhere exc. modal dialog
Open <i>Measures</i> panel	Ctrl+M	Anywhere exc. modal dialog
Open <i>Texture</i> panel	Ctrl+U	Anywhere exc. modal dialog
Open <i>Editor</i> panel	Ctrl+E	Anywhere exc. modal dialog
Start <i>Eraser</i> tool	E	<i>Editor</i> panel
Start <i>Defeature brush</i>	D	<i>Editor</i> panel
Start <i>Positioning</i> tool	P	<i>Editor</i> panel
Start <i>Transformation</i> tool	T	<i>Editor</i> panel
Start <i>Smoothing brush</i>	S	<i>Editor</i> panel
Open web manual	F1	Anywhere
Open local User Guide file	Ctrl+F1	Anywhere
Call <i>Settings</i> dialog	F10	Anywhere exc. modal dialog
Show/hide <i>Workspace</i> panel	F11	Anywhere exc. modal dialog
Show/hide <i>Log</i> window	Ctrl+Alt+L	Anywhere exc. modal dialog

CHAPTER 14

Conventions and Acronyms

Portions of this user guide are highlighted to draw your attention. For example,

Note: Important information appears in specially formatted paragraphs.

The following examples illustrate our conventions:

- Panel and element names that appear in the application window use italics: e.g., *Workspace*, *File* and *Texture*
- Buttons, checkboxes and elements of dropdown lists in panels and application menus are italicized and underscored: *Invert*, *Apply* and so on
- Shortcuts, individual keys and hardware buttons use gray highlighting: e.g., `Ctrl + A`
- Characters that appear in a field, file extension, or directory or file path employ the following style: `Scan 1`, `SPROJ`, `C:\Program Files`, and so on.

Note the following abbreviations and icons:

- LMB—left mouse button
- RMB—right mouse button
- ►—*Play/Pause* button on the scanner body

- Accuracy, 130
- accuracy – general term, 13
- Adaptive, 114
- Autopilot, 13

- buffer size, 178
- bundle, 13
- By_radius, 117

- CAD model, 13
- colorMode, 114

- decimationStep, 114

- edgeLength, 114
- effective_distance_from_scanner, 112
- error, 130

- feature_search_radius, 112
- Fill_holes, 117
- Filter_by_threshold, 119
- fine registration, 13
- force_constraints, 131
- frames, 13
- fusion, 13

- Geometry
 - for Fine registration, 99
 - for Global registration, 112
- Geometry_alignment, 112
- Geometry_and_Texture
 - for Fine registration, 99
 - for Global registration, 112

- Geometry_Ray, 112
- global registration, 13

- keep_boundary, 130
- key frames, 13
- key_frame_ratio, 112

- Leave_biggest_objects, 119

- Manually, 117
- max_hole_len, 127
- max_hole_radius, 117
- max_neighb_normals_angle, 130
- maxEdgeLength, 114
- maxIncidenceAngle, 114
- maxTriangleAngularSize, 114
- mesh, 13
- method, 114
- minDistBetweenDescriptors, 112
- minimumAngle, 114
- minTriangleAngle, 114
- mode, 119
- model, 14

- near and far cutting planes, 14
- None, 114

- project, 14

- registration_algorithm
 - for Fine registration, 99
 - for Global registration, 112
- Remesh, 130

remesh_edge_thr, [130](#)
remove_targets, [117](#)
resolution
 general term, [14](#)
resolution
 for Fusion, [117](#)
 for Outlier removal, [94](#)
rough registration, [14](#)
scan, [14](#)
section
 in a point-cloud scan, [14](#)
 in measurements, [14](#)
SectionColor, [114](#)
Simple, [114](#)
SourceColor, [114](#)
std_dev_mul_threshold, [94](#)
steps, [121](#)
stop_condition value, [130](#)
supporting surface, [14](#)

Targets, [112](#)
targets, [14](#)
Targets_Geometry, [112](#)
threshold, [119](#)
tracking, [14](#)
tri_num
 for Fast mesh simplification, [131](#)
 for Mesh simplification, [130](#)
Triangle_quantity, [130](#)

useWholeCloudTriangulation, [114](#)
UV_Triangle_quantity, [130](#)
UV_Vertex_quantity, [130](#)

voxel size, [178](#)
voxelSide, [112](#)
vrt_num, [130](#)

Watertight, [117](#)